

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KINWELL](#) /

› [KINWELL 30-inch Faux Leather Tufted High Wingback Chairs \(Set of 2\) - Instruction Manual](#)

KINWELL 148-2P

KINWELL Faux Leather Tufted High Wingback Chairs (Set of 2)

Model: 148-2P

Instruction Manual

1. INTRODUCTION

Thank you for choosing the KINWELL Faux Leather Tufted High Wingback Chairs. This set of two accent armchairs is designed to provide comfort and style to your living space. This manual provides essential information for the safe assembly, proper use, and maintenance of your new chairs. Please read these instructions carefully before assembly and retain them for future reference.



Image: Two KINWELL Faux Leather Tufted High Wingback Chairs in a living room.

2. SAFETY INFORMATION

- **Read all instructions:** Ensure you understand all assembly steps and safety warnings before proceeding.
- **Adult assembly required:** This product should be assembled by adults.
- **Keep children away:** During assembly, keep children and pets away from the work area and small parts.
- **Use on a level surface:** Assemble the chairs on a clean, flat, and soft surface (e.g., carpet) to prevent damage.
- **Do not overtighten:** Tighten all bolts and screws firmly, but do not overtighten to avoid stripping threads or cracking components.
- **Regular checks:** Periodically check all connections to ensure they remain tight.
- **Weight limit:** Do not exceed the maximum weight recommendation of 300 pounds per chair.
- **Proper use:** Use the chairs only for their intended purpose (sitting). Do not stand on the chairs or use them as a step stool.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact KINWELL customer support.

- Chair Body (x2)
- Gold Metal Legs (x8)
- Lumbar Toss Pillow (x2)
- Assembly Hardware (screws, washers, Allen wrench)

4. SETUP AND ASSEMBLY

Follow these steps to assemble your KINWELL Wingback Chairs:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Locate Legs:** The gold metal legs are typically stored in a zippered compartment underneath the seat cushion of the chair body. Unzip the compartment and retrieve the legs and hardware.
3. **Attach Legs:** Invert the chair body. Align each gold metal leg with the pre-drilled holes on the underside of the chair frame. Secure each leg using the provided screws and washers. Tighten with the Allen wrench. Ensure all legs are firmly attached and stable.
4. **Position Chair:** Carefully turn the chair upright. Ensure it stands level and does not wobble.
5. **Place Lumbar Pillow:** Position the included lumbar toss pillow on the chair for added comfort and support.



Image: Chair dimensions and leg storage location.



Image: Detail of the gold metal leg.

5. OPERATING AND USAGE

Your KINWELL Wingback Chairs are designed for comfortable seating in various indoor settings such as living rooms, dining rooms, bedrooms, or apartments.

- **Seating:** The overstuffed padded back and seat provide a comfortable experience.
- **Lumbar Support:** The removable lumbar toss pillow offers adjustable lower-back support. You can slide it higher or remove it entirely to suit your posture and comfort preference.
- **Placement:** Position the chairs on a hard floor or carpeted surface.



Image: Detail of the lumbar toss pillow.

6. MAINTENANCE

Proper care will extend the life and appearance of your chairs.

- **Cleaning:** For general cleaning, wipe the faux leather surface with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Dusting:** Regularly dust the chairs with a soft, dry cloth.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the faux leather to fade or crack. Position your chairs away from direct sunlight.
- **Avoid Sharp Objects:** Keep sharp objects away from the faux leather to prevent punctures or tears.




Image: Detail of the tufted faux leather material.

7. TROUBLESHOOTING

- **Chair wobbles:**

- Ensure all legs are securely tightened. Loosen and re-tighten if necessary, making sure the chair is on a level surface during tightening.
- Check if the floor surface is uneven. Try moving the chair to a different spot or using furniture pads under the legs to level it.

- **Loose parts:**

- Periodically check all screws and bolts and tighten them as needed.

- **Stains on faux leather:**

- For most stains, a mild soap solution on a damp cloth can be used. Test on an inconspicuous area first. Wipe clean with a dry cloth immediately.

8. SPECIFICATIONS

Feature	Detail
Brand	KINWELL
Model Name	148-2p
Color	Faux Leather in Camel
Product Dimensions	33.8"D x 30"W x 51.6"H
Material	Faux Leather (Upholstery), Foam (Fill)
Back Style	Tufted Back, Wing Back
Maximum Weight Recommendation	300 Pounds
Product Care Instructions	Wipe Clean
Included Components	Cushion (Lumbar Toss Pillow)
Item Weight	48 pounds (per chair)
Seat Height	20 Inches
Seat Depth	20 Inches
Arm Height	24.8 Inches

9. WARRANTY INFORMATION

Specific warranty details for KINWELL products may vary. Please refer to the warranty card included with your purchase or visit the official KINWELL website for the most up-to-date warranty information and terms and conditions.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing or damaged parts, please contact KINWELL customer support through the retailer where you purchased the product or visit the KINWELL official website for contact information.

For more information, you may visit the [KINWELL Store on Amazon](#).