

[Manuals.plus](#) /

> [WLIVE](#) /

> WLIVE TV Stand with Charging Station, Entertainment Center with 8 Fabric Drawer, TV Media Console Table Open Storage Shelves, Wood Top for Living Room, Hallway, Rustic Brown Rustic Brown Wood Grain Print

WLIVE ASNG104DHS2

WLIVE TV Stand with Charging Station Instruction Manual

MODEL: ASNG104DHS2

Brand: WLIVE

PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your WLIVE TV Stand with Charging Station. Designed for living rooms, hallways, nurseries, or offices, this entertainment center features a rustic brown wood grain print finish, 8 fabric drawers, open storage shelves, and an integrated charging station for convenience.

- **Integrated Charging Station:** Equipped with 2 AC sockets and 2 USB ports, featuring a 1.5m flexible cable for easy power access. UL/ETL certified for electrical safety.
- **Ample Storage:** Measures 11.7"D x 47.1"W x 33.9"H, suitable for TVs up to 35 inches. Includes 9 detachable fabric drawers and a spacious wood top for organized storage and display.
- **Stable and Safe Structure:** Constructed with a 15mm thickened metal steel frame and cross support rods, supporting up to 150 lbs. Includes an anti-tilt device for wall attachment to ensure safety.
- **Premium Design Details:** Features smooth slide tracks for drawers, curved handles, and 6 all-directional adjustable feet to adapt to various floor types and protect surfaces.
- **Durable Materials:** Drawers are made of high-quality fiberboard and breathable non-woven fabric. The desktop is P2 grade artificial wood, scratch-resistant and easy to clean. Materials are EPA & SGS tested for health and environmental safety.

IMPORTANT SAFETY INFORMATION

For your safety and to prevent injury or damage to the product, please adhere to the following guidelines:

- Always secure the TV stand to the wall using the provided anti-tipping hardware. This is crucial to prevent accidental tipping, especially in households with children or pets.

- Use the adjustable feet to ensure the unit is level on uneven floors. An unstable unit can be a tipping hazard.
- Do not overload the drawers or shelves. Exceeding the weight capacity (150 lbs for the media stand) may compromise stability and lead to tipping or structural damage.
- Keep the TV stand away from direct heat sources, such as radiators or fireplaces, to prevent warping, discoloration, or other material damage.
- Ensure all electrical connections for the charging station are secure and follow local electrical codes. Do not use the charging station if the cord is damaged.

SETUP AND ASSEMBLY

Your WLIVE TV Stand is designed for straightforward assembly. Please follow the detailed assembly guide included in the packaging. All screw parts are clearly marked, and reserved holes and necessary tools are provided for quick setup, typically within an hour.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components and hardware listed in the assembly guide are present. The product is packed with thick foam and wooden sheeting to prevent transit damage.
2. **Assemble Frame:** Begin by assembling the metal steel frame according to the instructions. Ensure all connections are secure.
3. **Attach Wood Top and Shelves:** Secure the P2 grade artificial wood top and any fixed shelves to the assembled frame.
4. **Install Charging Station:** Integrate the charging station unit into its designated slot. Connect the 1.5m power cable.
5. **Insert Fabric Drawers:** Once the frame is complete, insert the detachable fabric drawers into their respective slots. Ensure they slide smoothly.
6. **Adjust Feet:** Utilize the 6 all-directional adjustable feet to level the TV stand on your floor surface, preventing wobbling.
7. **Secure Anti-Tilt Device:** Attach the anti-tilt device to the back of the unit and secure it to a wall stud as per the instructions. This step is critical for safety.




Figure 1: Product Dimensions and Weight Capacities. This diagram illustrates the overall dimensions of the TV stand (11.7"D x 47.1"W x 33.9"H) and the weight limits for different sections, including 10 lbs for small shelves, 16 lbs for larger open shelves, and 50 lbs for the main top surface.

PRODUCT SIZE



Figure 2: Integrated Charging Station. This image highlights the power supply unit built into the TV stand, featuring two 125V/2A AC sockets and two USB ports, along with a switch and a 5-foot power cord. This allows for convenient charging of devices and powering of electronics.

OPERATING INSTRUCTIONS

Once assembled and safely secured, your WLIVE TV Stand is ready for use. Here's how to maximize its functionality:

- Placing Your Television:** Position your television on the main wood top. The stand is designed to accommodate TVs up to 35 inches. Ensure the TV is centered and stable.
- Utilizing the Charging Station:** Plug the TV stand's power cord into a wall outlet. Use the 2 AC sockets for devices like your TV, game console, or router. The 2 USB ports are ideal for charging smartphones, tablets, or other USB-powered devices. The integrated switch controls power to the outlets.
- Organizing with Fabric Drawers:** The 9 detachable fabric drawers provide ample space for storing various items such as media accessories, remote controls, books, or personal belongings. Pull the curved handles to open and close drawers smoothly.

4. **Using Open Storage Shelves:** The open shelves are suitable for displaying decorative items, books, or housing smaller media devices.



Figure 3: TV Stand in Use. This image shows the WLIVE TV Stand with a television on its top surface, a tablet charging on the side shelf, and various items stored in the fabric drawers, demonstrating its practical application in a living space.



Figure 4: Product in a Living Room Environment. This photograph displays the TV stand integrated into a modern living room, showcasing its aesthetic appeal and functional use alongside other furniture and decor.

MAINTENANCE AND CARE

Proper care will extend the life and maintain the appearance of your WLIVE TV Stand.

- **Cleaning the Wood Top:** The P2 grade artificial wood top is scratch-resistant and easy to clean. Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Cleaning Fabric Drawers:** For the fabric drawers, spot clean with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash or tumble dry the fabric drawers.
- **General Maintenance:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Adjustable Feet:** If the stand becomes uneven, re-adjust the 360-degree adjustable feet to restore stability.



Figure 5: Key Product Details. This composite image highlights important features: the waterproof nature of the wood top, the anti-tilt device for wall securing, the stable triangular structure of the fabric drawers, and the 360-degree adjustable feet for leveling.

TROUBLESHOOTING

This section addresses common issues you might encounter with your WLIVE TV Stand.

Problem	Possible Cause	Solution
TV Stand is wobbly or unstable.	Uneven floor surface; loose connections; anti-tilt device not installed.	Adjust the 6 all-directional adjustable feet to level the unit. Check and tighten all assembly screws. Ensure the anti-tilt device is properly secured to the wall.
Drawers do not slide smoothly.	Drawer not properly aligned; obstruction in the slide track; drawer overloaded.	Remove the drawer and re-insert, ensuring it is correctly aligned with the slide tracks. Check for any debris or objects obstructing the tracks. Reduce the weight in the drawer if it is overloaded.

Problem	Possible Cause	Solution
Charging station not working.	Power cord not plugged in; wall outlet issue; charging station switch off; damaged cable.	Ensure the TV stand's power cord is securely plugged into a functional wall outlet. Check if the charging station's integrated switch is in the 'on' position. Test the wall outlet with another device. If the cable is damaged, discontinue use and contact customer support.
Fabric drawers appear misshapen.	Overloading; prolonged heavy use.	Remove contents and reshape the drawer. Avoid overloading drawers beyond their intended capacity.

SPECIFICATIONS

Brand	WLIVE
Model Name	ASNG104 Storage Cabinet/DHS2
Product Dimensions	11.7"D x 47.1"W x 33.9"H
Color	Rustic Brown Wood Grain Print
Room Type	Hallway, Living Room, Nursery, Office
Item Weight	29.5 Pounds
Number of Drawers	8 (detachable fabric drawers)
Power Outlet	2 AC Sockets, 2 USB Ports, 1.5m Cable Length
Material	Metal Steel Frame, P2 Grade Artificial Wood Top, Fiberboard & Non-woven Fabric Drawers
Assembly Required	Yes
Product Care Instructions	Wipe with Damp Cloth

WARRANTY AND SUPPORT

WLIVE is committed to providing high-quality products and excellent customer service. While specific warranty details are not provided in this manual, WLIVE offers professional after-sales support to address any concerns or issues you may have with your TV stand.

For assistance with assembly, missing parts, product defects, or any other inquiries, please contact WLIVE customer service through the retailer where you purchased the product or visit the official WLIVE store online. Please have your model number (ASNG104DHS2) and purchase information ready when contacting support.

You can visit the WLIVE Store for more information:[WLIVE Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question