

BoxWave AccuPoint Active Stylus

BoxWave AccuPoint Active Stylus User Manual

Model: AccuPoint Active Stylus

Compatible with Castles S1F3 and other capacitive touchscreens

1. INTRODUCTION

Thank you for choosing the BoxWave AccuPoint Active Stylus. This electronic stylus is designed to provide a precise and natural writing and drawing experience on your capacitive touchscreen devices, such as the Castles S1F3. With its ultra-fine tip and no-pairing required operation, it offers convenience and accuracy for all your digital tasks.

2. SAFETY INFORMATION

- Keep the stylus away from water and excessive moisture.
- Do not attempt to disassemble or modify the stylus. This will void the warranty.
- Avoid extreme temperatures.
- Keep out of reach of small children due to small parts.
- Use only the provided MicroUSB cable for charging.

3. PACKAGE CONTENTS

- BoxWave AccuPoint Active Stylus
- MicroUSB Charging Cable



Image: The BoxWave AccuPoint Active Stylus shown alongside a Castles S1F3 device, illustrating the product and its intended use environment.

4. PRODUCT OVERVIEW

The AccuPoint Active Stylus features a sleek, durable design with key components for optimal performance.

- **Ultra-Fine Tip:** Provides precise input for writing and drawing.
- **FiberMesh Tip:** An alternative tip for general navigation and broader strokes.
- **Power Button/Indicator Light:** Activates the stylus and shows battery status.
- **Built-in Charging Port:** For convenient recharging.
- **Brushed Aluminum Barrel:** Ensures strength, stability, and a comfortable grip.



Image: A detailed diagram highlighting the key features of the AccuPoint Active Stylus, including the built-in charging port, indicator light, 1.9mm extra fine tip, and FiberMesh tip. It also notes that no Bluetooth is required.

5. SETUP

1. **Initial Charge:** Before first use, fully charge the stylus. Connect the provided MicroUSB cable to the stylus's charging port and the other end to a standard USB power source (e.g., computer USB port, wall adapter). The indicator light will show charging status.
2. **Power On:** Press the power button located on the stylus barrel to turn it on. The indicator light will illuminate.



Image: The AccuPoint Active Stylus connected to a laptop via its MicroUSB charging cable, demonstrating convenient charging.

6. OPERATING THE STYLUS

The AccuPoint Active Stylus operates without the need for Bluetooth pairing, making it simple to use.

1. **Activation:** Ensure the stylus is powered on (indicator light is lit).
2. **Interaction:** Simply touch the ultra-fine tip or FiberMesh tip to your device's screen. The stylus emits electronic pulses to interact with the screen, allowing for natural writing, tapping, and swiping.
3. **Precision Use:** For detailed tasks like drawing or fine writing, use the ultra-fine tip. For general navigation or quick selections, either tip can be used.
4. **Power Off:** Press the power button again to turn off the stylus when not in use to conserve battery life.

Note: The AccuPoint Active Stylus does not support Palm Rejection or Pressure Sensitivity.



Image: A hand holding the AccuPoint Active Stylus, precisely tapping an icon on a tablet screen, demonstrating its accurate interaction.

7. MAINTENANCE

- **Charging:** Recharge the stylus when the indicator light signals low battery. A full charge provides approximately 12 hours of use.
- **Cleaning:** Wipe the stylus body with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Tip Care:** Handle the stylus tips with care. If the FiberMesh tip becomes worn, it can be removed and replaced.



Image: Close-up of the stylus showing different indicator light colors for 'Power On' (blue), 'Charging' (red), and 'Full Charge' (green), illustrating the fast charging feature.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stylus does not turn on.	Low battery.	Charge the stylus fully using the provided MicroUSB cable.
Stylus is unresponsive on screen.	Stylus is off; screen protector interference; device issue.	Ensure stylus is powered on. Try on a different device or remove thick screen protectors. Restart your device.
Inaccurate input.	Worn tip; screen condition.	Ensure the tip is clean and intact. Replace FiberMesh tip if worn. Clean your device's screen.

9. SPECIFICATIONS

- **Model:** AccuPoint Active Stylus

- **Color:** Metallic Silver
- **Tip Size:** 1.9mm (Ultra-Fine Tip)
- **Battery Life:** Approximately 12 hours of continuous use
- **Charging Port:** MicroUSB
- **Material:** Brushed Aluminum Barrel
- **Weight:** 1.3 ounces
- **Compatibility:** Capacitive Touchscreens (e.g., Castles S1F3)







Image: The AccuPoint Active Stylus resting next to a smartphone, highlighting its slim profile and sleek design.


10. WARRANTY AND SUPPORT

BoxWave products are designed for quality and reliability. For warranty information or technical support, please visit the official BoxWave website or contact their customer service. Please refer to your purchase documentation for specific warranty terms.

For additional assistance, you may contact BoxWave Corporation, the seller of this product.

Related Documents - AccuPoint Active Stylus

 <p>DOUXE S3 Active Stylus Pen Instruction Manual</p>	<p>DOUXE S3 Active Stylus Pen Instruction Manual</p> <p>Comprehensive instruction manual for the DOUXE S3 Active Stylus Pen, detailing features, technical specifications, operating instructions, safety warnings, and warranty information for touchscreen device users.</p>
	<p>Penyeah Stylus Pen User Manual - DIY Combinations and Usage Guide</p> <p>Comprehensive user manual for the Penyeah P1 stylus pen, detailing DIY combinations of tips, usage instructions, and replacement procedures. Learn how to maximize your stylus experience for various devices and applications.</p>
 <p>sbs Ultra Fine Stylus Pen Designed for iPad 2018, 2019, 2020, 2021</p>	<p>SBS Ultra Fine Stylus Pen for iPad: Precision, Tilt Function, and Style</p> <p>Discover the SBS Ultra Fine Stylus Pen (Tilt Pencil) for iPad 2018-2021. Featuring tilt function, palm rejection, durable aluminum design, and a replaceable POM nib for precise, lag-free drawing and writing.</p>
 <p>POWEROLOGY NÉOTEC Active Stylus Pen SKU: PGBSTPN</p>	<p>Powerology NÉOTEC Active Stylus Pen - User Manual and Specifications</p> <p>Comprehensive guide to the Powerology NÉOTEC Active Stylus Pen (SKU: PGBSTPN), covering operation, features, specifications, compatible iPad models, and warranty information.</p>
 <p>ASUS ASUS PEN SA300</p>	<p>ASUS Pen SA300 Quick Start Guide</p> <p>This guide provides instructions on how to use and maintain the ASUS Pen SA300 Active Stylus, including package contents, inserting and replacing the battery, and replacing the pen tip and holder.</p>



[ASUS Pen 2.0 \(SA203H\) Active Stylus: Quick Start Guide](#)

Get started with your ASUS Pen 2.0 (SA203H) Active Stylus. This guide covers package contents, LED indicators, hardware interface, charging, and Bluetooth pairing instructions.