

Manuals.plus /
› Actualia /
› M15 Retro Game Stick User Manual

Actualia 64G

M15 Retro Game Stick User Manual

Model: 64G | Brand: Actualia

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your M15 Retro Game Stick. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Game Console (1 unit)
- HDMI Cord (1 unit)
- USB Charging Cable (1 unit)
- Wireless Gamepad (2 units)
- Instruction Manual (1 unit)



Image: Overview of the M15 Retro Game Stick and its included accessories.

PRODUCT FEATURES

- **Retro Game Console:** Designed for revisiting classic games, supporting 3P4P multiplayer experiences.
- **High-Definition HDMI Output:** Features 4K HDMI output (1080P/720P compatible) for clear visuals on large screens. Plug and play functionality for immediate use.
- **Extensive Compatibility:** Supports multiple classic simulators, offering high performance, low power consumption, fast program loading, smooth task processing, and fast game speed.
- **Easy Operation:** Allows users to save and collect games, customize key settings, and expand ROM to download additional games. Includes game pausing, saving, and archiving functions.
- **Wireless Connectivity:** Capable of connecting wireless gamepads, supporting up to four players for online battles.

4K HD

The upgraded version of HD is more
smooth and ready to play



Game box*1



Gamepad * 2

Image: The M15 console and gamepads, emphasizing 4K HD output capabilities.

2.4G WIRELESS CONTROLLER GAMEPAD

Support up to 10 kinds of classic simulators to
play classic nostalgic games



Game box*1



Game box*1

Image: The M15 console and gamepads, highlighting 2.4G wireless controller functionality.

SETUP GUIDE

1. **Connect the Game Stick:** Insert the M15 Retro Game Stick directly into an available HDMI port on your television or monitor.
2. **Power Connection:** Connect the provided USB charging cable to the game stick and then to a 5V/1A or 5V/2A USB power source (e.g., TV USB port, USB wall adapter).
3. **Controller Pairing:**

- Ensure the wireless gamepads have sufficient battery power.
 - The gamepads should automatically pair with the game stick upon power-up. If not, refer to the troubleshooting section.
4. **Select Input:** Switch your television or monitor's input source to the corresponding HDMI port where the game stick is connected.
 5. **Start Gaming:** The main menu should appear on your screen, allowing you to navigate and select games.



Image: The M15 console connected to a TV, ready for gameplay.

OPERATING INSTRUCTIONS

Navigating the Menu:

- Use the directional pad (D-pad) or left analog stick on the gamepad to navigate through game lists and menu options.
- Press the 'A' button (or equivalent action button) to select an option or start a game.

- Press the 'B' button (or equivalent back button) to go back to the previous menu.

In-Game Functions:

- **Pausing/Saving:** Press 'START' + 'SELECT' simultaneously to access the in-game menu for options like saving game progress, loading states, or exiting the game.
- **Game Selection:** The console supports a wide range of emulators. You can browse games by emulator type or search for specific titles.
- **Adding Games:** The system allows for ROM expansion to download and add more games. Refer to advanced user guides or online resources for detailed instructions on this process.



Image: Demonstrating gameplay with the M15 Retro Game Stick and its wireless controllers.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the console and controllers. Avoid using liquid cleaners or abrasive materials.

- **Storage:** Store the game stick and accessories in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the console and controllers with care to prevent physical damage. Avoid dropping or subjecting them to strong impacts.
- **Power:** Always disconnect the power cable when the device is not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No display on TV.	Incorrect HDMI input selected; loose HDMI connection; no power.	Ensure TV is on the correct HDMI input. Check HDMI cable connection. Verify USB power cable is securely connected and power source is active.
Controllers not responding.	Low battery; not paired; interference.	Replace controller batteries. Ensure the wireless receiver is properly inserted into the game stick. Move closer to the console to reduce interference.
Games run slowly or freeze.	Overheating; software issue.	Ensure adequate ventilation around the console. Restart the game stick. If persistent, consider a factory reset (consult support for instructions).
Cannot save game progress.	Insufficient storage; incorrect save procedure.	Check available storage space. Ensure you are using the 'START' + 'SELECT' menu to save games properly.

SPECIFICATIONS

Component	Detail
Material	ABS
CPU	Aigame, Duad-core Cortex-A7 up to 1.0GHz
Voltage Input	5V/1A/2A
Memory Performance	DDRIII 256M
Interface	HDMI Output, 1080P, 720P
Supported Languages	English, Spanish, Portuguese, Korean, Arabic, and more.
Product Dimensions	17 x 12 x 6 cm (6.69 x 4.72 x 2.36 inches)
Product Weight	480g
Input Device	Gamepad
Model Name	M15 Game Console
Color	White
Recommended Age	12 years and up



Image: Various angles of the M15 Retro Game Stick console, detailing its ports and design.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided on the product packaging or visit the official Actualia website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Actualia. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can I purchase just one replacement controller with its dongle for the Actualia M15 Retro Game Stick, and what is the price?

This website provides product manuals and support information but is not a retailer and does not handle sales or pricing. According to the product information for the Actualia M15 Retro Game Stick, the console...

[Read full answer](#)

Is it possible to install Nintendo 64 games on the Actualia M15 Retro Game Stick, and if so, how?

The Actualia M15 Retro Game Stick is designed to support multiple classic simulators and emulators. While the manual does not explicitly list Nintendo 64 (N64) in its basic specifications, it does state that the...

[Read full answer](#)

How do I format the SD card for my Actualia M15 Retro Game Stick?

The official manual for the Actualia M15 Retro Game Stick does not provide a built-in formatting utility within the console menu. If you need to format the SD card for ROM expansion or because...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0CYWL8CVV>

More documents and user manuals: <https://manuals.plus/>