

Gyfimoie G0001050

Gyfimoie Dresser for Bedroom with Full Length Mirror, 6-Drawer Storage Cabinet with LED Lights and Charging Station

Brand: Gyfimoie | **Model:** G0001050

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Gyfimoie 6-Drawer Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all parts are securely fastened before use.
- To prevent tipping, the dresser must be securely attached to a wall using the provided anti-tip device. This is crucial for safety, especially in households with children.
- Do not overload drawers. Distribute weight evenly.
- Keep small parts away from children during assembly.

PACKAGE CONTENTS

Verify that all components and hardware are present before starting assembly. Refer to the included parts list in your physical package for specific quantities and identification. Below is a general overview of the dresser and its dimensions.




Image Description: This image displays the overall dimensions of the dresser, measuring approximately 47.3 inches in width, 15.3 inches in depth, and 30.8 inches in height. It also shows the dimensions of the accompanying full-length mirror, which is 47.2 inches long and 15.7 inches wide. Internal drawer and shelf dimensions are also indicated.

SETUP AND ASSEMBLY

Assembly of the Gyfimoie dresser requires careful attention to detail. Please follow the step-by-step instructions provided in your physical assembly manual. The following video demonstrates the assembly process, which can be a helpful visual aid.

Your browser does not support the video tag.

Video Description: This video provides a visual guide to assembling the Gyfimoie 6-drawer dresser. It demonstrates the process of attaching various panels, installing drawer slides, and constructing the drawer boxes. The video highlights key steps and component placement to assist with successful assembly.

Ensure all screws and connectors are tightened appropriately. Do not overtighten to avoid damaging the material. The anti-tip device should be installed as the final step to secure the dresser to the wall.



Built-in Charging Station



125V/12A
2 AC Outlets



5V/2A
2 USB Ports



4.9FT
Power Cord

Image Description: This image highlights the quality construction features of the dresser, including the safety anti-tip kit, the use of premium MDF material, a stable base design, and a structurally fixed design for enhanced durability.

OPERATING INSTRUCTIONS

LED Lighting System

The dresser features multi-color RGB LED light strips. These lights can be controlled via a remote or a dedicated mobile application. You can adjust colors, brightness, and choose from various modes including music, voice, and timing modes to create your desired ambiance.



Image Description: This image illustrates the customizable LED lighting feature of the dresser. It shows the open storage spaces illuminated in different colors (red, pink, green, blue) and details the control options available, including app control for RGB colors, microphone mode, music mode, timing function, and key control.

Your browser does not support the video tag.

Video Description: This video demonstrates the various features of the Gyfimoie 6-drawer dresser, including the functionality of the LED lights. It showcases different color options and modes, providing a visual representation of how the lighting system can enhance the room's atmosphere.

Integrated Charging Station

The top surface of the dresser includes a built-in charging station with 2 AC power outlets (125V/12A) and 2 USB ports (5V/2A). This allows for convenient charging of electronic devices such as laptops, mobile phones, and other small appliances directly from the dresser.

Built-in Charging Station




125V/12A
2 AC Outlets


5V/2A
2 USB Ports


4.9FT
Power Cord

Image Description: This image provides a close-up view of the dresser's built-in charging station, featuring two AC power outlets and two USB ports. A smartphone and a smartwatch are shown actively charging, demonstrating the convenience of this feature.

Full-Length Mirror

The dresser comes with a versatile 47.24"x15.74" full-length mirror. This mirror can be used in several ways:

- Mounted vertically on a wall.
- Hung separately on a door.
- Mounted horizontally on a wall to serve as a dressing table mirror.
- Leaned against a wall for flexible placement.



Image Description: This composite image illustrates the flexible placement options for the full-length mirror. It shows the mirror positioned vertically beside the dresser, mounted horizontally above it, and leaning against a wall, demonstrating its adaptability to different room layouts and user preferences.

MAINTENANCE

Cleaning and Care

- Wipe the dresser surfaces with a dry, soft cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- For spills, wipe immediately with a damp cloth and then dry thoroughly.
- Periodically check all hardware connections to ensure they remain tight. Retighten if necessary.
- Keep the dresser away from direct sunlight and excessive moisture to prevent warping or discoloration.

TROUBLESHOOTING

Common Issues and Solutions

- **Drawers not gliding smoothly:** Ensure the drawer slides are correctly installed and aligned. Check for any obstructions in the tracks. Verify that all screws securing the slides are tight.
- **LED lights not working:** Check if the power adapter is securely plugged into both the dresser and a working wall outlet. Ensure the remote control has fresh batteries and is pointed directly at the receiver. If using the app, ensure Bluetooth or Wi-Fi connection is active and the app is updated.
- **Dresser wobbles:** Confirm that the dresser is placed on a level surface. Recheck all assembly hardware to ensure tightness. Install the anti-tip device as instructed to stabilize the unit.
- **Charging station not providing power:** Verify that the power cord for the charging station is fully plugged into a live wall outlet. Check if the power strip itself has an on/off switch and is in the 'on' position. Test with different devices and cables to rule out device-specific issues.

SPECIFICATIONS

- **Brand:** Gyfimoie
- **Model Name:** Dresser-1050 (G0001050)
- **Product Dimensions:** 15.35"D x 47.32"W x 30.86"H
- **Color:** White
- **Number of Drawers:** 6
- **Drawer Type:** Ball Bearing Slide
- **Material:** High-Quality MDF
- **Features:** Full-Length Mirror (47.24"x15.74"), Multi-color RGB LED Lights, Built-in Charging Station (2 AC outlets 125V/12A, 2 USB ports 5V/2A)
- **Item Weight:** 96.3 pounds
- **Assembly Required:** Yes

WARRANTY AND SUPPORT

For any questions, concerns, or issues regarding your Gyfimoie dresser, please contact the manufacturer's customer support. Refer to the contact information provided in your product packaging or visit the official Gyfimoie website for assistance. Please have your model number (G0001050) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question