



Manuals.plus /

› URIZONS /

› URIZONS JM13 Ball Shape Earhook Wireless Earbuds Instruction Manual

URIZONS JM13

URIZONS JM13 Ball Shape Earhook Wireless Earbuds Instruction Manual

Model: JM13

1. INTRODUCTION

Thank you for choosing the URIZONS JM13 Ball Shape Earhook Wireless Earbuds. These earbuds are designed to provide a high-fidelity audio experience with features tailored for gaming, sports, and everyday use. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

2. PRODUCT OVERVIEW & COMPONENTS

The URIZONS JM13 earbuds feature a unique ball-shape design with earhooks for a secure and comfortable fit. The charging case is compact and includes a hang string for portability.



Image 1: URIZONS JM13 Ball Shape Earhook Wireless Earbuds and Charging Case. The image displays the purple ball-shaped charging case with the two earhook earbuds nestled inside. A purple hang string is attached to the case.

Package Contents:

- URIZONS JM13 Wireless Earbuds (Left & Right)
- Ball Shape Charging Case
- Charging Cable
- Hang String
- User Manual

Key Features:

- **Earpiece Shape:** Ball Shape, Open Ear design
- **Connectivity:** Bluetooth 5.0 (Wireless)
- **Audio:** 12mm Dynamic Audio Driver, Enhanced Bass Stereo Sound, High-Definition Call with Noise Cancellation
- **Controls:** Touch Control for media and calls
- **Battery Life:** Up to 5 hours per charge (earbuds)
- **Charging:** Fast Charging (1.5 hours for full charge)
- **Special Features:** Breathing Light, Microphone Included, Hang String for portability

3. SETUP

3.1 Initial Charging

Before first use, fully charge the earbuds and charging case. Connect the provided charging cable to the USB-C port on the charging case and a compatible USB power source. The charging time is approximately 1.5 hours.

3.2 Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** The earbuds automatically power off when placed back into the charging case. Alternatively, during usage, double-click the pointed touch area on the earbud to power it off.



Image 2: The image shows the URIZONS JM13 earbuds and charging case. An arrow points to the touch-sensitive area on the earbud, indicating where to double-click for power off functionality.

3.3 Bluetooth Pairing

1. Ensure the earbuds are charged and removed from the charging case to power on.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "JM13" from the list of available devices to pair.
4. Once paired, the earbuds will indicate a successful connection (e.g., a voice prompt or indicator light change).

Video 1: This video demonstrates the Bluetooth pairing process for the URIZONS JM13 Ball Shape Earhook Wireless Earbuds. It shows how to activate pairing mode and connect to a mobile device.

3.4 Changing Voice Prompt Language (Chinese to English)

If the wireless earbuds' voice prompts are in Chinese, you can change them to English. Before the Bluetooth earbud is paired with your mobile device, double-click the pointed touch area on the earbud. This action will toggle the language between Chinese and English.

4. OPERATING INSTRUCTIONS

4.1 Wearing the Earbuds

The JM13 earbuds feature an open-ear earhook design for comfort and awareness of your surroundings. Gently place the earhook over your ear, ensuring the speaker rests comfortably near your ear canal without entering it directly.



**Comfortable to wear for a long time
True! Senseless Wear**

Adoption of the back-arc cavity design. SFE technology for long-lasting comfort.

Image 3: A woman is shown wearing the URIZONS JM13 earbud on her ear, demonstrating the comfortable and secure fit of the earhook design.

4.2 Touch Controls

The earbuds are equipped with touch-sensitive controls on the pointed area (refer to Image 2 for location) for easy management of music and calls.

- **Play/Pause Music:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Long press on either earbud during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.

5. CHARGING

The earbuds are charged by placing them into the charging case. The charging case itself is charged via a USB-C cable.

- **Earbud Charging:** Place the earbuds correctly into their respective slots in the charging case. They will automatically begin charging.
- **Case Charging:** Connect the provided USB-C cable to the charging port on the case and a USB power adapter (not included). The case has an indicator light to show charging status.
- **Battery Life:** Earbuds provide approximately 5 hours of playback on a single charge. The charging case extends the total listening time.

6. CARE & MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** These earbuds are **Not Water Resistant**. Avoid exposure to water, sweat, rain, or excessive moisture to prevent damage.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and ensure they remain charged. Store in a cool, dry place.
- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) as this can affect battery life and performance.

IPX5

IPX5 life-grade waterproof, waterproof and splash-proof, let you fearless of weatherproof, to meet the daily life of

dustproof and waterproof



Image 4: The purple ball-shaped charging case is shown with water droplets on its surface. A text overlay indicates that the product is IPX5 life-grade waterproof, but the product specifications state 'Not Water Resistant'. For optimal longevity, avoid water exposure.

7. TROUBLESHOOTING

- **Earbuds not powering on:** Ensure the earbuds are charged. Place them in the charging case for a few minutes, then remove them.
- **Earbuds not pairing:** Ensure Bluetooth is enabled on your device and the earbuds are in pairing mode (removed from case). Forget previous pairings on your device and try again.
- **No sound or low volume:** Check the volume levels on both your device and the earbuds. Ensure earbuds are properly seated in your ears.
- **Voice prompts in wrong language:** Before pairing, double-click the touch area on the earbud to switch languages.
- **Intermittent connection:** Ensure your device is within the 10-meter Bluetooth range and there are no significant obstructions.

8. SPECIFICATIONS

Feature	Specification
Model Name	JM13
Brand	URIZONS
Connectivity Technology	Wireless (Bluetooth 5.0)
Earpiece Shape	Ball Shape, Open Ear
Noise Control	Active Noise Cancellation
Sensitivity	98 dB
Audio Driver Type	Dynamic Driver
Battery Life (Earbuds)	5 Hours
Charging Time	1.5 Hours
Bluetooth Range	10 Meters
Control Method	Touch
Water Resistance Level	Not Water Resistant
Material	Plastic
Product Dimensions	1.57 x 1.57 x 1.57 inches
Item Weight	1.06 ounces (30 Grams)
UPC	768472543769

9. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official URIZONS website. Keep your purchase receipt as proof of purchase for any warranty claims.