

jioeinly T221

jioeinly Slim Case for Powmus T221 10 Inch Tablet - Instruction Manual

Model: T221 | Brand: jioeinly

INTRODUCTION

This manual provides instructions for the proper installation, usage, and maintenance of your jioeinly Slim Case, designed for the Powmus T221 10 Inch Tablet. Please read this manual thoroughly before use to ensure optimal performance and protection for your device.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x jioeinly Slim Case for Powmus T221 10 Inch Tablet

INSTALLATION GUIDE

1. **Prepare Your Tablet:** Ensure your Powmus T221 10 Inch Tablet is clean and free of dust or debris.
2. **Align the Tablet:** Gently align your tablet with the case, ensuring the camera, ports, and buttons match the case's cutouts.
3. **Insert the Tablet:** Carefully push the tablet into the case, starting with one side or corner, until it is securely seated within the protective frame. Ensure all four corners of the tablet are fully enclosed by the case's protective corners.
4. **Check Fit:** Verify that the tablet is snug and does not move freely within the case. All ports, speakers, and buttons should remain accessible and functional.

Ergonomic Structure



Built-in magnets bolster different positions.



Image: The tablet case provides all-over protection, ensuring device ports, speakers, and buttons remain fully functional and accessible.

OPERATING INSTRUCTIONS

Using the Flip Stand Feature

The case is designed with a folding cover that converts into a stand, offering multiple viewing angles for your tablet.

1. **Viewing Angle:** To set up for viewing, fold the front cover back and position it to create a triangular support structure. This allows for an upright viewing angle suitable for watching videos or video calls.
2. **Typing Angle:** For a lower, more ergonomic typing angle, fold the cover differently to create a shallower support. This position is ideal for typing or drawing.



Image: The case allows for two primary stand positions: an upright viewing angle and a lower typing angle, facilitated by built-in magnets.

Magnetic Closure

The case features side magnets that ensure the cover remains securely closed when not in use, protecting the tablet screen and facilitating easier handling.

PRODUCT FEATURES

- **Enhanced Protection:** Equipped with four protective corners designed to minimize the risk of damage from accidental drops and impacts.
- **Slim and Lightweight Design:** Manufactured using a voltage process, resulting in a thinner and lighter profile for comfortable portability.
- **Durable Aesthetics:** Features an exquisite inkjet pattern that maintains its brightness and resists fading over time.
- **Integrated Stand Functionality:** The flip cover allows the tablet to be positioned in a standing orientation for hands-free viewing or typing.
- **Secure Closure:** Side magnets ensure the case remains closed, providing continuous screen protection.
- **Additional Storage:** Includes features for card insertion and stashing small change.



Image: The jioeuinly Slim Case in a closed position, showcasing its design and slim profile.

CARE AND MAINTENANCE

To maintain the appearance and functionality of your tablet case, follow these guidelines:

- **Cleaning:** Wipe the case gently with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these may damage the material or pattern.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Avoid Sharp Objects:** Prevent contact with sharp objects to avoid scratches or punctures to the case material.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Tablet does not fit securely.	Incorrect tablet model or improper installation.	Ensure your tablet is a Powmus T221 10 Inch Tablet. Re-align and gently push the tablet into the case, ensuring all corners are seated.

Problem	Possible Cause	Solution
Stand feature is unstable.	Improper folding of the cover.	Adjust the fold of the cover to create a stable triangular support. Ensure the magnetic points are engaged.
Case cover does not close completely.	Obstruction or misalignment.	Check for any foreign objects between the cover and the tablet. Ensure the tablet is correctly seated and not protruding.

SPECIFICATIONS

Product Dimensions: 0.39 x 0.39 x 0.39 inches

Item Weight: 2.46 ounces

Form Factor: Flip Case

Color: DJS (Specific pattern/design)

Compatibility: Powmus T221 10 Inch Tablet

Special Features: Card insertion, Stash the change, Thickened anti-drop corner protector, Folding stand, Magnetic closure

Manufacturer: jioeuinly

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available documentation. For support inquiries, please refer to the retailer or manufacturer's official website for contact details.