

TOPTECH STAR-115

STAR-115 15" Woofer Portable Bluetooth Speaker

User Instruction Manual

1. INTRODUCTION

Thank you for purchasing the TOPTECH STAR-115 Portable Bluetooth Speaker. This powerful speaker is designed to deliver blazing sound with a vibrant flame light show, perfect for home use, outdoor gatherings, and parties. Please read this manual carefully before operating the device to ensure proper use and to maximize its performance and lifespan.

2. SAFETY INFORMATION

- Do not expose the speaker to water or excessive moisture. This product is not waterproof.
- Avoid placing the speaker near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the speaker during lightning storms or when unused for long periods.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

3. PACKAGE CONTENTS

Please check the box for the following items:

- STAR-115 Portable Bluetooth Speaker
- Remote Control
- Wired Microphone
- Power Adapter
- User Manual (this document)
- Warranty Card

4. PRODUCT OVERVIEW

Familiarize yourself with the various parts of your STAR-115 speaker.



Front view of the STAR-115 speaker, showcasing its 15-inch woofer and vibrant multi-color flame light display.



Side view of the STAR-115 speaker, highlighting its integrated handle and wheels for easy portability.

Control Panel (Top/Rear)

- **Power Button:** Turns the speaker on/off.

- **Mode Button:** Switches between Bluetooth, FM Radio, AUX, USB, and TF Card modes.
- **Volume Control:** Adjusts the master volume.
- **Microphone Input:** For connecting the wired microphone.
- **USB Port:** For USB flash drives.
- **TF Card Slot:** For TF (MicroSD) cards.
- **AUX Input:** For connecting external audio devices via a 3.5mm cable.
- **Light Mode Button:** Controls the flame light effects.
- **Previous/Next Track Buttons:** Navigates through tracks in media playback modes.
- **Play/Pause Button:** Controls playback.

5. SETUP

5.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided power adapter to the speaker's charging port and plug it into a standard wall outlet. The charging indicator light will show the charging status (e.g., red for charging, off or green for fully charged).



The speaker features a reliable battery for extended playback. Ensure it is fully charged before use.

A full charge provides approximately 6 hours of battery life, depending on usage and volume levels.

5.2 Powering On/Off

Press and hold the **Power Button** on the control panel to turn the speaker on or off.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Connection

The STAR-115 speaker is compatible with Bluetooth-enabled devices for wireless audio streaming.

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.

2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "STAR-115" from the list of devices.
4. Once connected, the speaker will emit a confirmation sound, and the LED light will stop flashing.



Quick and easy connection via Bluetooth, USB, TF card, AUX, or FM Radio.

6.2 USB/TF Card Playback

Insert a USB flash drive or TF (MicroSD) card into the respective port. The speaker will automatically switch to USB/TF mode and begin playing audio files (MP3, WAV, etc.) from the storage device.

- Use the Previous/Next Track buttons to navigate.
- Press the Play/Pause button to control playback.

6.3 AUX Input

Connect an external audio device (e.g., MP3 player, laptop) to the speaker's AUX input using a 3.5mm audio cable. The speaker will automatically switch to AUX mode. Control playback from your connected device.

6.4 FM Radio

Press the **Mode Button** to switch to FM Radio mode. The speaker will automatically scan and save available

radio stations. Use the Previous/Next Track buttons to switch between saved stations.

6.5 Microphone Usage

Connect the wired microphone to the Microphone Input port. Adjust the microphone volume using the dedicated knob on the control panel (if available) or the master volume.

6.6 Flame Light Operation

The STAR-115 features a multi-color flame light show. Press the **Light Mode Button** to activate or change the lighting effects. Press again to cycle through different patterns or turn off the lights.



One click activation of multi-color disco lights adds extra excitement to your gathering.

6.7 True Wireless Stereo (TWS) Pairing

For an unparalleled stereo sound experience, you can pair two STAR-115 speakers together.

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (refer to control panel diagram if available, or try the Mode button for 3 seconds if no dedicated TWS button).
3. The primary speaker will search for the secondary speaker. Once connected, both speakers will emit a confirmation sound.

4. Now, connect your mobile device to the primary speaker via Bluetooth as described in section 6.1. Audio will play through both speakers in stereo.



Pair two speakers to get true wireless stereo sound, creating a harmonious and immersive sound environment.

6.8 Remote Control Usage

The included remote control allows for convenient operation from a distance. Functions include power on/off, mode selection, volume control, track navigation, play/pause, and light control.

7. MAINTENANCE

7.1 Cleaning

Wipe the speaker's exterior with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Avoid spraying liquids directly onto the speaker.

7.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery periodically (e.g., every 3 months) to maintain its health.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Connect the speaker to the power adapter and charge it.
No sound.	Volume is too low or muted.	Increase the volume on the speaker and your connected device.
Bluetooth connection fails.	Speaker is not in pairing mode; device is too far; interference.	Ensure speaker is in pairing mode. Move device closer. Disconnect other Bluetooth devices. Try restarting both speaker and device.
USB/TF card not playing.	Incorrect file format; card/drive not inserted correctly; corrupted files.	Ensure files are in supported format (MP3, WAV). Reinsert the card/drive. Try a different card/drive.
Microphone not working.	Microphone not connected properly; microphone volume too low.	Ensure microphone is fully plugged in. Adjust microphone volume.
TWS pairing fails.	Speakers already connected to other devices; too far apart.	Ensure both speakers are disconnected from other Bluetooth devices. Place them close together during pairing.

9. SPECIFICATIONS

Feature	Detail
Model Name	STAR-115
Speaker Type	Woofer
Woofer Diameter	15 Inches
Connectivity Technology	Bluetooth

Feature	Detail
Wireless Communication Technology	Bluetooth
Bluetooth Range	33 Feet (10 Meters)
Power Source	Battery Powered
Battery Life	6 Hours
Speaker Maximum Output Power	150 Watts
Audio Output Mode	Stereo
Included Components	Remote control, wired microphone, adapter, user manual, warranty card
Product Dimensions	1"D x 1"W x 1"H (Note: This appears to be a placeholder, actual dimensions may vary)
Color	Black
Is Waterproof	FALSE
Manufacturer	Top Tech Audio
UPC	755824425859

10. WARRANTY AND SUPPORT


10.1 Warranty Information

This product comes with a Limited Warranty. Please refer to the included Warranty Card for detailed terms and conditions, including coverage period and what is covered. Keep your purchase receipt as proof of purchase for warranty claims.

10.2 Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact TOPTECH customer support. Contact information can typically be found on the product packaging, warranty card, or the official TOPTECH website.

For more information, you may visit the [TOPTECH Store on Amazon](#).



[Bosch PWS Angle Grinder User Manual and Safety Guide](#)

Official user manual for Bosch PWS series angle grinders. Includes detailed safety instructions, operating procedures, product features, technical specifications, and maintenance information.



[Geberit Duofix Frame, Smyle WC, Sigma Flush Plate: Product Overview](#)

Comprehensive overview of Geberit's wall-hung toilet installation systems, including the Duofix frame, Smyle Square WC, compatible seats, and Sigma01 flush plates. Features detailed specifications, application purposes, and technical data.



[Geberit 109.304.00.5 In-Wall Tank System Installation Guide](#)

This guide provides detailed installation instructions, product specifications, troubleshooting tips, and warranty information for the Geberit 109.304.00.5 In-Wall Tank System with Dual Flush Technology, manufactured by Geberit and distributed by Chicago Faucets.



[Alfa Romeo Spider 1989 Edition Workshop Manual](#)

Comprehensive workshop manual for the Alfa Romeo Spider, 1989 Edition. Provides detailed instructions for tune-up, repair, overhaul, disassembly, assembly, checks, inspections, and troubleshooting.



[NewAir NPR122GA00 Portable 115 Quart Car Fridge and Freezer Owner's Manual](#)

This owner's manual provides comprehensive instructions for the NewAir NPR122GA00 Portable 115 Quart Car Fridge and Freezer, covering specifications, safety information, operating instructions, and maintenance.



[American Dryer AD-115 Installation and Operator's Manual](#)

This comprehensive manual details the installation, operation, and maintenance of the American Dryer AD-115 series dryers (Gas, Electric, Steam). It includes critical safety warnings, technical specifications, step-by-step installation guides, routine maintenance procedures, and troubleshooting tips for optimal performance and safety.