Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kssvzz RX-CF-OR-EU

Kssvzz Portable Camping Fan with LED Lantern User Manual

Model: RX-CF-OR-EU

1. Introduction

Thank you for choosing the Kssvzz Portable Camping Fan with LED Lantern. This versatile device is designed to provide powerful airflow and illumination for various indoor and outdoor activities, including camping, hiking, fishing, and office use. With its long-lasting battery and multiple features, it ensures comfort and convenience wherever you go.

2. Product Features

- **20000mAh Super-large Capacity Battery:** Provides extended operation time.
- **4 Speed Quiet Airflow:** Adjustable fan speeds for optimal comfort with low noise (less than 28 dB).
- **3 Level Brightness LED Lantern:** Integrated LED light with adjustable brightness for various lighting needs.
- **270-Degree Adjustable Angle:** Allows you to direct airflow precisely.
- **360-Degree Rotating Hanging Hook:** Offers flexible placement options, suitable for tents, umbrellas, hammocks, or RVs.
- **Multipurpose Power Supply:** Can be used as an emergency power bank via USB output (1W-6W).
- **Fast Charging:** Type-C input voltage: 5V-2A.
- **Compact and Portable Design:** Easy to carry and store for travel and outdoor adventures.
- **Durable Construction:** Made with plastic finish and 3 blades.

3. Package Contents

Upon opening the box, please verify that all items are present and in good condition:

- 1 x Kssvzz Portable Camping Fan with LED Lantern
- 1 x USB Type-C Charging Cable



Figure 3.1: Front of the product packaging, showing the fan and key features.




Figure 3.2: Side of the product packaging, detailing usage tips and warnings.

4. Setup

Before first use, it is recommended to fully charge the fan.

1. **Unboxing:** Carefully remove the fan and its accessories from the packaging.
2. **Initial Charge:** Connect the provided USB Type-C cable to the charging port on the back of the fan and plug the other end into a compatible USB power source (e.g., wall adapter, power bank). The battery indicator lights will show the charging progress.



Figure 4.1: Charging the fan and using it as a power supply.

5. Operating Instructions

5.1 Fan Operation

The fan features 4 adjustable wind speeds. The battery indicator lights will show the remaining charge (e.g., 75% battery indicated by 3 lights).

1. **Power On/Off:** Press the fan speed button once to turn on the fan at the lowest speed.
2. **Adjust Fan Speed:** Press the fan speed button repeatedly to cycle through the 4 speeds. Each press will increase the speed.

3. **Battery Life per Speed (approximate):**
    - Speed 1: Up to 32 hours
    - Speed 2: Up to 24 hours
    - Speed 3: Up to 16 hours
    - Speed 4 (Max): Up to 8 hours



Figure 5.1: Fan speed settings and corresponding battery life.

5.2 LED Lantern Operation

The fan includes an integrated LED lantern with 3 brightness levels.

1. **Power On/Off:** Press the light button once to turn on the LED lantern at the lowest brightness.
2. **Adjust Brightness:** Press the light button repeatedly to cycle through the 3 brightness levels.
3. **Battery Life per Brightness Level (approximate):**
    - Low Brightness: Up to 38 hours

- Middle Brightness: Up to 24 hours
- High Brightness: Up to 10 hours



Figure 5.2: LED lantern brightness levels and corresponding battery life.

5.3 Adjusting Fan Angle and Hook

- **Fan Angle:** The fan head can be manually tilted up to 270 degrees to direct airflow as needed.
- **Hanging Hook:** The integrated hook on the base can rotate 360 degrees, allowing you to hang the fan from various supports.



Figure 5.3: Fan with 270-degree adjustable angle.



Figure 5.4: Fan with 360-degree rotating hanging hook.

5.4 Using as a Power Bank

The fan can serve as an emergency power supply to charge other devices. Simply connect your device's USB cable to the appropriate output port on the fan.

6. Maintenance

- **Cleaning:** Gently wipe the fan and LED surface with a soft, dry cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** If the fan will not be used for an extended period, charge it fully and store it in a cool, dry place. It is recommended to charge the fan every three months to maintain battery health.
- **Safety:** Do not put your fingers or any objects into the fan net when the fan is working. Do not remove the front and back cover of the fan to reassemble this product. Do not use this product near fire or in wet areas.

7. Troubleshooting

- **Fan or LED Light Not Working:** If the fan stops working or the LED light is not functioning, please charge the fan. Check the battery indicator lights to confirm charge level.
- **Weak Airflow:** Ensure the fan is set to a higher speed setting. Check for any obstructions in front or behind the fan.
- **Charging Issues:** Ensure the USB-C cable is securely connected to both the fan and the power source. Try a different USB port or power adapter.

8. Specifications

Brand	Kssvzz
Model Name	X23-Orange
Item Model Number	RX-CF-OR-EU
Color	Orange
Product Dimensions	4"D x 8"W x 10"H
Item Weight	1.54 pounds (700 Grams)
Power Source	Battery Powered (20000mAh Lithium Polymer)
Number of Power Levels	4 (Fan)
Light Type	LED (3 Brightness Levels)
Noise Level	28 dB
Voltage	5 Volts
Wattage	6 watts
Connector Type	USB Type C
Material	Plastic
Indoor/Outdoor Usage	Outdoor, Indoor
Specification Met	CE, RoHS

9. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or contact Kssvzz customer service directly. Keep your purchase receipt for any warranty claims.

© 2024 Kssvzz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYZ5B238

More documents and user manuals: **https://manuals.plus/**