## SAMMIX AW105

# SAMMIX Digital Picture Frame

**Model: AW105 - User Manual**

## 1. Introduction

This manual provides detailed instructions for setting up, operating, and maintaining your SAMMIX 10.1 Inch WiFi Digital Picture Frame, Model AW105. This device allows you to easily share and display your cherished photos and videos with family and friends from anywhere in the world.

## 2. Key Features

- **Private Sharing:** Instantly share moments with your frame via the Uhale phone application.
- **Multiple Upload Methods:** Upload photos and videos via Uhale Phone App (iOS/Android), Micro SD card, USB cable from a computer, or the Uhale Web App.
- **High-Definition Display:** Features a 10.1-inch IPS LCD panel with 1280x800 resolution for clear viewing from any angle.
- **Touch Screen Interface:** Easy navigation and operation directly on the frame.
- **Ample Storage:** Built-in 16GB memory, expandable with up to 32GB Micro SD card.
- **Flexible Placement:** Designed for both tabletop display and wall-mounting, supporting both portrait and landscape orientations.
- **Customizable Settings:** Includes features like sleep mode, weather and time display, adjustable brightness, slideshow settings, and the ability to send instant or timed wishes.




Overview of the SAMMIX Digital Picture Frame's core functionalities.

## 3. Product Overview

The SAMMIX AW105 digital picture frame is designed for ease of use and versatile display. It features a sleek black frame and a responsive touch screen.




The SAMMIX Digital Picture Frame in use, showcasing its display and app connectivity.




The frame supports automatic rotation and can be placed on a desktop or mounted on a wall.

## 4. Setup Guide

### 4.1. Powering On

Connect the provided power adapter to the frame and plug it into a power outlet. The frame will automatically power on.

### 4.2. Connecting to Wi-Fi

1. On the frame's touch screen, navigate to Settings.
2. Select 'Wi-Fi' and choose your desired network from the list.
3. Enter the Wi-Fi password and confirm.

### 4.3. Downloading the Uhale App


The Uhale app is essential for sharing photos and videos remotely. Download it from your smartphone's app store:

- For iOS devices: Search for "Uhale" in the Apple App Store.
- For Android devices: Search for "Uhale" in the Google Play Store.

### 4.4. Pairing the Frame with the App

To link your frame with the Uhale app:

1. Open the Uhale app on your smartphone and create an account or log in.
2. On your SAMMIX frame, go to the 'Add Friend' or 'Pairing' section. You will see a QR code and a unique pairing code (e.g., 1307470077).
3. In the Uhale app, select the option to add a new frame. You can either scan the QR code displayed on the frame or manually enter the pairing code.
4. Once paired, your frame will be ready to receive photos and videos from your app.





Steps for downloading the Uhale app, logging in, and pairing your frame.

## 5. Operating Instructions

### 5.1. Sharing Photos and Videos

There are multiple ways to share content with your SAMMIX digital picture frame:

- **Uhale Phone App:**
  Select photos or videos (max 120 seconds) from your phone's gallery within the Uhale app. Choose the recipient frame(s) and send. You can send up to 100 photos at a time.




Detailed steps for sharing photos and videos using the Uhale app.

- **Micro SD Card:**
  Insert a Micro SD card (up to 32GB) containing JPG/JPEG/BMP/PNG images or MP4 videos into the frame's SD card slot. The frame can play content directly from the card or allow you to import/export files.
- **PC Transfer (USB Cable):**
  Connect the frame to your computer using a USB cable (not included). The frame will appear as a removable drive, allowing you to drag and drop photos and videos directly.
- **Uhale Web App:**
  Access the Uhale Web App from your computer's browser. You can upload up to 500 photos at once without needing to install any software.




Transferring content from a PC to the frame via USB cable or Web App.

### 5.2. Managing Content and Settings

Use the touch screen to navigate the frame's interface and adjust settings:

- **Viewing Content:** Swipe left or right to browse photos and videos. Tap on a file to view it in full screen.
- **Slideshow Settings:** Adjust slideshow interval, transition effects, and display order (e.g., by date, random).
- **Show/Hide Photo Caption, Weather & Temperature:** You can configure the frame to display real-time weather and time, or hide photo captions and sender names for privacy.




Option to show or hide photo captions, weather, and temperature on the display.

- **Sleep Mode & Clock:** Set a schedule for the screen to turn on/off to save energy. When in sleep mode, the frame can function as a digital clock.




The frame's sleep mode functionality, allowing it to act as a clock during off-hours.

- **Sending Wishes:** Use the Uhale app to send instant or timed greeting cards to the frame.



Sending personalized wishes to the frame via the Uhale app.

- **Other Features:** Withdraw photos via the app, mark favorite photos, sort by date/friends, fit to frame/full screen, adjust brightness.




Additional customizable features available on the SAMMIX digital picture frame.

## 6. Storage Information

The SAMMIX AW105 comes with 16GB of built-in internal memory. This allows for storage of a significant number of photos and videos directly on the device.
For expanded storage or bulk file transfers, the frame supports Micro SD cards up to 32GB. You can play content directly from the Micro SD card or use it to import/export files to and from the internal memory.




The frame offers large internal storage and supports Micro SD card expansion.

## 7. Maintenance

To ensure the longevity and optimal performance of your digital picture frame, follow these maintenance guidelines:

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution specifically designed for electronics. Avoid harsh chemicals or abrasive materials.

- **Cleaning the Frame:** Wipe the frame's body with a dry, soft cloth.
- **Power Off When Not in Use:** If storing the frame for an extended period, power it off and unplug it from the power source.
- **Avoid Extreme Conditions:** Do not expose the frame to extreme temperatures, direct sunlight for prolonged periods, or high humidity.
- **Ventilation:** Ensure the ventilation openings on the frame are not blocked to prevent overheating.

## 8. Troubleshooting

If you encounter issues with your SAMMIX Digital Picture Frame, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Frame does not power on. | Power adapter not connected or faulty outlet. | Ensure the power adapter is securely connected to the frame and a working power outlet. Try a different outlet. |
| Cannot connect to Wi-Fi. | Incorrect password, weak signal, or network issue. | Double-check the Wi-Fi password. Move the frame closer to the router. Restart your router and the frame. |
| Photos/Videos not appearing on frame. | Incorrect file format, transfer error, or app issue. | Ensure files are JPG/JPEG/BMP/PNG for photos or MP4 for videos. Verify successful transfer via app/USB/SD card. Check app's history for transfer status. |
| Touch screen is unresponsive. | Temporary software glitch or dirty screen. | Restart the frame by unplugging and re-plugging the power. Clean the screen with a soft, dry cloth. |
| Frame is slow or freezes. | Too many files, low memory, or software issue. | Delete unnecessary files to free up space. Restart the frame. If persistent, consider a factory reset (refer to advanced settings). |

If the problem persists after trying these solutions, please contact SAMMIX customer support.

## 9. Specifications

| Feature | Detail |
|---|---|
| Brand | SAMMIX |
| Model Number | AW105 |
| Screen Size | 10.1 Inches |
| Resolution | 1280x800 |
| Internal Storage | 16GB |
| External Storage Support | Micro SD Card (up to 32GB) |
| Compatible Devices | iPad, Android Smartphone |
| Product Dimensions | 7.3 x 10.5 x 0.99 inches |

| Feature | Detail |
| --- | --- |
| Item Weight | 0.634 ounces |
| Supported Image Formats | JPG/JPEG/BMP/PNG |
| Supported Video Formats | MP4 (max 120s via app) |

## 10. Warranty and Support

SAMMIX stands by the quality of its digital picture frames. Each unit undergoes rigorous testing to ensure reliability.

- **Warranty:** Your SAMMIX Digital Picture Frame comes with a 1-year warranty from the date of purchase.
- **Customer Support:** We provide lifetime support for our products. If you have any questions, issues, or require assistance, our 24-hour online service is available to help.

Please refer to the contact information provided with your product packaging or visit the official SAMMIX website for support details.

© 2024 SAMMIX. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question