

[Manuals.plus](#) /

› [YJWFHPU](#) /

› YJWFHPU Dog Training Collar with Remote User Manual

YJWFHPU B0CYZCSPNG

YJWFHPU Dog Training Collar with Remote User Manual

Model: B0CYZCSPNG

1. INTRODUCTION

Thank you for choosing the YJWFHPU Dog Training Collar with Remote. This device is designed to assist in effective and humane dog training, offering various modes to suit your dog's needs and temperament. Please read this manual thoroughly before use to ensure proper operation and safety for your pet.



Image: The YJWFHPU Dog Training Collar system, showing the remote control and the collar receiver.

Key Features:

- **3 Training Modes:** Beep (1-8 levels), Vibration (1-16 levels), and Electric Shock (1-99 levels) for customizable training.
- **Extended Control Range:** Up to 1640 feet (500 meters) for training in various environments.
- **IP67 Waterproof Receiver:** The collar receiver is waterproof, suitable for use in wet conditions or during swimming. The remote control is splash-proof.
- **Quick Charging & Long Battery Life:** Both devices charge in 2-3 hours, providing 7-15 days of continuous use.
- **Adjustable Collar:** Suitable for middle to large dog breeds weighing 5-120 lbs.
- **Reflective Strip:** Enhances visibility for night walks.

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines to prevent harm to your pet or damage to the device:

- **Not for Aggressive Dogs:** Do not use this product on aggressive dogs. Consult a professional trainer for such cases.
- **Collar Fit:** Ensure the collar fits snugly but not too tightly. It should allow one finger to fit between the strap and your dog's neck.
- **Wear Duration:** Do not leave the collar on your dog for more than 12 hours per day. Prolonged wear can cause skin irritation.
- **Skin Checks:** Regularly check your dog's neck for signs of irritation, redness, or sores. If found, discontinue use and consult a veterinarian.
- **Children:** Keep the device and all its components out of reach of children.
- **Water Immersion:** The receiver is IP67 waterproof, but the remote control is only splash-proof. Do not immerse the remote in water.
- **Proper Use of Static Mode:** Use the static (electric shock) mode responsibly and only when necessary, starting at the lowest level. This mode is intended for correction, not punishment.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your training collar system:



Image: Detailed diagram illustrating the remote control's screen display, keypad lock, LED flashlight, mode buttons (Bip, Vibration, Shock), channel selection, and the receiver's indicator light, silicone protective case, on/off button, vibration probes, and charging port.

Remote Control:

- Screen Display
- Keyboard Lock
- LED Flashlight Mode
- Bip Mode Button
- Vibration Mode Button

- Shock Mode Button
- Select Level Buttons
- Select Channel Button

Receiver Collar:

- Indicator Light
- Silicone Protective Case
- On/Off Button
- Vibration Probes (Contact Points)
- Charging Port

4. SETUP GUIDE

4.1 Charging the Devices

Before first use, fully charge both the remote control and the receiver collar.

1. Connect the included charging cable to the charging ports on both the remote and the receiver.
2. Plug the USB end of the cable into a standard USB power adapter (not included), computer, power bank, or car charger.
3. The indicator lights on both devices will show charging status (refer to device display for specifics).
4. Charging typically takes 2-3 hours. Once fully charged, disconnect the cable.



Image: Illustration showing the remote and receiver being charged simultaneously using a dual USB charging cable, compatible with various USB power sources.

4.2 Fitting the Collar

Proper fit is crucial for the effectiveness and safety of the training collar.

1. Ensure the receiver is turned off.

2. Place the receiver collar around your dog's neck, positioning the receiver unit centrally under the chin or on the side of the neck.
3. Adjust the strap so it is snug but not tight. You should be able to fit one finger comfortably between the strap and your dog's neck.
4. The contact points (probes) on the receiver should make consistent contact with your dog's skin. If your dog has thick fur, you may need to trim the fur slightly or use longer contact points (if provided).
5. The collar is adjustable and suitable for dogs weighing 5-120 lbs.

4.3 Pairing the Remote and Receiver

The remote and receiver are usually pre-paired. If they are not, or if you need to re-pair them:

1. Turn on the remote control.
2. Turn on the receiver collar.
3. On the remote, select the desired channel (e.g., CH1 or CH2).
4. Press and hold the power button on the receiver collar until the indicator light flashes rapidly.
5. Within 10 seconds, press any mode button (Beep, Vibration, or Shock) on the remote control.
6. If pairing is successful, the receiver's indicator light will stop flashing and remain solid, or beep to confirm.



Image: Illustration demonstrating the remote's capability to control two separate receiver collars for training two dogs simultaneously by switching channels.

5. OPERATING INSTRUCTIONS

5.1 Understanding Training Modes

The YJWFHPU training collar offers three distinct modes:



Image: Visual representation of the three training modes: Beep (8 frequencies), Vibration (Level 1-16), and Electric Shock (Level 1-99).

- **Beep Mode (8 Levels):** Emits an audible tone. Often used as a warning or for positive reinforcement.
- **Vibration Mode (1-16 Levels):** Delivers a non-harmful vibration. Useful for getting your dog's attention or as a mild correction.
- **Electric Shock Mode (1-99 Levels):** Provides a static stimulation. This mode should be used as a last resort for serious behavioral issues and always at the lowest effective level.

5.2 Using the Remote Control

1. **Turn On/Off:** Press the power button on the remote to turn it on or off.
2. **Select Channel:** Use the 'CH' button to switch between channels if training multiple dogs.
3. **Select Mode:** Press the respective button for Beep, Vibration, or Shock mode.
4. **Adjust Level:** Use the '+' and '-' buttons to adjust the intensity level for Vibration or Shock modes. Start at the lowest level and increase gradually until your dog responds.
5. **Activate Correction:** Press the selected mode button again to deliver the correction.
6. **Keypad Lock:** Use the keypad lock feature to prevent accidental activation.
7. **LED Flashlight:** Activate the LED flashlight for visibility in low-light conditions.



Image: A dog wearing the training collar, with a hand holding the remote control, illustrating the training process.

5.3 Control Range

The collar system offers an extended control range of up to 1640 feet (500 meters) in open areas. Environmental factors such as terrain, buildings, and electromagnetic interference can affect the actual range.



Image: A black dog wearing the training collar, with an overlay illustrating the 500-meter control range of the remote control.

6. MAINTENANCE

6.1 Cleaning

- Wipe the receiver collar and remote control with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the charging port cover on the receiver is securely closed when not charging to maintain its waterproof integrity.

6.2 Battery Care

- Recharge the devices when the battery indicator shows low power.
- For long-term storage, charge the devices to about 50% and store them in a cool, dry place. Recharge every few months to prevent deep discharge.

6.3 Waterproofing

The receiver collar is IP67 waterproof, meaning it can withstand immersion in water up to 1 meter for 30 minutes. This makes it suitable for use in rain or during swimming. However, the remote control is only splash-proof and should not be submerged.



Image: Illustration showing the collar receiver submerged in water, indicating its IP67 waterproof rating, suitable for use during rain or bathing.

7. TROUBLESHOOTING

If you encounter issues with your YJWFHPU Dog Training Collar, please refer to the following common solutions:

Problem	Possible Cause	Solution
Collar not responding to remote	Low battery; Not paired; Out of range; Incorrect channel selected	Charge both devices; Re-pair the devices (see Section 4.3); Move closer to the dog; Select the correct channel on the remote.
No static/vibration correction	Contact points not touching skin; Level too low; Fur too thick	Adjust collar fit; Increase intensity level gradually; Trim fur around contact points or use longer probes (if available).
Remote screen is blank	Low battery; Remote is off	Charge the remote; Press the power button to turn it on.

Problem	Possible Cause	Solution
Short control range	Environmental interference; Obstacles	Move to an open area; Avoid areas with strong electromagnetic signals.
Dog shows skin irritation	Collar worn too long/too tight; Allergic reaction	Remove collar immediately; Clean the area; Consult a veterinarian. Ensure proper fit and wear duration (max 12 hours/day).

8. PRODUCT SPECIFICATIONS

- **Model:** B0CYZCSPNG
- **Brand:** YJWFHPU
- **Training Modes:** Beep (1-8 levels), Vibration (1-16 levels), Electric Shock (1-99 levels)
- **Control Range:** Up to 1640 feet (500 meters)
- **Receiver Waterproof Rating:** IP67 (Remote is splash-proof)
- **Battery Type:** Lithium Ion (included)
- **Charging Time:** 2-3 hours
- **Battery Life:** 7-15 days (continuous use)
- **Suitable Dog Weight:** 5-120 lbs
- **Item Weight:** 12.3 ounces
- **Package Dimensions:** 6.69 x 5.59 x 1.81 inches
- **Included Components:** Remote control, Receiver collar, Charging cable
- **Care Instructions:** Keep away from Children

9. WARRANTY AND CUSTOMER SUPPORT

YJWFHPU stands by the quality of its products.

- **1-Year Warranty:** This product comes with a 1-year warranty from the date of purchase. During this period, we offer free returns and exchanges for manufacturing defects.
- **24/7 Customer Service:** If you have any questions, concerns, or require assistance with your dog training collar, please do not hesitate to contact our customer service team. We are available 24/7 to assist you.

For support, please refer to the contact information provided with your purchase or visit the official YJWFHPU store page on Amazon.