

- [Manuals.plus](#) /
- › [Aroepurt](#) /
 - › Dialn X10 Pulse Tablet Case User Manual

Aroepurt Dialn X10 Pulse Tablet Case HD

User Manual

AROEPURT SLIM CASE FOR DIALN X10 PULSE TABLET

Model: HD (Compatible with Dialn X10 Pulse)

1. Introduction

Thank you for choosing the Aroepurt Slim Case for your Dialn X10 Pulse Tablet. This flip stand cover is designed to provide comprehensive protection and enhanced usability for your device. It features a slim and lightweight design, four protective corners, side magnets for secure closure, and an exquisite inkjet pattern. This manual will guide you through the installation, operation, and maintenance of your new tablet case.



Figure 1: Aroepurt Slim Case with vibrant butterfly and floral artwork.

2. Setup and Installation

Installing your Dialn X10 Pulse Tablet into the Aroepurt Slim Case is a straightforward process. Ensure your tablet is clean and free of debris before installation.

1. **Prepare the Case:** Open the flip cover of the case.
2. **Align the Tablet:** Carefully align your Dialn X10 Pulse Tablet with the case's internal frame, ensuring that the camera, ports, and buttons align with the corresponding cutouts on the case.
3. **Insert the Tablet:** Gently press the tablet into the case, starting with one side and then the other, until it is securely seated within the protective corners. The four protective corners are designed to minimize the risk of drop damage.
4. **Check Fit:** Verify that the tablet is snug and all edges are covered by the case. Ensure all ports and buttons are accessible and functional.

ALL-OVER PROTECTION

Goes into every side & corner



Device ports, speakers, buttons all work fine



Slim & Lightweight



Figure 2: Illustration of tablet insertion and protective features. The image shows the case's corners providing all-over protection and highlights its slim and lightweight profile.

Note: This case does not include a dedicated keyboard position. It is designed for tablet-only use.

3. Operating Instructions

The Aroepurt Slim Case offers versatile functionality to enhance your tablet experience.

3.1. Using the Flip Stand Feature

The case is designed with a folding stand feature, allowing you to position your tablet at various angles for comfortable viewing or typing.

1. **Viewing Angle:** To set up for viewing, fold the front cover back and tuck it into the designated groove or magnetic area on the back of the case. This creates a stable triangular stand ideal for watching videos or making video calls.
2. **Typing Angle:** For a lower, more ergonomic typing angle, fold the cover differently to create a shallower incline. This position is suitable for typing or drawing.

Ergonomic Structure



Built-in magnets bolster different positions.



Figure 3: Demonstrates the ergonomic structure of the case, showing both viewing and typing angles supported by built-in magnets.

3.2. Secure Closure

The case features side magnets that ensure the cover remains securely closed when not in use, protecting your tablet screen from scratches and impacts.

3.3. Port and Button Access

Precision cutouts provide full access to all ports, speakers, and buttons of your Dialn X10 Pulse Tablet without needing to remove the case.

4. Maintenance

To ensure the longevity and appearance of your Aroepurt Slim Case, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the exterior of the case with a soft, damp cloth. For stubborn stains, a mild soap solution can be used, but avoid harsh chemicals or abrasive cleaners as they may damage the exquisite inkjet pattern.
- **Drying:** Allow the case to air dry completely before reinserting your tablet.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent fading of the pattern.
- **Avoid Sharp Objects:** Keep the case away from sharp objects that could scratch or puncture its surface.

5. Troubleshooting

If you encounter any issues with your tablet case, please refer to the following common solutions:

- **Case Does Not Fit Tablet:**
Ensure you have the correct model of tablet (Dialn X10 Pulse) for this specific case. Double-check the alignment during installation. If the tablet is forced, it may not be the correct model or is not aligned properly.
- **Stand Feature is Unstable:**
Ensure the folding stand is correctly engaged and tucked into the magnetic groove. The surface on which the tablet is placed should be flat and stable. The built-in magnets are designed to bolster different positions securely.
- **Magnets Not Holding Cover Closed:**
Check if there is any debris or foreign object preventing the magnets from making full contact. Ensure the tablet is seated correctly within the case, as misalignment can prevent proper closure.
- **Pattern Fading:**
The exquisite inkjet pattern is designed for long-lasting vibrancy. To prevent premature fading, avoid prolonged exposure to direct sunlight and harsh chemicals.

6. Specifications

Product Name	Aroepurt Slim Case for Dialn X10 Pulse Tablet
Model	HD (Compatible with Dialn X10 Pulse)
Brand	Aroepurt
Product Dimensions	0.39 x 0.39 x 0.39 inches

Item Weight	2.46 ounces
Form Factor	Flip Case
Shell Type	Hybrid
Special Features	Card insertion, Stash the change, Thickened anti-drop corner protector + folding stand
What's in the Box	1*Tablet Case

7. Warranty and Support

Aroepurt is committed to providing high-quality products. For any questions, concerns, or support needs regarding your Aroepurt Slim Case, please contact the retailer or manufacturer directly. Please retain your proof of purchase for any warranty claims.

Specific warranty details may vary by region and retailer. Refer to the product packaging or the point of purchase for detailed warranty information.

© 2024 Aroepurt. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CYZJDSRT>

More documents and user manuals: <https://manuals.plus/>