

RAINPOINT B0CYZQFDF7

RAINPOINT Bluetooth Water Timer Instruction Manual

MODEL: B0CYZQFDF7

Brand: RAINPOINT

INTRODUCTION

Thank you for choosing the RAINPOINT Bluetooth Water Timer. This smart device is designed to simplify your garden watering, offering precise control and efficiency. With its dual-zone capabilities and Bluetooth connectivity, you can manage your irrigation schedules directly from your smartphone. This manual provides comprehensive instructions for setup, operation, and maintenance to ensure optimal performance of your water timer.

For additional features and remote control, this timer can be paired with a compatible RainPoint Smart Hub (sold separately) to enable Wi-Fi connectivity.

PACKAGE CONTENTS

- 1 x RAINPOINT Bluetooth Water Timer (Model: B0CYZQFDF7)
- 1 x User Manual
- Quick Start Guide

Note: 4 x AA alkaline batteries are required and not included in the package.

SPECIFICATIONS

Feature	Detail
Brand	RAINPOINT

Model	B0CYZQFDF7
Color	Green
Material	Metal
Product Dimensions	5.83"D x 3.23"W x 6.34"H
Item Weight	1.45 pounds
Number of Settings	12
Connectivity	Bluetooth (can be upgraded to Wi-Fi with optional hub)
Watering Modes	Normal, Interval, Cycle & Soak
Watering Frequency	Daily, Weekly, Odd Days, Even Days, Every 2-30 Days

SETUP GUIDE

1. Battery Installation

The RAINPOINT Bluetooth Water Timer requires 4 AA alkaline batteries for operation. To install, open the battery compartment on the back of the timer and insert the batteries, ensuring correct polarity. Close the compartment securely. Refer to Video 1 for a visual guide on battery installation.

2. App Installation and Connection

To control your water timer, download the "RainPoint Smart+" app from your device's app store. Follow the on-screen instructions to register an account and log in. Once the app is installed, ensure your phone's Bluetooth is enabled. The app will guide you through the process of adding your new water timer. Keep your smartphone within 196 feet (60 meters) of the timer for a stable Bluetooth connection.

Your browser does not support the video tag.

Video 1: Detailed guide on connecting the timer to the app and setting up watering plans.

BLUETOOTH CONNECTION

No smart hub included



Figure 1: Bluetooth connection between the timer and the smartphone app.

3. Physical Installation

Attach the timer's inlet to your outdoor faucet. Hand-tighten only to prevent damage. Then, connect your garden hoses to the timer's outlets. The timer features two independent zones for customized watering.

6 WATERING PLANS PER ZONE

2 watering modes, meet all watering needs



Figure 2: Proper installation of the water timer to a faucet and hoses.

OPERATING INSTRUCTIONS

Programming Watering Schedules

The RainPoint Home APP allows you to set up to 6 watering schedules per zone. You can choose from three watering modes and five frequencies to meet diverse watering needs:

- **Normal Irrigation:** Set duration from 1 minute to 12 hours.

- **Interval Irrigation:** Set duration from 1 second to 60 minutes.
- **Cycle & Soak:** Set duration from 1 minute to 12 hours.

Watering frequencies include daily, weekly, odd days, even days, or every 2 to 30 days.

HIGHLY FLEXIBLE WATERING FREQUENCY

Water in the way you want



Everyday

Everyday	☒
Interval	☐
Customize	☐

Cancel | Confirm



Every 2-30 Day

07
08
09
Every 10 Day



Day of the Week

Monday	☒
Tuesday	☐
Wednesday	☒
Thursday	☐

Figure 3: Setting flexible watering frequencies via the app.

Manual Watering

You can initiate manual watering directly from the app or by pressing the button on the timer. This allows for immediate watering without affecting your programmed schedules.

MANUAL WATERING

You can choose between "irrigation" or "interval" watering as needed

Timer: 10 mins



APP: 1min - 12h



Figure 4: Manual watering activation via the app.

Rain Delay Function

To prevent overwatering during rainy periods, utilize the rain delay feature. You can set a delay of 24, 48, or 72 hours, after which your scheduled watering will automatically resume.

RAIN DELAY

Skip the watering schedules, avoid overwatering



Figure 5: Rain delay options to skip watering schedules.

Seasonal Adjustment

The seasonal adjustment feature automatically modifies watering durations based on a percentage you set (10%-200%) for each month. This eliminates the need for frequent manual adjustments as seasons change.

SEASONAL PLANNING FOR WATERING

Meet the watering needs of different seasons





Figure 6: Seasonal adjustment for optimized watering throughout the year.

MAINTENANCE

- **Battery Replacement:** Replace batteries annually or when the low battery indicator appears in the app. Use only new alkaline batteries.
- **Cleaning:** Periodically check the inlet filter for debris and clean it to ensure proper water flow. Use a soft brush and water.
- **Winterization:** Before freezing temperatures, remove the timer from the faucet, drain all water, and store

it indoors in a dry, protected area. Remove batteries if storing for extended periods.

- **Seal Inspection:** Regularly inspect the rubber washers and seals for wear and tear. Replace if necessary to prevent leaks.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Timer not watering.	Low batteries, incorrect schedule, faucet off, clogged filter.	Replace batteries. Check app schedule. Ensure faucet is fully open. Clean inlet filter.
Water leaking from connections.	Loose connection, worn washer, damaged threads.	Tighten connections (hand-tighten only). Replace rubber washer. Inspect threads for damage.
Cannot connect to app via Bluetooth.	Timer out of range, Bluetooth off on phone, app issue.	Move closer to the timer (within 196 ft). Enable Bluetooth on your phone. Restart the app or phone.
Schedules not running as expected.	Rain delay active, seasonal adjustment, incorrect time zone.	Check if rain delay is active in the app. Verify seasonal adjustment settings. Confirm correct time zone in app settings.

WARRANTY INFORMATION

RAINPOINT products are manufactured to high-quality standards and are warranted against defects in materials and workmanship. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official RAINPOINT website.

CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your RAINPOINT Bluetooth Water Timer, please contact our customer support team. Contact information can be found on the RAINPOINT website or in the product packaging.

For additional resources and FAQs, please visit the [RAINPOINT Store on Amazon](#).

 USER MANUAL Model: ITV205 Email: service@rainpoint.us WhatsApp: +1 858-365-5162 Toll Free: 1-855-361-5658 (US) 858-365-5658 (US) 858-365-5162 (INTL) Save the user manual for future reference. If you have any questions, please contact us to get support.	RainPoint ITV205 Water Timer User Manual Comprehensive user guide for the RainPoint ITV205 automatic garden hose timer, covering setup, programming for multiple zones, rain delay, manual watering, troubleshooting, and maintenance.
 USER MANUAL 1-Zone Water Timer Model No. ITV105 Save the user manual for future reference. If you have any questions, please contact us to get support.	RainPoint 1-Zone Water Timer User Manual (Model ITV105) Comprehensive user manual for the RainPoint ITV105 1-Zone Water Timer, detailing installation, programming, additional functions like Rain Delay and Manual Watering, troubleshooting, precautions, and warranty information.
 USER MANUAL ☐ English ☐ Español Model: ITV105 Email: service@rainpoint.us WhatsApp: +1 858-365-5162 Toll Free: 1-855-361-5658 (US) 858-365-5658 (US) 858-365-5162 (INTL) Save the user manual for future reference. If you have any questions, please contact us to get support.	RainPoint ITV105 Automatic Water Timer User Manual User manual for the RainPoint ITV105 automatic water timer, detailing installation, programming, operation, maintenance, and troubleshooting for efficient garden watering.
 USER MANUAL Quickdial Automatic Hose Timer Model No. ITV152 Save the user manual for future reference. If you have any questions, please contact us to get support.	RainPoint Quickdial Automatic Hose Timer User Manual ITV152 Comprehensive user manual for the RainPoint Quickdial Automatic Hose Timer (Model No. ITV152). This guide covers product overview, specifications, installation, programming irrigation duration and frequency, manual operation, cleaning, troubleshooting, precautions, warranty policy, and customer support.
 QUICK START GUIDE Model No. ITV305 and ITV405	RainPoint ITV305/ITV405 Quick Start Guide: Easy Hose Timer Setup Get your RainPoint ITV305 and ITV405 hose timers up and running quickly with this easy-to-follow quick start guide. Learn installation, battery insertion, programming, and troubleshooting for your garden watering.
 USER MANUAL ☐ English ☐ Español Model: ITV105 Email: service@rainpoint.us WhatsApp: +1 858-365-5162 Toll Free: 1-855-361-5658 (US) 858-365-5658 (US) 858-365-5162 (INTL) Save the user manual for future reference. If you have any questions, please contact us to get support.	RainPoint ITV105 User Manual: Your Guide to Automated Garden Watering This user manual provides comprehensive guidance for the RainPoint ITV105 automatic water timer. Learn how to install, program, and maintain your device for efficient garden irrigation and water conservation.

