

[Manuals.plus](#) /

› [Newday](#) /

› Newday 52-inch Ceiling Fan with Lights and Remote Instruction Manual (Model ND-52-1235)

Newday ND-52-1235

Newday 52-inch Ceiling Fan with Lights and Remote Instruction Manual

Model: ND-52-1235 | Brand: Newday

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Newday 52-inch Ceiling Fan. This modern ceiling fan features a quiet DC motor, integrated dimmable LED lighting with adjustable color temperatures, and a convenient remote control. It is designed for both indoor and outdoor use, offering reversible airflow for year-round comfort.

SAFETY INFORMATION

- Always disconnect power at the circuit breaker before installation or servicing.
- Ensure all electrical connections comply with local codes and ordinances.
- Mount the fan to a ceiling joist or support structure capable of holding at least 35 lbs (15.9 kg).
- Do not bend the blade holders during installation or cleaning.
- Keep children away from the fan during operation.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Ceiling Fan unit
- Mounting Hardware
- Remote Control
- LED Light Kit
- Fan Blades (3)
- Down Rods (various sizes, if applicable)



Image: The Newday 52-inch ceiling fan, remote control, and reversible fan blades showing both white and wood grain sides.

SPECIFICATIONS

Feature	Specification
Brand	Newday
Model Name	DY1235-3B/52 (ND-52-1235)
Size	52 inches
Product Dimensions	52"D x 52"W x 13.2"H
Color	White
Number of Blades	3
Motor Type	DC Motor
Fan Speeds	6 (with Natural Wind Mode)
Airflow	Up to 5600 CFM
Light Kit	Dimmable LED, 3 Color Temperatures (3000K, 4000K, 6500K)
Control Method	Remote Control
Timer	1/3/6 Hour Options
Indoor/Outdoor Usage	Indoor, Outdoor
Installation Type	Down Rod Mount & Angled (up to 15°)
Power Source	DC
Voltage	110 Volts
Wattage	24 watts
Item Weight	12.1 Pounds

Batteries for Remote

2 AAA batteries required (not included)



Image: Diagram showing the dimensions of the 52-inch ceiling fan, including a 13.2-inch height and 5-inch downrod.

INSTALLATION

The Newday 52-inch ceiling fan is designed for straightforward installation. Most parts are pre-assembled to simplify the process. A step-by-step video guide is available to assist you.

Pre-Installation Checklist

- Ensure power is OFF at the circuit breaker.
- Gather all necessary tools (screwdriver, wire strippers, ladder, etc.).
- Confirm your ceiling can support the fan's weight (minimum 35 lbs).

Mounting

The fan supports both standard downrod mount and angled ceiling installations (up to 15 degrees). Follow the detailed instructions provided in the packaging for secure mounting.

Newday – DIY Friendly in Just 1 Hour!



Newday 52" Ceiling Fan

- ✓ Step-by-step video guide included
- ✓ Save \$50+ on electrician costs
- ✓ All tools included in the box
- ✓ 1-hour setup – Just follow the video!



Other Ceiling Fan

- X Requires licensed electrician
- X Complex wiring – Risk of mistakes
- X Pay \$50+ extra for installation
- X Half-day work – Time wasted!

Wiring

Blade Attachment

[illegible]

Installation Video

Your browser does not support the video tag.

OPERATING INSTRUCTIONS

Your Newday ceiling fan is operated using the included remote control. Ensure 2 AAA batteries are installed correctly.



Image: The remote control for the Newday ceiling fan, showing buttons for fan speed, light control, timer, and directional airflow.

Fan Speed Control

- Press buttons **1** through **6** to select desired fan speed (1 being the lowest, 6 being the highest).
- **Sleep Mode:** Press the moon icon button to activate sleep mode. This mode simulates natural wind by cycling through speeds 1, 2, and 3 every 20 seconds, providing a gentle and quiet airflow.



Image: Visual representation of the Newday ceiling fan's six wind speeds, categorized for sleeping, entertainment, and fitness.

Light Control

- Press **LIGHT ON** to turn the light on, and **LIGHT OFF** to turn it off.
- **Color Temperature Adjustment:** Long press the **WW** button for Warm White (3000K), **NW** for Natural White (4000K), or **DW** for Cool White (6500K).
- **Brightness Adjustment:** Use the **+** and **-** buttons to adjust the brightness from 20% to 100%.



Image: Illustration of the Newday ceiling fan's dimmable LED light, showing Warm White (3000K), Natural White (4000K), and Cool White (6500K) settings.

Memory Function

The fan's light has a memory function. To set a preferred color temperature and brightness:

1. Turn the light on and select your desired color temperature and brightness.
2. Leave the light on for at least 10 seconds.
3. Turn off the light.
4. Wait for at least 10 seconds before turning it back on.

The light will restore to your last selected settings. *Note: If you turn the light on again within 10 seconds of turning it off, the color temperature will switch.*



Image: Visual guide explaining how to use the light memory function, emphasizing the 10-second wait period.

Reversible Airflow (Summer/Winter Mode)

The DC motor allows for reversible blade rotation, optimizing air circulation for different seasons:

- **Summer Mode (Forward):** Blades rotate counter-clockwise, pushing air downward to create a cooling breeze.
- **Winter Mode (Reverse):** Blades rotate clockwise, drawing air upward to circulate warm air evenly throughout the room.



Image: Diagram illustrating the reversible airflow feature, showing downward airflow for cooling in summer and upward airflow for circulating warm air in winter.

Timer Function

Set the fan to automatically turn off after a specified period:

- Press **1H** for 1 hour.
- Press **3H** for 3 hours.

- Press **6H** for 6 hours.

This feature is useful for energy saving and convenience, especially during sleep.

MAINTENANCE

Cleaning

- Always turn off the power before cleaning.
- Wipe the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Regularly check for dust accumulation on the blades and motor to ensure optimal performance.

General Care

- Periodically check all connections and screws to ensure they are secure.
- The LED light kit is designed for long-term use and typically does not require replacement.

TROUBLESHOOTING

If you encounter issues with your Newday ceiling fan, refer to the following common solutions:

Problem	Possible Cause	Solution
Fan does not start	No power, loose wiring, remote control issues.	Check circuit breaker. Ensure all wiring is secure. Replace remote batteries. Re-pair remote if necessary (refer to remote pairing instructions in full manual).
Light does not work	Loose connection, LED kit malfunction, power issue.	Check wiring to the light kit. Ensure power is supplied. If the LED light board is damaged or lost, contact customer service for a replacement.
Fan wobbles	Loose blades, unbalanced blades, improper mounting.	Ensure all blade screws are tightened. Use the included balancing kit if necessary. Verify the mounting bracket is securely installed.
Remote not responding	Dead batteries, remote not paired.	Replace AAA batteries. Refer to the full manual for remote pairing instructions.
Noise during operation	Loose screws, motor issue, blades hitting an obstruction.	Tighten all screws. Ensure no obstructions are near the blades. The DC motor is designed for quiet operation; if noise persists, contact support.

WARRANTY AND SUPPORT

Newday offers a comprehensive warranty and dedicated customer support for your ceiling fan.

- **Warranty:** The entire ceiling fan unit is covered by a 2-year warranty. The DC motor is covered by a 10-year warranty.
- **Customer Service:** For any questions or issues during use, including installation problems or replacement parts (e.g., LED light board, remote control), please contact our 24/7 customer service team. You can find product support through your order details on Amazon.



Image: Graphic detailing the 2-year warranty for the fan and 10-year warranty for the motor, along with customer support information.