

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [vidaXL](#) /

› [vidaXL Kids Wooden Picnic Table \(Model 832596\) - Instruction Manual](#)

vidaXL 832596

vidaXL Kids Wooden Picnic Table - Instruction Manual

Model: 832596

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your vidaXL Kids Wooden Picnic Table. Please read these instructions carefully before assembly and retain them for future reference. This picnic table is designed for children aged 2-8 years.

SAFETY INFORMATION

- Ensure all parts are securely fastened before use. Regularly check for loose screws or damaged components.
- This product is intended for outdoor use only.
- Maximum weight capacity: 110.2 lbs (50 kg). Do not exceed this limit.
- Supervise children during use to prevent accidents.
- Keep small parts away from young children during assembly to avoid choking hazards.
- Do not allow children to climb on the table or stand on the seats.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed in the assembly guide are present. The package includes all necessary picnic table pieces and an assembly guide.

- Wooden table top sections
- Wooden seat sections
- Legs and support beams
- Fasteners (screws, bolts, nuts)
- Assembly Guide

SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended that two people assemble the table. A screwdriver is recommended for assembly (not included).

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Check against the included assembly guide to ensure all pieces are present.
2. **Assemble Legs:** Attach the leg pieces to form the A-frame structures as indicated in the assembly guide. Ensure all screws are tightened securely.
3. **Attach Seats:** Secure the wooden seat sections to the assembled leg frames using the provided fasteners. Make sure the seats are level and firmly attached.
4. **Install Tabletop:** Place the tabletop sections onto the upper supports of the leg frames. Fasten the tabletop securely, ensuring it is stable and level.
5. **Final Check:** Once assembled, gently shake the table to confirm stability. Tighten any loose fasteners.



Image: Angled view of the assembled vidaXL Kids Wooden Picnic Table, showcasing its structure and natural pine finish.




Image: Close-up of the wooden joints and screws, highlighting the solid pine construction and secure fastenings.

OPERATING AND USAGE

The vidaXL Kids Wooden Picnic Table is designed for various outdoor activities for children aged 2-8. It provides a stable surface for:

- Picnics and outdoor meals
- Crafts and drawing activities
- Playing games
- Socializing with other children

The slatted design of the seats and tabletop promotes ventilation, enhancing comfort during use.



Image: The vidaXL Kids Wooden Picnic Table placed in a grassy garden, with building blocks and a toy car on the tabletop, demonstrating its use for play.

MAINTENANCE

Proper care will extend the life of your wooden picnic table.

- **Cleaning:** Wipe the table surfaces with a damp cloth to remove dirt and spills. Avoid using harsh chemicals or abrasive cleaners, as these can damage the wood finish.
- **Drying:** After cleaning or rain, ensure the table is thoroughly dried to prevent water damage and mold growth.
- **Protection:** As the table has an untreated finish, consider applying a suitable wood sealant or outdoor furniture oil annually to protect it from weather elements and prolong its lifespan.
- **Storage:** During prolonged periods of non-use or harsh weather conditions, it is recommended to store the table indoors or cover it with a protective outdoor furniture cover.

TROUBLESHOOTING

- **Table feels wobbly:** Check all screws and bolts to ensure they are tightened securely. Re-tighten if necessary. Ensure the table is on a flat, even surface.
- **Wood appears discolored or weathered:** This is normal for untreated wood exposed to outdoor elements. Apply a wood sealant or outdoor furniture oil to restore and protect the finish.
- **Difficulty with assembly:** Refer to the detailed assembly guide included in your package. Ensure you have the correct tools (screwdriver recommended). If issues persist, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	vidaXL
Model Number	832596
Material	Solid Pine Wood
Color	Natural Pine (Brown)
Dimensions (W x L x H)	38.2 in x 34.6 in x 20.5 in (97 cm x 88 cm x 52 cm)
Item Weight	27.34 lbs (14.6 kg)
Age Range	2-8 years
Maximum Weight Capacity	110.2 lbs (50 kg)
Indoor/Outdoor Use	Outdoor Only
Assembly Required	Yes
Recommended Assembly People	2
Tools Recommended	Screwdriver (not included)



Image: Detailed dimensional diagram of the picnic table, showing width, length, and height measurements in both inches and centimeters.

WARRANTY AND SUPPORT

All products sold by vidaXL are covered by at least a 2-year legal guarantee. For warranty claims, missing parts, or assembly assistance, please contact vidaXL customer support through their official website or the retailer where the product was purchased.

For additional product information and support, you may visit the [vidaXL Store on Amazon](#).

PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official vidaXL video showcasing the quality and craftsmanship of their solid wood products, including the type of wood used in this picnic table.

