

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [TwoOases](#) /

> [TwoOases 2500W Pressurized Handheld Steam Cleaner \(Model TC-SC-001\) User Manual](#)

**TwoOases TC-SC-001**

# TwoOases 2500W Pressurized Handheld Steam Cleaner User Manual

Model: TC-SC-001

## 1. INTRODUCTION

---

Thank you for choosing the TwoOases 2500W Pressurized Handheld Steam Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and retain it for future reference.



Image: The TwoOases 2500W Pressurized Handheld Steam Cleaner, shown with its steam gun, various brush attachments, extension tube, and protective gloves.

## 2. IMPORTANT SAFETY INSTRUCTIONS

**WARNING: Failure to follow these safety instructions may result in electric shock, fire, or serious injury.**

- Always ensure the steam cleaner is unplugged before filling or emptying the water tank, or when attaching/detaching accessories.
- The steam cleaner operates at high temperatures (up to 221°F/105°C) and high pressure (3 Bar). Exercise extreme caution to prevent burns.
- Do not touch the metal nozzle or the emitted steam directly. Keep hands, face, and body away from the steam outlet during operation.
- Never direct steam at people, pets, or electrical appliances.
- Ensure the gasket is correctly positioned to prevent air and water leakage.
- The steam cleaner does not have a trigger on the spray gun handle. To stop steaming, turn off the main power switch on the machine body.
- Do not use the appliance if the power cord or plug is damaged.

- Keep the appliance out of reach of children.
- Use only clean tap water. Do not add corrosive chemicals, detergents, or other liquids to the water tank unless specifically instructed by the manufacturer for enhanced cleaning effects. Always refer to the manual for approved additives.

### 3. PRODUCT FEATURES

---

The TwoOases Steam Cleaner is designed for powerful and efficient cleaning across various surfaces. Key features include:

- **High Power & Fast Heating:** 2500W heating element generates 221°F/105°C high-temperature steam and 3 Bar pressure within 15 seconds.
- **Adjustable Steam Output:** 6-speed touch-adjustable button allows precise control over steam intensity.
- **Large Water Tank:** 1100ml capacity provides approximately 30 minutes of continuous steaming, reducing the need for frequent refills.
- **Chemical-Free Cleaning:** Utilizes only water steam for deep cleaning, eliminating the need for harsh chemicals.
- **Portable & Lightweight:** Weighing approximately 3.8 lbs (1.7 kg) with compact dimensions (7.9x5.7x5.2 inches), it is easy to carry and store.
- **Versatile Attachments:** Includes various brush heads and an extension pole for diverse cleaning tasks.

# HIGH PRESSURE & TEMPERATURE



**221°F/105°C**  
*High Temperature*

**2500w**  
*High Power*

**15Seconds**  
*Fast Heating*

Image: Visual representation of the steam cleaner's high temperature (221°F/105°C), high power (2500W), and rapid 15-second heating capability.



Image: The steam cleaner's control panel showing a 6-grade adjustable steam output and a real-time gear display for precise control.



Image: The steam cleaner highlighting its 1100ml large capacity water tank, designed for extended cleaning sessions without frequent refills.

#### 4. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Steam Cleaner Machine with Tank
- 1 x 2m Steam Pipe
- 1 x 1.5m Power Cord
- 1 x Extension Tube
- 2 x Steel Brush
- 2 x Plastic Brush
- 1 x Big Plastic Brush (Round Brush)
- 2 x Sealing Ring
- 1 x Glove
- 1 x User Manual (this document)

# Portable & Light



Lightweight

**3.8 LB**

Weight

**7.9 Inch**

Length

**5.7 Inch**

Width

**5.2 Inch**

Height

**2 m / 6.6ft**

Steam pipe



Steel Brush x 2



Plastic Brush x 2



Round Brush



Gloves



Instruction



Power Cord



Waterproof Washers



Extension Tube

Image: A visual guide to all components included in the TwoOases steam cleaner package.

## 5. SETUP AND OPERATION

Follow these steps for safe and effective use of your steam cleaner:

- 1. Fill Water Tank:** Pull out the top cover of the steam cleaner and fill the water tank with clean tap water. Do not overfill. Ensure the cover is securely closed.
- 2. Attach Accessories:** Select the appropriate brush head (steel, plastic, or large plastic) for your cleaning task and securely attach it to the steam gun. If needed, use the extension tube for hard-to-reach areas.
- 3. Connect Power:** Plug the power cord into a suitable electrical outlet.
- 4. Power On:** Press the power switch on the machine body to turn on the steam cleaner. The device will begin heating up.
- 5. Wait for Heating:** The steam cleaner will be ready for use in approximately 15 seconds, indicated by

the steam output.

6. **Adjust Steam Output:** Use the "+" or "-" buttons on the smart touch screen to adjust the steam intensity according to your cleaning needs. The screen will display the current gear.
7. **Begin Cleaning:** Hold the steam gun and direct the steam towards the dirty surface. Move the steam gun steadily over the area to be cleaned.
8. **Turn Off:** To stop steaming, turn off the main power switch on the machine body.



Image: A step-by-step visual guide demonstrating how to set up and operate the steam cleaner, from filling the water tank to adjusting steam output.

## 5.1. Recommended Uses

This versatile steam cleaner is suitable for a wide range of cleaning tasks:

- **Kitchen:** Stoves, walls, microwaves, refrigerators, countertops, sinks.
- **Bathroom:** Tiles, grout, toilets, showers, bathtubs.
- **Living Areas:** Hard floors, carpets (spot cleaning), upholstery, furniture.
- **Other:** Toys, windows, BBQ grills, car interiors.

**Before**  
**After**

**DEEPLY CLEANING OUT**  
**100% natural**  
**No chemical addition**  
*Green and environmental protection*

**221°F/105°C**  
*High Temperature*

Image: Before and after cleaning a stovetop, demonstrating the steam cleaner's effectiveness on stubborn grease and grime.

# CONVENIENT & EFFICIENT

## FOR WHOLE HOUSE CLEANING



Image: Examples of the steam cleaner's versatility, showing before and after results on car seats, a kitchen range hood, and a washing machine drum.

## 6. MAINTENANCE

- **Empty Water Tank:** After each use, unplug the appliance and allow it to cool. Pull out the stopper at the bottom of the tank to empty any remaining water. This prevents mineral buildup and prolongs the life of the unit.
- **Clean Accessories:** Rinse brush heads and other attachments with water after use. Allow them to air dry completely before storing.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or weak steam output.	Water tank is empty or low. Appliance not fully heated.	Refill the water tank. Wait for 15 seconds after powering on for full heating.

Problem	Possible Cause	Solution
Water leakage.	Gasket not properly seated. Water tank overfilled.	Check and reposition the sealing gasket. Do not overfill the water tank.
Appliance does not turn on.	Not plugged in. Power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet. Test the outlet with another device.
Metal nozzle becomes loose during use.	Vibration during scrubbing.	Periodically check and tighten the nozzle if it loosens.

## 8. SPECIFICATIONS

Feature	Detail
Brand	TwoOases
Model Name	Handheld Steam Cleaner (TC-SC-001)
Wattage	2500 watts
Voltage	120 Volts (AC)
Maximum Temperature	221°F (105°C)
Steam Pressure	3 Bar
Heating Time	Approximately 15 seconds
Tank Volume	1100 Milliliters (1.1 Liters)
Item Weight	3.74 pounds (1.7 Kilograms)
Product Dimensions	7.9"W x 5.7"D x 5.2"H
Power Source	Corded Electric
Steam Pipe Length	2 meters (6.6 feet)
Power Cord Length	1.5 meters

## 9. WARRANTY AND SUPPORT

The TwoOases Steam Cleaner comes with a **1-Year Warranty**. We are committed to providing satisfactory after-sales service.

If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact us. Our customer support team aims to respond within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official TwoOases website.

