



Manuals.plus /

› Squirrey /

› Squirrey Height Adjustable Mobile Desk G2 Instruction Manual

Squirrey AMD026

Squirrey Height Adjustable Mobile Desk G2 Instruction Manual

Model: AMD026

1. INTRODUCTION

Thank you for choosing the Squirrey Height Adjustable Mobile Desk G2. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions thoroughly before use and retain them for future reference.



Image 1: The Squirrey Height Adjustable Mobile Desk G2, featuring a dark wood tabletop and a black C-shaped base with adjustable height mechanism.

2. SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not overload the desk. Refer to the specifications for maximum weight capacity.
- Operate the height adjustment mechanism carefully to avoid pinching fingers or other body parts.
- Place the desk on a level and stable surface.
- Keep children and pets away from the desk during height adjustments.
- Avoid placing hot items directly on the tabletop without protection.
- This product meets Singapore's product safety and quality standards.

3. PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Tabletop (Dark Wood)
- Desk Frame (Vertical Column and Base)
- Pneumatic Gas Spring Mechanism (pre-installed in column)
- Casters (Wheels)
- Assembly Hardware (screws, wrench, etc.)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Squirrey Mobile Desk G2. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Attach Casters to Base:** Securely attach the casters to the bottom of the desk base using the provided hardware. Ensure they are tightened to prevent wobbling.
3. **Assemble Desk Frame:** Connect the vertical column to the C-shaped base. Ensure the pneumatic gas spring mechanism is correctly aligned. Fasten all screws firmly.
4. **Attach Tabletop:** Carefully place the tabletop onto the assembled desk frame. Align the pre-drilled holes on the tabletop with the mounting points on the frame. Secure the tabletop using the provided screws. Do not overtighten.
5. **Final Check:** Verify that all screws are tightened and the desk is stable. Test the height adjustment mechanism.

5. OPERATION

5.1 Height Adjustment

The Squirrey Mobile Desk G2 features a pneumatic gas spring mechanism for smooth and effortless height adjustments.

- **To Raise the Desk:** Gently lift the lever located under the tabletop while applying slight upward pressure to the tabletop. The desk will rise smoothly. Release the lever at your desired height.
- **To Lower the Desk:** Gently lift the lever located under the tabletop while applying slight downward pressure to the tabletop. The desk will lower smoothly. Release the lever at your desired height.
- Ensure no objects are obstructing the desk's movement during adjustment.

5.2 Mobility

The desk is equipped with smooth-rolling casters for easy relocation.

- To move the desk, simply push or pull it to your desired location.
- Ensure the path is clear of obstacles to prevent damage or accidents.
- For stability during use, ensure the casters are locked if available, or position the desk against a wall or furniture to prevent unwanted movement.

6. MAINTENANCE

- **Cleaning:** Wipe the tabletop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Gas Spring:** The pneumatic gas spring is maintenance-free. Do not attempt to disassemble it.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not adjust height smoothly.	Obstruction in mechanism; lever not fully engaged; desk overloaded.	Check for obstructions. Ensure the lever is fully pressed. Reduce weight on the desk.
Desk is wobbly.	Loose screws; uneven surface.	Check and tighten all assembly screws. Move the desk to a level surface.
Casters do not roll freely.	Debris in casters; casters not properly installed.	Clean any debris from the casters. Ensure casters are securely attached.

8. SPECIFICATIONS

Model Number	AMD026
Brand	Squirrey
Tabletop Dimensions (L x W)	710mm x 400mm
Height Adjustment Range	640mm - 990mm
Product Dimensions (Overall)	40D x 71W x 64H cm (at lowest height)
Weight	13.85 kg
Material	Wood (Tabletop), Metal (Frame)
Special Features	Height Adjustable, Mobile (with casters), C-shaped design

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact your retailer or the Squirrey customer service department. Keep your purchase receipt as proof of purchase.

Contact Information: Refer to the contact details provided with your purchase or visit the official Squirrey website.

