

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Puldoum](#) /

› Puldoum 4-in-1 Electric Milk Frother and Steamer (PUL 002-WT) Instruction Manual

Puldoum PUL 002-WT

Puldoum 4-in-1 Electric Milk Frother and Steamer (PUL 002-WT) Instruction Manual

Model: PUL 002-WT | Brand: Puldoum

1. INTRODUCTION

Thank you for choosing the Puldoum 4-in-1 Electric Milk Frother and Steamer. This appliance is designed to create various milk preparations, including hot airy foam, hot thick foam, cold foam, and heated milk, for your favorite beverages like lattes, cappuccinos, macchiatos, and hot chocolate. Please read this manual carefully before first use to ensure safe and optimal operation.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not immerse the base unit or power cord in water or other liquids.
- This appliance is for household use only.
- Ensure the voltage rating matches your local power supply.
- Do not operate the appliance with a damaged cord or plug.
- Keep out of reach of children.
- Always place the appliance on a stable, flat, heat-resistant surface.
- Do not touch hot surfaces. Use handles or knobs.
- Unplug from outlet when not in use and before cleaning.
- Do not use attachments not recommended by the manufacturer.
- Do not rinse the exterior of the frother directly under the tap. Wipe with a damp cloth.
- Do not place in a dishwasher.

3. PRODUCT OVERVIEW

3.1 Components

- Frother Unit with Non-Stick Interior
- Transparent Lid
- Power Base
- Frothing Whisks (2 included)
- Power Cable (integrated with base)

3.2 Features

- **4-in-1 Functionality:** Hot airy foam, hot thick foam, cold foam, and hot milk.
- **Automatic Operation:** One-button control for ease of use.
- **Large Capacity:** Heats up to 350ml (11.8 oz) of milk, froths up to 160ml (5.4 oz) for hot/cold frothing.
- **Temperature Control:** Built-in Strix temperature control system with automatic shut-off at 65 ± 2 °C.
- **Non-Stick Coating:** Food-grade stainless steel interior with non-stick coating for easy cleaning.
- **Quiet Operation:** Designed for minimal noise during use.



Figure 1: Puldoum 4-in-1 Electric Milk Frother and Steamer (PUL 002-WT).



Figure 2: Overview of the 4 operating modes: Warm light foam, Warm thick foam, Hot milk, and Cold foam.

4. SETUP

1. Unpack the frother and all its components.
2. Wash the interior of the frother jug and the whisks with warm soapy water. Rinse thoroughly and dry. Do not immerse the exterior of the frother or the power base in water.
3. Place the power base on a dry, flat, and stable surface.
4. Ensure the correct whisk is inserted into the bottom of the frother jug for your desired function (see Operating Instructions).
5. Connect the power cable to a suitable electrical outlet.

5. OPERATING INSTRUCTIONS

The Puldour milk frother offers four distinct functions, easily selected with a single button. Always ensure the frother is placed on its power base before operation.

5.1 Milk Recommendations

For optimal frothing results, we recommend using whole milk, soy milk, almond milk, or milk with a fat content of more than 3%. Cold milk (refrigerated temperature) is ideal for frothing.

5.2 Fill Levels

Observe the MIN and MAX fill lines inside the frother jug. Do not exceed the MAX frothing line (160ml / 5.4 oz) for foam, or the MAX heating line (350ml / 11.8 oz) for hot milk without frothing. Overfilling can cause overflow.



Figure 3: Internal fill lines for heating (350ml) and frothing (160ml).

5.3 Function Selection

The frother typically uses two types of whisks: one for frothing and one for heating/stirring. Ensure the correct whisk is securely placed on the shaft at the bottom of the jug.

Table 1: Operating Modes and Whisk Usage

Function	Whisk Type	Max Fill	Button Press	Result
Hot Airy Foam	Frothing Whisk	160ml	Press once	Light, fluffy hot foam
Hot Thick Foam	Frothing Whisk	160ml	Press twice	Dense, creamy hot foam
Cold Foam	Frothing Whisk	160ml	Press and hold for 2 seconds	Cold, airy foam
Hot Milk / Hot Chocolate	Stirring Whisk (no spring)	350ml	Press three times	Heated milk or hot chocolate (no foam)

General Operation Steps:

1. Pour the desired amount of milk into the frother jug, observing the MIN/MAX lines.
2. Place the lid securely on the frother.
3. Select your desired function by pressing the power button according to Table 1. The indicator light will illuminate.
4. The frother will automatically stop when the process is complete (approximately 2 minutes).
5. Carefully remove the lid and pour out the frothed or heated milk.



Figure 4: Example of rich and creamy milk foam produced by the frother.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygiene of your Puldoom milk frother. Always unplug the appliance before cleaning.

1. After each use, immediately rinse the interior of the frother jug and the whisk with warm water.
2. Use a soft brush and mild soapy water to clean the non-stick interior.
3. Rinse thoroughly to remove all soap residue.
4. **Important:** Do not rinse the exterior of the frother jug or the power base directly under running water. Wipe the exterior with a soft, damp cloth.
5. Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the non-stick coating.
6. The frother jug and whisks are **not** dishwasher safe. Hand wash only.
7. Ensure all parts are completely dry before storing or next use.



Figure 5: The non-stick interior allows for easy cleaning with water and a soft brush.

7. TROUBLESHOOTING

Table 2: Common Issues and Solutions

Problem	Possible Cause	Solution
Frother does not start.	Not plugged in; power outage; frother not correctly placed on base.	Check power connection; ensure frother is seated correctly on the base.
Milk does not froth well.	Incorrect milk type (low fat); milk too warm; whisk not properly installed; overfilled.	Use cold whole milk or milk with >3% fat; ensure frothing whisk is used and correctly placed; do not exceed MAX frothing line.
Milk overflows.	Overfilled frother jug.	Do not exceed the MAX fill line for frothing (160ml) or heating (350ml).
Milk is not hot enough.	Incorrect setting; appliance malfunction.	Ensure the correct hot milk/foam setting is selected. If problem persists, contact customer support.

8. SPECIFICATIONS

Specification	Detail
Brand	Puldoum
Model Number	PUL 002-WT
Color	White
Capacity (Heating)	350 ml (11.8 oz)
Capacity (Frothing)	160 ml (5.4 oz)
Power	350 Watts
Material	Plastic exterior, Food-grade Stainless Steel interior with Non-stick coating
Features	Automatic shut-off, Temperature display, 4-in-1 functions
Item Weight	334.52 grams (11.8 ounces)
Care Instructions	Hand wash only

9. WARRANTY AND SUPPORT

Puldoum offers a **6-month return or exchange policy** on all Puldoum products. If you encounter any questions or issues with your Puldoum Electric Milk Frother, please do not hesitate to contact our customer service team. We are committed to providing support and assistance. For customer service inquiries, please refer to the contact information provided with your purchase or

visit the official Puldoum website.