Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- GLOBE /
- > Globe Electric LED Integrated Rechargeable Multicolor Portable Touch Lamp User Manual

GLOBE 13607

Globe Electric LED Integrated Rechargeable Multicolor Portable Touch Lamp

Model: 13607

Introduction

This manual provides detailed instructions for the safe and efficient use of your Globe Electric LED Integrated Rechargeable Multicolor Portable Touch Lamp. Please read this manual thoroughly before operating the device and retain it for future reference.



Image: The Globe Electric portable touch lamp, showing its cylindrical design and warm white illumination.

Safety Information

- Do not expose the lamp to water or excessive moisture. This product is not waterproof.
- Do not attempt to disassemble or modify the lamp. This may void the warranty and pose a safety risk.
- Use only the provided USB charging cable or a certified equivalent.
- Keep the lamp away from direct heat sources and flammable materials.
- This lamp contains a rechargeable battery. Do not dispose of the product in fire.
- Ensure the lamp is placed on a stable surface when in use.

Package Contents

Verify that all items are present in the package:

• 1 x Globe Electric LED Integrated Rechargeable Multicolor Portable Touch Lamp (Model 13607)

- 1 x USB Charging Cable (3.2 feet)
- 1 x Instruction Sheet (this manual)

Setup

- 1. **Initial Charge:** Before first use, fully charge the lamp. Connect the included USB charging cable to the lamp's charging port and to a standard USB power adapter (not included) or a computer USB port. The charging indicator (if present) will show charging status. A full charge typically takes several hours.
- 2. **Placement:** Place the lamp on a flat, stable surface. For hanging, extend the retractable hook located at the bottom of the lamp and secure it to a suitable fixture.



Image: A visual guide illustrating the lamp's touch-sensitive top for color changes, the retractable hook on the bottom, and a spectrum of available light colors.

Operating Instructions

- 1. **Power On/Off:** Locate the manual on/off switch, typically on the base of the lamp. Flip the switch to the "ON" position to activate the lamp. Flip to "OFF" to power down.
- 2. **Changing Colors:** With the lamp powered on, gently tap the top surface of the lamp to cycle through the available light colors. The lamp offers 6 distinct color settings.

- 3. **Adjusting Brightness (Dimmable):** The lamp features 3 preset dimmable light options. Continue tapping the top surface after cycling through colors to adjust the brightness levels of the white light settings.
- 4. **Retractable Hook:** To use the portable hanging feature, pull out the metal hook from the bottom of the lamp. Once extended, the lamp can be hung from various points. Push the hook back into the base when not in use.

Maintenance

- Cleaning: Disconnect the lamp from any power source before cleaning. Use a soft, dry cloth to wipe the exterior of the lamp. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the lamp frequently. Recharge the lamp when the light output diminishes. If storing for an extended period, charge the lamp every 3-6 months.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted. Manual switch is off.	Charge the lamp using the USB cable. Ensure the manual on/off switch is in the "ON" position.
Lamp does not charge.	USB cable or power adapter is faulty. Charging port is obstructed.	Try a different USB cable or power adapter. Check the charging port for debris.
Colors do not change.	Incorrect tapping method.	Ensure you are gently tapping the top surface of the lamp.
Light is dim.	Battery is low. Dimmable setting is active.	Recharge the lamp. Tap the top surface to cycle through brightness levels.

Specifications

Feature	Detail
Model Number	13607
Brand	GLOBE
Product Dimensions	3.74"D x 3.74"W x 4.72"H (9.5 cm D x 9.5 cm W x 12 cm H)
Item Weight	0.33 Pounds (approx. 5.3 ounces)
Light Source Type	LED Integrated
Power Source	Battery Powered (Rechargeable via USB)
Control Method	Touch
Color Options	6 Multicolor settings, 3 Dimmable white light options
Battery Life (Full Charge)	9-12 hours
Included Components	USB Charging Cable, Instruction Sheet

Feature	Detail
Material	Plastic (Base Material: Plastic, Shade Material: Plastic)
Finish Type	Satin White
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant
Voltage	120 Volts (for charging adapter, lamp operates on battery)
Color Temperature	3000 Kelvin (for white light)




Image: Product dimensions diagram, indicating height and width measurements.

Warranty and Support

This product is sold without an explicit warranty as per manufacturer information. For any questions,

technical assistance, or support regarding your Globe Electric LED Integrated Rechargeable Multicolor Portable Touch Lamp, please contact Globe Electric customer service directly.

You may find contact information on the manufacturer's official website or through the retailer where the product was purchased.

Related Documents - 13607



Globe SMART FLOOR LAMP User Manual and Setup Guide

Comprehensive guide for the Globe SMART FLOOR LAMP, including safety instructions, features, specifications, assembly, and connecting to the Globe Suite app and voice assistants like Google Home and Amazon Alexa.



Globe Streamwatch Xtreme Prepaid User Manual and Setup Guide

Comprehensive user manual for the Globe Streamwatch Xtreme Prepaid device. Learn how to connect to the internet, stream content on your TV, access apps via Google Play, and find troubleshooting solutions. Includes setup guides and device information.



Globe Smart Switch User Guide

User guide for the Globe Smart Switch, detailing installation, setup via the Globe Suite™ app, features like remote control, scheduling, and voice assistant integration. Learn how to enhance your home with smart lighting control.



Globe Running Boards Assembly Guide for Haul LT Bicycle

Step-by-step instructions and safety information for assembling Globe Running Boards onto your Globe Haul LT bicycle, including parts lists, torque specifications, and weight limits.




Globe Motion Activated Security Light Installation and Operation Guide

Comprehensive guide for installing, operating, and troubleshooting the Globe Motion Activated Security Light. Features include specifications, safety precautions, step-by-step installation instructions, and maintenance tips.



Globe SG13A-22 Arby's Slicer Instruction Manual

Comprehensive instruction manual for the Globe SG13A-22 Arby's slicer, covering safety, installation, operation, cleaning, sanitizing, knife sharpening, maintenance, troubleshooting, and warranty information.




[pdf] Accessories

Spence™ Steam and Fluid Control Instruction Manuals DELIVERY PIPE Line are now being filled with fluid flowing through Main Valve As delivery pressure yellow rises It overcomes the force manuals spence steam control instruction en us 10195548 spencevalve documents |||

SpenceTM Steam and Fluid Control Instruction Manuals TABLE OF CONTENTS SECTION I INTRODUCTION TO ... 0 WAL04-13604-00 WAL04-13608-00 WAL04-13583-00 WAL04-13587-00 WAL04-13591-00 WAL04-13603-00 WAL04-13607-00 WAL04-13611-00 WAL04-13631-00 WAL04-13634-00 WAL04-13637-00 WAL04-13635-00 WAL04-1365-00 WAL04-1365-00 WAL04-1365-00 WAL04-1365-00 WAL04-1365-00 WAL04-1365-00 WAL04-1365-00

lang:en score:27 filesize: 37.03 M page_count: 270 document date: 2024-06-26



[pdf] User Manual

13607 IS lores TéléchargerVeilleuse à DEL tactile Globe Canadian Tire13607 1523075 is e7f88d3b cf54 4a65 902d b5ecc051d570media canadiantire ca manual product b5ecc051d570 |||

..

lang:en score:19 filesize: 2.27 M page_count: 2 document date: 2024-12-05



[pdf] User Manual Installation Guide Instructions Troubleshooting Guide

Manuals Spence Type J Control Valves VCIMD 14934 EN Emerson manuals spence type j control valves en 6308624 emerson documents automation |||

Instruction Manual VCIMD-14934 November 2021 Spence Type J Control Valve Type J WARNING Failure t ... 0 WAL04-13604-00 WAL04-13608-00 WAL04-13583-00 WAL04-13587-00 WAL04-13591-00 WAL04-13603-00 WAL04-13607-00 WAL04-13631-00 WAL04-13634-00 WAL04-13637-00 WAL04-13632-00 WAL04-13635-00...


lang:en score:19 filesize: 1.38 M page_count: 12 document date: 2021-05-23



Great RV Escapes: Quick Reference Guide for United States and Canada

A comprehensive directory of RV parks and campgrounds across the United States and Canada, featuring contact information, websites, and locations for Great RV Escapes.

lang:de score:17 filesize: 2.09 M page_count: 24 document date: 2017-11-08



Billboard International Buyer's Guide 1992

The 1992 Billboard International Buyer's Guide is a comprehensive directory for the music and home video industries, listing record labels, music publishers, home video companies, and industry services and suppliers worldwide. It includes contact information, key personnel, and label details for businesses in the music and entertainment sectors.

lang:en score:17 filesize: 29.26 M page count: 317 document date: 2019-07-11



Billboard 1982-83 International Buyer's Guide: Music Industry Directory

The Billboard 1982-83 International Buyer's Guide is a definitive industry resource, featuring comprehensive listings of record companies, music publishers, wholesalers, services, and detailed statistics from over 70 countries. Essential for music business professionals navigating the early 1980s market.

lang:en score:17 filesize: 70.05 M page_count: 582 document date: 2019-10-07





[pdf] Guide

View Your GuideMyBaseGuide Comprehensive Guide to U S Military Bases News and ServicesFt Drum Guidecdn sanity io files 1sxbvyx9 production 8ef0c8f33093d432171cd7aa8bca6ddeeb93a3f7 ||| Northline Utilities, LLC operates on a regional basis, serving 15 School Lane Au Sable Forks, NY 1 ... OUSING WELCOME EDUCATION Hospital 1H River Hospital 315-482-2511 4 Fuller St. Alexandria Bay, NY 13607 www.riverhospital.org Emergency room open 24/7 Directions from Fort Drum s Gas Alley Gate 1. L...

lang:en score:16 filesize: 50.94 M page_count: 75 document date: 2025-04-08



[pdf] Specifications Warranty

GILL SEALED BATTERIES Aircraft Spruce These batteries are also backed by a 2 year warranty even for TURBINE AIRCRAFT wiring guides strain relief sized 16 gauge insulated 2025 EL aircraftspruce 2025Individual |||

CM WP GILL SEALED BATTERIES The Gill LT Sealed Valve Regulated Lead-Acid VRLA Batteries provide ... n White Long Black 14V White Long Black 28V White Short Black 14V White Short Black 28V Part No 11-13607 11-13610 11-13608 11-13612 Price ------- WHELEN 71440 LED POST LIGHT Product Aviation - ... lang:en score:13 filesize: 5.9 M page count: 93 document date: 2024-06-20



[pdf] Guide Accessories Catalog

SATA GmbH Co KG EN Product products English Catalogue Spray guns Cup Systems Breathing Protection Filter Technology Accessories Merchandise Items german engineering made in germany tool werkzeug spray gun lackieren paint sata catalogue 2023 02 06 — As most end users use quick couplings are Hose guide on Humidifier kit consisting of humidifier module lid seal Catalog 221205 241786 uid 63e126bf522ef assets cms |||

CATALOGUE 2023 SPRAY GUNS CUP SYSTEMS BREATHING PROTECTION FILTER TECHNOLOGY ADDITIONAL PRODUCT ... en, 9 mm, 15 m Components for the quick coupling system 13508 13516 13524 13557 13565 13581 13599 **13607** 13615 13623 13631 13649 53942 6981 7237 Nipple 3/8 male thread for SATA quick coupling Nip...

lang:en score:11 filesize: 27.7 M page_count: 164 document date: 2023-02-06



[pdf] User Manual Documentation Decleration of Conformity

Hypertext marks in LaTeX links for Sebastian Rahtz deceased Heiko Oberdiek inactive The Project github latex3 hyperref issues di S \cdot Citato da 15 — documentation package consists of several files Manual USER MANUAL also available as HTML ChangeLog This file records the version osl ugr es CTAN macros latex contrib doc |||

Hypertext marks in LATEX Sebastian Rahtz deceased Heiko Oberdiek inactive The LATEX Project http ... vmode 311 13604 Hy escapeform PDFForm List 13605 HyField AdvanceAnnotCount 13606 pdfm mark **13607** ann list HyField TheAnnotCount space 13608 dvipdfm setdim 13609 PDFForm List 13610 ...

lang:en score:10 filesize: 6.29 M page count: 512 document date: 2023-11-26