

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Incanto](#) /

> [Incanto Aura Bean-to-Cup Coffee Machine User Manual](#)

Incanto Aura

Incanto Aura Bean-to-Cup Coffee Machine User Manual

Model: Aura | Brand: Incanto

1. INTRODUCTION

Welcome to the Incanto Aura Bean-to-Cup Coffee Machine user manual. This guide provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new coffee machine. Please read all instructions carefully before first use and keep this manual for future reference.

2. SAFETY INSTRUCTIONS

- Always ensure the machine is placed on a stable, level surface.
- Do not immerse the machine, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Unplug the machine from the power outlet before cleaning or when not in use for extended periods.
- Do not operate the machine with a damaged cord or plug. Contact customer support for repairs.
- Only use whole coffee beans in the bean hopper. Do not use ground coffee, instant coffee, or other substances.
- Use only cold, fresh water in the water tank.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Incanto Aura coffee machine.



Figure 3.1: Front view of the Incapto Aura coffee machine.



Figure 3.2: Dimensions of the Incapto Aura coffee machine (40.5 cm depth x 18.5 cm width x 31.5 cm height).

4. SETUP

4.1 First Use

1. Unpack the machine and remove all packaging materials.
2. Place the machine on a stable, flat surface.
3. Clean the water tank, bean hopper, and drip tray with warm water and mild detergent. Rinse thoroughly.
4. Fill the water tank with fresh, cold water.
5. Fill the bean hopper with whole coffee beans.
6. Plug the machine into a grounded power outlet.
7. The machine will perform an initial rinse cycle. Follow on-screen prompts or indicator lights.

4.2 Filling the Water Tank

The water tank is located on the side of the machine and is easily removable for filling.



Figure 4.1: A hand pouring water into the transparent water tank of the Incapto Aura coffee machine.

4.3 Filling the Bean Hopper

Open the lid on top of the machine to access the bean hopper. Ensure only whole coffee beans are added.



Figure 4.2: A hand pouring whole coffee beans from a bag into the bean hopper of the Incapto Aura coffee machine.

5. OPERATING INSTRUCTIONS

The Incapto Aura features a touch-sensitive control panel for easy operation.



Figure 5.1: A finger interacting with the touch control panel of the Incapto Aura coffee machine.



Figure 5.2: Close-up of the control panel showing icons for various coffee selections: Short Coffee, Long Coffee, Double Espresso, Americano, Hot Water, and Favorite Coffee.

5.1 Making a Single Coffee

1. Place a cup under the coffee dispenser.
2. Select your desired coffee type (e.g., Espresso, Long Coffee, Americano) from the touch panel.
3. The machine will automatically grind the beans and brew your coffee.

5.2 Making Two Coffees Simultaneously

The Incapto Aura can brew two cups at once using the double espresso function.



Figure 5.3: The Incapto Aura coffee machine dispensing two espressos into two glass cups simultaneously.

1. Place two cups under the coffee dispenser.
2. Select the Double Espresso icon on the touch panel.
3. The machine will brew two espressos simultaneously.

5.3 Hot Water Dispensing

For tea or other hot beverages, the machine can dispense hot water.

1. Place a cup under the coffee dispenser.
2. Select the Hot Water icon on the touch panel.
3. The machine will dispense hot water.

5.4 Customization and Favorite Coffee

You can customize the grind settings and save your preferred coffee settings using the 'Favorite Coffee'

option on the touch panel.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Incapto Aura.

6.1 Automatic Cleaning Program

The machine features an automatic cleaning program. Follow the LED alerts for maintenance actions.

6.2 Removable Components

The brewing unit, drip tray, and coffee grounds container are easily removable for cleaning.

- **Drip Tray and Coffee Grounds Container:** Empty and rinse daily or when indicated by the machine.
- **Brewing Unit:** Remove and rinse under running water weekly. Allow to air dry before reinserting.

6.3 Descaling

The machine will indicate when descaling is required. Use the provided descaling powder sachets or a suitable descaling solution according to the instructions on the descaler packaging and the machine's prompts.

6.4 Included Accessories

Your Incapto Aura comes with a brush for cleaning the grinder and brewing group, a cloth, and 3 sachets of descaling powder for proper maintenance.

7. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
No coffee is dispensed.	Water tank empty; coffee beans empty; brewing unit blocked.	Refill water tank; refill bean hopper; clean brewing unit.
Coffee is too weak/strong.	Grind setting incorrect; coffee quantity setting incorrect.	Adjust grind setting; adjust coffee strength setting.
Machine leaks.	Drip tray full; water tank not properly inserted.	Empty drip tray; ensure water tank is correctly seated.
Descaling alert.	Machine requires descaling.	Perform descaling procedure as per manual.

If the problem persists after attempting these solutions, please contact Incapto customer support.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	Incapto
Model Number	Aura
Color	Black
Dimensions (L x W x H)	40.5 x 18.5 x 31.5 cm
Weight	9 Kilograms
Capacity (Beans)	150 Grams
Pressure	19 Bars
Power	1690 Watts
Voltage	240 Volts
Material	Plastic
Special Features	Water filter, Automatic cleaning, Integrated coffee grinder, Programmable, Removable tank

9. OFFICIAL PRODUCT VIDEO

Video 9.1: An overview of the Incapto Aura coffee machine, demonstrating its compact design, ease of use, and various coffee preparation functions, including filling beans and water, and brewing different coffee types.

10. WARRANTY AND SUPPORT

Your Incapto Aura coffee machine comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Incapto website.

For technical support, spare parts, or any inquiries, please contact Incapto customer service through their official channels. Information regarding spare parts availability is currently unavailable.