

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Intex](#) /

> [Intex 64131ED Dura-Beam Plus Deluxe Pillow: Fiber-Tech – Twin Size – Built-in Electric Pump – 16.5in Bed Height – 300lb Weight Capacity User Manual](#)

Intex 64131ED

Intex Dura-Beam Plus Deluxe Pillow Twin Air Mattress

Model: 64131ED | Brand: Intex

1. OVERVIEW

The Intex Dura-Beam Plus Deluxe Pillow Air Mattress offers enhanced comfort, stability, and support through its Fiber-Tech Technology. With a raised height of 16.5 inches, it provides easy accessibility, mimicking the feel of traditional mattresses. The soft, velvety sleeping surface and built-in pillow contribute to a comfortable night's sleep. A powerful internal electric pump ensures convenient inflation and deflation, and a carry bag is included for easy storage and transport.



Figure 1: Intex Dura-Beam Plus Deluxe Pillow Twin Air Mattress.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before using this product. Failure to follow these instructions may result in serious injury or property damage.

- Do not overinflate.
- Keep away from sharp objects and heat sources.
- This product is not a life-saving device. Do not use in water.
- Ensure the area around the mattress is clear of obstructions.
- Supervise children when using the air mattress.
- Do not stand or jump on the mattress.
- For detailed safety information, refer to the official [Safety Information PDF](#).


3. SETUP INSTRUCTIONS

3.1. Initial Inflation

1. Unroll the air mattress on a clean, flat surface, ensuring no sharp objects are underneath.
2. Locate the built-in electric pump.
3. Plug the power cord into a standard 110-120V AC electrical outlet.
4. Turn the pump dial to the 'Inflate' position. The mattress will begin to inflate.
5. Inflate until the mattress is firm to the touch. Do not overinflate. Inflation time for a Twin size is approximately 2.25 minutes.
6. Once inflated, turn the pump dial to the 'Off' position and unplug the power cord. Securely close the pump cover.

Dura-Beam® Plus **Deluxe Pillow Rest**

RAISED AIR MATTRESS



Mattress Size

Twin: 39" x 75" x 16 ½"

Queen: 60" x 80" x 16 ½"



Inflating Time*

Twin: 2 ¼ mins.

Queen: 3 ¼ mins.



Max Weight Capacity

Twin: 300 lbs., 136 kg.

Queen: 600 lbs., 272 kg.

*Inflating time varies by mattress size and desired firmness.

Figure 2: Mattress specifications including inflation time.

3.2. First Use & Material Stretch

During the first few uses, the material of the air mattress will naturally stretch. This may cause the mattress to feel softer or appear to lose air. This is normal and not an indication of a leak. Simply re-inflate the mattress to your desired firmness. The material will fully settle within 2-3 nights of use.

FIBER-TECH[®]

Construction



Made of thousands of high-strength polyester fibers for enhanced support and comfort.

Figure 3: Fiber-Tech Construction for enhanced support.




Figure 4: Dura-Beam Advantage: Maintains shape, unlike traditional air mattresses.

4. OPERATION

4.1. Inflation and Deflation

The built-in electric pump allows for quick and easy inflation and deflation. To inflate, turn the dial to the 'Inflate' position. To deflate, turn the dial to the 'Deflate' position. The pump will actively remove air from the mattress, making it easier to fold and store.

4.2. Adjusting Firmness

You can adjust the firmness of the mattress by adding or removing small amounts of air. For a firmer feel, inflate slightly more. For a softer feel, deflate slightly. Ensure the pump is in the 'Off' position when not actively inflating or deflating.



Figure 5: Top and Bottom Edge Support for a solid foundation.

5. CARE AND MAINTENANCE

5.1. Cleaning

To clean the air mattress, wipe the surface with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Ensure the mattress is completely dry before storing.

5.2. Storage

After deflating, fold the mattress neatly. Store it in the included carry bag in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the stored mattress.



Figure 6: Convenient carry bag for storage and transport.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Mattress loses air / feels soft	Material stretching (normal for first uses) or minor temperature changes.	Re-inflate to desired firmness. This is common during the first 2-3 nights.
Pump not working	Not plugged in, power outage, or pump dial not in correct position.	Ensure power cord is securely plugged in. Check household power. Turn dial to 'Inflate' or 'Deflate'.
Difficulty folding for storage	Not fully deflated.	Ensure pump is set to 'Deflate' and runs until all air is removed. Press out any remaining air while folding.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	Air Mattress with Internal Pump
Model Number	64131ED
Size	Twin (Approx. 39" L x 75" W)
Height	16.5 Inches
Weight Capacity	300 Pounds (136 kg)
Inflation Time	Approx. 2.25 minutes (Twin)
Special Features	Puncture Resistant, Built-In Pump, Built-In Pillow
Material	PVC (Fiber-Tech Construction)
Included Components	Carry Bag, Repair Patch
Item Weight	8.91 pounds
UPC	078257328062

8. WARRANTY AND SUPPORT

8.1. Warranty Information

This Intex air mattress comes with a 1-year limited warranty from the date of purchase. The warranty covers manufacturing defects in materials and workmanship. Please retain your proof of purchase for warranty claims.

8.2. Customer Support

For further assistance, product inquiries, or warranty claims, please visit the official Intex website or contact their customer service department. Contact information can typically be found on the product packaging or the Intex brand store page on Amazon.

Visit the [Intex Store on Amazon](#) for more information.