HOMLAND RW310

HOMLAND RW310 3-Wheel Rollator Instruction Manual

Model: RW310

1. Introduction

Thank you for choosing the HOMLAND RW310 3-Wheel Rollator. This manual provides essential information for the safe assembly, operation, and maintenance of your rollator. Please read it thoroughly before use and retain it for future reference.



Image 1.1: The HOMLAND RW310 3-Wheel Rollator, showcasing its compact design and purple frame.

2. Safety Information

Always prioritize safety when using the rollator. Failure to follow these instructions may result in injury.

- **Maximum Weight Capacity:** Do not exceed 260 lbs (118 kg).
- Ensure all parts are securely locked and adjusted before each use.

- Always engage the brakes when standing still or sitting.
- Do not use the rollator on stairs or escalators.
- Be cautious on uneven surfaces, ramps, and wet floors.
- Regularly inspect the brakes, wheels, and frame for wear or damage.



Image 2.1: Illustration of the dual-brake system, robust aluminum frame, and 8-inch non-slip wheels, highlighting control and safety features.



Image 2.2: Detailed view of the reliable dual brake system, showing how to engage the brake (pull lever) and lock the wheels (push lever down).

3. Assembly and Setup

The HOMLAND RW310 rollator comes largely pre-assembled. Follow these steps to prepare it for use.

3.1 Unfolding the Rollator

1. Place the folded rollator on a flat, stable surface.
2. Gently pull the handles outwards until the frame fully expands and locks into place.
3. Ensure the storage bag is properly seated and secured.

3.2 Adjusting Handle Height

The handle height is adjustable to suit users between approximately 4'8" and 6'1" (142 cm to 185 cm).

1. Locate the height adjustment pins on the handle tubes.
2. Press the pin and slide the handle up or down to the desired height.
3. Ensure the pin snaps securely into one of the adjustment holes.
4. Repeat for the other handle, ensuring both are at the same height.

The handle height can be adjusted from 33 inches (84 cm) to 37 inches (94 cm).



Image 3.1: Visual guide for adjusting the handle height, illustrating the different height settings and the recommended user height range.

4. Operating Instructions

4.1 Walking with the Rollator

Push the rollator forward slightly, then step forward with one foot, followed by the other. Maintain an upright posture and keep your weight centered over the rollator for stability.

4.2 Using the Brakes

- **To Slow Down or Stop:** Squeeze the brake levers gently towards the handles.
- **To Lock the Wheels:** Push the brake levers down until they click into the locked position. This prevents the rollator from moving.
- **To Unlock the Wheels:** Pull the brake levers up until they release from the locked position.

4.3 All-Terrain Mobility

The premium 8-inch wheels are designed for smooth movement across various indoor and outdoor surfaces, including ceramic

tile, wood floors, carpeted areas, and asphalt roads. The wheels feature anti-vibration and silent movement for enhanced comfort.



Image 4.1: Detailed view of the 8-inch all-terrain wheel, highlighting its design for smooth and quiet operation on diverse surfaces.



Image 4.2: Examples of the rollator being used in different settings, demonstrating its versatility for outdoor and indoor mobility, including navigating narrow spaces.

4.4 Using Accessories

The rollator includes a cup holder, a cane holder, and a spacious storage bag for personal items.

- **Cup Holder:** Attach the cup holder to the frame as shown in the diagram.
- **Cane Holder:** Secure your cane in the designated holder.
- **Storage Bag:** Use the bag to carry personal belongings. Do not overload the bag.



Image 4.3: Overview of the rollator's advanced features, including the cane holder, cup holder, and integrated storage bag.

5. Folding and Storage

The HOMLAND RW310 features a 2-sided folding design for easy storage and transport.

1. Ensure the brakes are unlocked.
2. Locate the folding mechanism (usually a strap or lever) on the frame.
3. Pull the mechanism to initiate folding. The rollator will fold inward.
4. Once folded, it can stand upright for compact storage or be easily lifted into a car trunk.

The rollator weighs approximately 10.3 lbs (4.67 kg), making it easy to lift.



Image 5.1: Demonstration of the rollator's foldable and lightweight design, illustrating how it can be easily folded and stored in a vehicle.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your rollator.

- **Cleaning:** Wipe the frame with a damp cloth and mild detergent. Do not use abrasive cleaners.
- **Wheel Inspection:** Check wheels regularly for debris, wear, and proper rotation.
- **Brake Check:** Test the brakes before each use to ensure they engage and lock correctly.
- **Fastener Check:** Periodically check all screws and bolts to ensure they are tight.
- **Storage:** Store the rollator in a dry place away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Rollator does not roll smoothly.	Debris in wheels, loose wheel, worn wheel.	Clean wheels, check wheel attachment, replace worn wheels if necessary.
Brakes are not engaging or locking.	Brake cable too loose, worn brake pads.	Adjust brake cable tension (consult a professional if unsure), inspect and replace brake pads.
Rollator feels unstable.	Handles not adjusted to equal height, loose frame components.	Ensure handles are at the same height, check all frame fasteners for tightness.
Difficulty folding the rollator.	Mechanism obstructed, frame not fully expanded.	Clear any obstructions, ensure the rollator is fully unfolded before attempting to fold.

8. Specifications

Feature	Specification
Model Number	RW310
Product Dimensions (L x W x H)	73.99 x 65.02 x 96.52 cm (29.13 x 25.6 x 37.99 inches)
Item Weight	4.67 kg (10.3 lbs)
Maximum Weight Capacity	118 kg (260 lbs)
Material	Aluminum
Handle Height Adjustment Range	84 cm to 94 cm (33 to 37 inches)
Recommended User Height	142 cm to 185 cm (4'8" to 6'1")
Wheel Size	8 inches
Foldable	Yes
Rollator Type	3-Wheel Rollator
Color	Violet

9. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact HOMLAND customer service directly. Contact details can typically be found on the product packaging or the manufacturer's official website.

© 2023 HOMLAND. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question