

[Manuals.plus](#) /

› [Pounur](#) /

› Pounur H9 Wireless Earbuds User Manual

## Pounur H9

# Pounur H9 Wireless Earbuds

## USER MANUAL

Model: H9

### 1. Product Overview

The Pounur H9 Wireless Earbuds are designed for an unparalleled audio experience, featuring Bluetooth 5.3 technology for stable connections, Hi-Fi stereo sound with powerful bass, and a comfortable, secure fit with ear hooks, ideal for sports and active lifestyles. These earbuds are IP7 waterproof, making them resistant to sweat and splashes, and offer intuitive touch controls for easy management of music and calls.



Image: Poonur H9 Wireless Earbuds in their charging case, showcasing the sleek design and digital battery display.

## 2. What's in the Box

Upon opening your Poonur H9 package, you will find the following components:

- Poonur H9 Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Multiple Sizes of Ear Tips (S/M/L)
- User Manual (this document)



Image: A visual representation of the Pounur H9 earbuds, charging case, USB cable, and ear tips included in the package.

## 3. Setup

---

### 3.1 Initial Charging

Before first use, ensure both the charging case and earbuds are fully charged.

1. Place the earbuds into the charging case, ensuring they are correctly seated in their respective slots.
2. Connect the charging case to a power source using the provided USB cable. The LED display on the case will indicate the charging status.
3. A full charge typically takes approximately 2 hours. The digital display on the charging case will show "100" when fully charged.

# Long Battery Life

Individual LED battery display



Power Display  
of Case



Power Status  
of Earbuds

**40Hrs**  
With Charging Case



**10Hrs**  
Earbud Playtime

Image: The charging case displaying battery percentages for both the case and individual earbuds, indicating long battery life.

## 3.2 Pairing with Your Device

The Poounur H9 earbuds feature one-step automatic pairing for convenience.

1. Ensure Bluetooth is enabled on your smartphone, tablet, or other compatible device.
2. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
3. On your device, search for Bluetooth devices and select "H9" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

*Note: After the initial pairing, the earbuds will automatically connect to the last paired device when the charging case lid is opened.*

# One-Step Pairing

The earbuds will be paired automatically after open charging case



Image: A visual guide demonstrating how the earbuds automatically pair with a device upon opening the charging case.

## 4. Operating Instructions

### 4.1 Wearing the Earbuds

The Poounur H9 earbuds are designed with flexible ear hooks for a secure and comfortable fit, especially during physical activity.

1. Select the ear tips (S/M/L) that provide the best seal and comfort for your ear canal.
2. Gently place the earbud into your ear canal.
3. Adjust the ear hook over your ear to ensure a snug and stable fit. The ear hooks are flexible and can be molded slightly for personalized comfort.


## Touch Intelligent Design

 **X2**  
Play/Pause

 **2S**  
Switch Song

 **X1**  
Adjust Volume



 **X2**  
Answer/End Call

 **2S**  
Hang up

 **X3**  
Activate siri

Image: Step-by-step instructions on how to put on the earbuds, including placing the earhook over the ear, inserting the eartip, and adjusting the earhook position for a comfortable and stylish fit.

### 4.2 Touch Controls

The Poounur H9 earbuds feature intuitive touch controls located on the upper part of the earphone surface.

Action	Function
Tap 2 times (L/R)	Play/Pause Music
Tap 1 time (L)	Volume Down (-)
Tap 1 time (R)	Volume Up (+)
Press and hold for 2 seconds (L)	Previous Song
Press and hold for 2 seconds (R)	Next Song
Tap 2 times (L/R) during call	Answer/End Call
Press and hold for 2 seconds (L/R) during call	Reject Call
Tap 3 times (L/R)	Activate Voice Assistant (Siri/Google Assistant)



### Comfortable and Stylish Fit

Equipped with soft, flexible and secure earloops design, no worries falling off, you'll consistently get comfortable fitting without hurting.






Image: A detailed graphic showing the touch control functions for music playback, call management, and voice assistant activation on the earbuds.

### 4.3 Call Functions

- **Answering/Ending Calls:** Tap the touch area on either earbud twice.
- **Rejecting Calls:** Press and hold the touch area on either earbud for 2 seconds.
- The built-in microphone ensures clear voice transmission during calls.

### 4.4 Music Playback

- **Play/Pause:** Tap the touch area on either earbud twice.
- **Next Song:** Press and hold the touch area on the *right* earbud for 2 seconds.
- **Previous Song:** Press and hold the touch area on the *left* earbud for 2 seconds.
- **Volume Up:** Tap the touch area on the *right* earbud once.
- **Volume Down:** Tap the touch area on the *left* earbud once.

### 4.5 Voice Assistant

Activate your device's voice assistant (Siri, Google Assistant, etc.) for hands-free control.

- **Activate:** Tap the touch area on either earbud three times.




Image: A visual representation of activating voice assistants like Hey Siri or Google Assistant by touching the earbud.

## 5. Care and Maintenance

### 5.1 Cleaning

Regular cleaning helps maintain the performance and longevity of your earbuds.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For ear tips, remove them from the earbuds and clean with a mild soap solution if necessary, then rinse thoroughly and dry completely before reattaching.
- **Important:** After exercise, wipe the metal charging contacts on the earbuds with a dry cloth to prevent corrosion from sweat.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

# IP7 Waterproof

With the nano coating, the sports running headphones supports IPX7 Waterproof, can prevent from sweat or splash



Tainy Day



Sweat Resistance



Splashproff

Image: The earbuds shown with water splashes, highlighting their IP7 waterproof capability for protection against sweat and rain.

## 5.2 Storage

When not in use, store the earbuds in their charging case to protect them from dust, damage, and to keep them charged.

- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

## 5.3 Battery Care

To maximize battery life:

- Avoid fully discharging the battery frequently.
- Charge the earbuds and case regularly, even if not used for extended periods.
- Do not expose to extreme heat or cold.

## 6. Troubleshooting

If you encounter issues with your Poonur H9 earbuds, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Earbuds not pairing/connecting	Bluetooth off, out of range, previously paired to another device.	Ensure Bluetooth is on and within 15m range. Forget "H9" from your device's Bluetooth list and re-pair. Ensure earbuds are charged and in the case before opening the lid.
Only one earbud working	Low battery, not properly seated in case, connection issue.	Place both earbuds back in the charging case, close the lid, wait a few seconds, then open again. Ensure both earbuds are charged.
No sound or low volume	Volume too low on device/earbuds, earbud placement, dirty ear tips.	Increase volume on both your device and the earbuds. Adjust earbud placement for a better seal. Clean ear tips and earbud mesh.
Charging case not charging	Faulty cable/adaptor, dirty charging port.	Try a different USB cable and power adapter. Ensure the charging port is clean and free of debris.
Touch controls unresponsive	Earbuds not properly worn, temporary software glitch.	Adjust earbuds to ensure proper fit. Place earbuds back in the case, close, then reopen to reset.

## 7. Technical Specifications

Feature	Specification
Model Name	H9
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	Up to 15 meters (49 feet)
Audio Driver Type	13mm Double-Layer Diaphragm Drivers
Battery Life (Earbuds)	Up to 8 hours per charge
Total Playtime (with Charging Case)	Up to 50 hours
Charging Time	Approximately 2 hours
Water Resistance Level	IP7 Waterproof
Control Method	Touch
Compatible Devices	Smartphones, Tablets, Laptops, Computers, TVs, Gaming Consoles, MP3 Players, iPods, Nintendo Switch, PS4, Xbox One, etc. (Android 4.4 or iOS 8.0 and above)
Item Weight	3.84 ounces

Feature	Specification
Product Dimensions	0.39 x 0.39 x 0.39 inches

## 8. Warranty and Support

---

Pounur products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, returns, or technical support, please refer to the warranty card included in your product packaging or visit the official Pounur store.

**Pounur Official Store:** <https://www.amazon.com/stores/Pounur/page/6BC9D2AA-1F9C-4CBC-AFA6-AFAE18773749>

