

## TOPTECH AL-212-BK

# AL-212 Wireless Bluetooth Speaker User Manual

Model: AL-212-BK | Brand: TOPTECH

## 1. INTRODUCTION

The TOPTECH AL-212 is a powerful and versatile wireless Bluetooth speaker designed to deliver high-fidelity sound with dynamic LED lighting. Featuring dual 12-inch woofers, it provides robust audio for various occasions, from home entertainment to outdoor parties. This manual provides detailed instructions for setting up, operating, and maintaining your speaker to ensure optimal performance.





Image: Front view of the AL-212 speaker, showcasing its dual 12-inch woofers and vibrant LED lighting.



**2\*12" Woofers**  
**Thunderous Bass Presence**

Image: Close-up view emphasizing the two 12-inch woofers, responsible for the speaker's powerful bass and clear audio output.

## 2. WHAT'S INCLUDED

Please check the package contents to ensure all items are present:

- AL-212 Wireless Bluetooth Speaker
- Remote Control
- Wired Microphone
- Power Adapter
- User Manual (this document)
- Warranty Card

## Include

- Weight: 52.9 lb
- Wireless Micophone
- Remote Control
- Portable wheels



Image: Visual representation of the speaker's dimensions and the accessories included in the package: wireless microphone, remote control, and portable wheels.

### 3. CONTROLS AND PORTS

Familiarize yourself with the control panel and various input/output ports located on the top and rear of the speaker.

#### Top Panel Controls:



Image: Detailed view of the speaker's top control panel, showing buttons for various functions and input ports.

# Simplified Interface



Image: A simplified diagram highlighting the key control buttons and their functions on the speaker's interface.

- **Power Button:** Turns the speaker on or off.
- **Mode Button:** Switches between Bluetooth, FM Radio, AUX, USB, and TF Card modes.
- **Volume Knob:** Adjusts the master volume.
- **Mic Volume Knob:** Adjusts the microphone volume.
- **Echo Knob:** Adjusts the microphone echo effect.
- **LED Mode Button:** Changes the LED light patterns.
- **Play/Pause Button:** Plays or pauses audio playback.
- **Previous/Next Track Buttons:** Skips to the previous or next track.
- **Record Button:** Records microphone input to USB/TF card.
- **TWS Button:** Initiates True Wireless Stereo pairing.

## Input/Output Ports:

- **USB Port:** For USB drive playback and charging external devices.
- **TF Card Slot:** For TF (MicroSD) card playback.
- **AUX Input (3.5mm):** Connect external audio devices via an audio cable.
- **Microphone Input (6.35mm):** Connect the wired microphone.
- **Guitar Input (6.35mm):** Connect a guitar or other instrument.

# Versatile Connectivity for Every Need

- The reliability of AUX
- The versatility of USB
- The convenience of SD card
- Wireless microphone
- Remote control
- Easily connect your smartphone, tablet, laptop, MP3 player, gaming console



Image: The AL-212 speaker displayed with icons representing its versatile connectivity options, including Bluetooth, USB, TF card, AUX, microphone, and remote control.

## 4. SETUP

### 4.1 Charging the Speaker

The AL-212 speaker is battery-powered. Before first use, fully charge the speaker using the provided power adapter. The charging indicator light will show the charging status and turn off when fully charged.

### 4.2 Initial Power On

Press and hold the Power button on the top panel to turn on the speaker. You will hear a power-on prompt, and the LED lights will illuminate.

## 5. OPERATING INSTRUCTIONS

### 5.1 Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing 'BLUE' on the display and an audible prompt.
2. Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
3. Search for "AL-212" in the list of available devices and select it to connect.
4. Once connected, you will hear a confirmation sound, and the 'BLUE' indicator will stop flashing.



Image: A smartphone screen showing the Bluetooth pairing menu, with the AL-212 speaker and a Bluetooth icon, illustrating the connection process.

### 5.2 True Wireless Stereo (TWS) Pairing

To achieve a stereo sound experience, you can pair two AL-212 speakers together using the TWS function.

1. Ensure both AL-212 speakers are powered on and not connected to any Bluetooth device.
2. Press the 'TWS' button on one of the speakers. It will emit a sound indicating it's searching for another speaker.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation sound.
4. Now, connect your Bluetooth device to one of the paired speakers (the master speaker) as described in Section 5.1. Audio will play in stereo through both speakers.

# Double the Impact, Double the Fun



Image: Two AL-212 speakers positioned outdoors, demonstrating the True Wireless Stereo (TWS) feature with a dotted line indicating the wireless connection between them.



Image: A simplified diagram showing two AL-212 speakers with a dotted line and 'TWS' label, illustrating the True Wireless Stereo connection.

## 5.3 USB/TF Card Playback

Insert a USB flash drive or TF (MicroSD) card into the respective port. The speaker will automatically switch to

USB/TF mode and begin playing audio files. Use the Play/Pause and Previous/Next Track buttons to control playback.

#### **5.4 AUX Input**

Connect an external audio device (e.g., MP3 player, laptop) to the AUX input port using a 3.5mm audio cable. The speaker will automatically switch to AUX mode. Control playback from your connected device.

#### **5.5 Microphone Usage**

Connect the provided wired microphone to the Microphone Input port. Adjust the microphone volume using the 'Mic Vol' knob and add echo effects with the 'Echo' knob. You can sing along with music playing from any source.

#### **5.6 FM Radio**

Press the 'Mode' button until you hear the FM radio prompt. Press the 'Play/Pause' button to auto-scan and save available FM stations. Use the Previous/Next Track buttons to switch between saved stations.

#### **5.7 LED Light Modes**

Press the 'LED Mode' button to cycle through different LED light patterns and effects. Press it repeatedly to find your preferred lighting display.





Image: The AL-212 speaker illuminated with its vibrant, multi-color LED lights, showcasing the dynamic light show feature.

## 5.8 Remote Control Functions

The included remote control provides convenient access to all speaker functions from a distance. Refer to the remote control diagram in the package for specific button layouts and functions.

## 6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use.
- **Water Exposure:** This speaker is not waterproof. Avoid exposing it to water or excessive moisture.

## 7. TROUBLESHOOTING

If you encounter issues with your AL-212 speaker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is low or depleted.	Connect the speaker to the power adapter and charge it fully.
No sound output.	Volume is too low; Incorrect mode selected; Device not connected properly.	Increase the speaker volume. Ensure the correct input mode (Bluetooth, AUX, USB/TF) is selected. Reconnect your device.
Bluetooth connection fails.	Speaker is not in pairing mode; Device is too far; Interference.	Ensure the speaker is in Bluetooth pairing mode. Move your device closer to the speaker. Avoid obstacles and other wireless devices.
Microphone not working.	Microphone not plugged in correctly; Mic volume is low.	Ensure the microphone is securely plugged into the correct input. Increase the 'Mic Vol' knob.
TWS pairing fails.	Speakers are already connected to another device; Speakers are too far apart.	Disconnect both speakers from any Bluetooth devices. Ensure they are within close proximity (within 10 meters) during pairing.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	AL-212-BK
Speaker Type	Woofer
Speaker Size	Dual 12 Inches
Connectivity Technology	Bluetooth, Auxiliary, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	33 Feet (10 Meters)
Audio Output Mode	Stereo (2.0 Surround Sound Channel Configuration)
Special Features	LED Light, Built-In Microphone, USB Port, Display, FM Radio, Remote Control
Power Source	Battery Powered

Feature	Detail
Product Dimensions	14.96"D x 7.48"W x 14.96"H
Color	Black
Mounting Type	Freestanding, Plug Mount
Manufacturer	Top Tech Audio
UPC	755824425927

## 9. WARRANTY AND SUPPORT

The TOPTECH AL-212 speaker comes with a Limited Warranty. Please refer to the included Warranty Card for detailed terms and conditions, including coverage period and claim procedures.

For technical support, troubleshooting assistance beyond this manual, or warranty inquiries, please contact TOPTECH customer service. Contact information can typically be found on the warranty card or the official TOPTECH website.

*Note: No official product videos from the seller were found to be embedded based on the provided criteria.*

© 2024 TOPTECH. All rights reserved.