

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Rfiver](#) /

› [Rfiver Table Top TV Stand User Manual](#)

Rfiver B0CZ7X2W4B

Rfiver Table Top TV Stand Instruction Manual

Model: B0CZ7X2W4B

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Rfiver Table Top TV Stand. Please read this manual thoroughly before installation and use to ensure proper setup and safe operation. This stand is designed to securely hold most 37 to 86 inch flat or curved TVs, with a maximum load capacity of 150 lbs.

2. SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or defective.
- Do not exceed the maximum weight capacity of 150 lbs (68 kg).
- Verify your TV's VESA mounting pattern is compatible with the stand (200x200mm to 800x600mm).
- Always use two or more people to lift and position the TV onto the stand.
- Place the TV stand on a stable, level surface to prevent tipping.
- Keep children and pets away from the assembly area.

3. PACKAGE CONTENTS

Please check the package to ensure all the following parts are included:

- TV Stand Base (2 pieces)
- Vertical TV Brackets (2 pieces)
- Connecting Bars (2 pieces)
- Hardware Kit (various screws, washers, spacers for TV mounting)
- Cable Fasteners
- Non-Slip Pads
- Soundbar Isolation Pads
- Instruction Manual

4. SETUP AND INSTALLATION

Follow these steps carefully for proper assembly. It is recommended to have a second person assist during the TV attachment phase.

4.1 Assemble Brackets

Begin by assembling the vertical TV brackets and connecting bars. Ensure all screws are tightened securely.



Image showing the first step of assembly: assembling the brackets.

4.2 Attach Brackets to TV

Carefully place your TV face down on a soft, clean surface. Attach the assembled brackets to the VESA mounting holes on the back of your TV using the appropriate screws, washers, and spacers from the hardware kit. Ensure the brackets are centered and level.

QUICK & EASY ASSEMBLY

NO DRILLING



Image illustrating the process of attaching the TV stand brackets to the television's VESA mounting points.

4.3 Attach Feet to Brackets

Connect the TV stand bases (feet) to the vertical TV brackets. This design features a double T-shaped structure for enhanced stability. Ensure all connections are firm.

T-SHAPE IS MORE STABLE

Structural stability of the T-shaped triangular support, not only does it have excellent stability, but it also has a strong 150 lbs load capacity.



Image highlighting the T-shaped structural support for improved stability.

4.4 Final Placement and Cable Management

Carefully lift the TV with the attached stand and place it on your desired surface. Apply the non-slip pads to the bottom of the stand's feet to prevent scratches and ensure stability. Use the included cable fasteners to organize and secure cables behind the TV, creating a tidy setup.



Images showing the cable management clip and non-slip pad for organized and stable setup.

5. OPERATING INSTRUCTIONS

5.1 Height Adjustment

The Rriver Table Top TV Stand features 6 levels of height adjustment, with each level providing approximately 1.8 inches of change. The total height can be adjusted up to 8.9 inches, allowing you to customize the viewing angle for optimal comfort. To adjust the height, carefully loosen the screws on the vertical brackets, slide the TV to the desired height, and then securely tighten the screws.

6 HEIGHT ADJUSTABLE ENJOY EYE LEVEL COMFORT




Image illustrating the various height adjustment levels of the TV stand.

5.2 Soundbar Placement

The stand's design allows for placement of a soundbar on the feet of the stand. Utilize the provided shock-absorbing soundbar isolation pads to reduce vibration and enhance your audio-visual experience.



Image demonstrating a soundbar placed on the stand's feet, utilizing the isolation pads.

6. MAINTENANCE

To ensure the longevity and appearance of your TV stand, follow these simple maintenance guidelines:

- Regularly check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- Clean the stand with a soft, dry cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- Keep the stand free from dust and debris.
- Avoid placing heavy objects on the stand's feet unless they are specifically designed for that purpose (e.g., soundbars with isolation pads).

7. TROUBLESHOOTING

If you encounter any issues with your Rriver Table Top TV Stand, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
TV wobbles or feels unstable	Screws are loose; stand not on a level surface; weight capacity exceeded.	Check and tighten all screws. Move the stand to a level surface. Ensure TV weight is within 150 lbs limit.
Difficulty adjusting height	Screws are too tight; obstruction in adjustment slots.	Loosen adjustment screws sufficiently. Check for any debris in the adjustment slots.
Scratches on furniture surface	Non-slip pads not applied or misplaced.	Ensure non-slip pads are correctly applied to the bottom of the stand's feet.

If the problem persists, please contact Rfiver customer service for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	Rfiver
Model	B0CZ7X2W4B
Compatible TV Sizes	37 to 86 inches
Maximum Load Capacity	150 lbs (68 kg)
VESA Compatibility	200x200mm to 800x600mm
Height Adjustment	6 levels, up to 8.9 inches total adjustment
Material	Alloy Steel
Color	Black
Product Dimensions	17.3 x 14.4 x 37.9 inches (approximate, assembled)
Item Weight	7.72 pounds

FITS FOR YOUR 37"-86" TV

WIDER RANGE OF APPLICATION





Image detailing the compatibility of the TV stand with various TV sizes and VESA mounting patterns.

9. WARRANTY AND SUPPORT

Rfiver products are manufactured with quality and durability in mind. For warranty information or technical support, please refer to the warranty card included with your product or visit the official Rfiver website. Our customer service team is available to assist you with any questions or concerns regarding your TV stand.


© 2025 Rfiver. All rights reserved.

Related Documents - B0CZ7X2W4B




[RFIVER TF3001U TV Stand Installation Manual](#)

Detailed installation guide for the RFIVER TF3001U TV Stand, including parts list, step-by-step assembly instructions, VESA compatibility chart, and safety guidelines. Learn how to safely mount your TV.




[Rfiver Universal Swivel Tabletop TV Stand Assembly Manual](#)

Assembly manual for the Rfiver Universal Swivel Tabletop TV Stand, Model UT2001. Provides step-by-step instructions and parts list for safe and proper installation.



[Rfiver TF2002 TV Stand Assembly Instructions and User Guide](#)

Comprehensive guide for assembling the Rfiver TF2002 TV stand. Includes parts list, step-by-step instructions, safety warnings, and cable management tips for your floor TV mount.



[RFIVER UT5002 TV Stand Assembly Instructions and User Guide](#)

This document provides assembly instructions, parts list, and safety notices for the RFIVER UT5002 TV Stand. Learn how to safely assemble and install your TV stand for optimal viewing.



[Comprehensive Product Catalog - Electronics, Home Goods, and Accessories](#)

A detailed catalog listing various products including electronics, home appliances, automotive accessories, personal care items, and more, with quantities, unit costs, total costs, and ASINs.