

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

TOPTECH BRAZE-8-BK

TOPTECH BRAZE-8 Dual 8" Woofer Rechargeable Party Portable Speaker User Manual

Model: BRAZE-8-BK

INTRODUCTION

Thank you for purchasing the TOPTECH BRAZE-8 Dual 8" Woofer Rechargeable Party Portable Speaker. This speaker is designed to deliver powerful sound and dynamic multi-color disco lights, perfect for various occasions from home use to outdoor parties. This manual provides essential information for safe and optimal use, including setup, operation, maintenance, and troubleshooting.





Image: Front view of the BRAZE-8 speaker showcasing its dual 8-inch woofers and vibrant multi-color LED lights on the grill.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Remote control
- Wired microphone
- Power adapter
- User manual (this document)
- Warranty card

SAFETY INFORMATION

To ensure safe operation and prevent damage, please read and adhere to the following safety guidelines:

- Do not expose the speaker to water, moisture, or extreme temperatures.
- Avoid placing the speaker near heat sources or in direct sunlight.
- Do not block ventilation openings.

- Use only the provided power adapter for charging.
- Do not attempt to disassemble or repair the speaker yourself. Contact qualified service personnel.
- Keep out of reach of children.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided power adapter to the speaker's charging port and plug it into a standard wall outlet. The charging indicator will illuminate. Once fully charged, the indicator may change color or turn off, depending on the model.



Image: An illustration showing the speaker and a large battery icon, indicating its built-in rechargeable battery feature.

2. Initial Power On

Locate the power button on the speaker. Press and hold it for a few seconds until the speaker powers on and you hear an audible prompt or see the display light up.

OPERATING INSTRUCTIONS

1. Bluetooth Connection

The speaker will automatically enter Bluetooth pairing mode upon power-on. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices. Select 'BRAZE-8' from the list. Once connected, you will hear a confirmation sound.



Image: The BRAZE-8 speaker shown with a smartphone displaying a Bluetooth connection screen, emphasizing seamless wireless

connectivity.

WIRELESS CONNECTIVITY

Easily transfer music from a smartphone, tablet, USB/TF card or other Bluetooth-enabled device with a range of up to 33 feet.



Image: A graphic illustrating the speaker's wireless connectivity with various devices such as laptops, pads, computers, cell phones, and TVs, highlighting a range of up to 33 feet.

2. True Wireless Stereo (TWS) Function

To achieve an immersive stereo experience, you can pair two BRAZE-8 speakers together using the TWS function. Power on both speakers. On one speaker, press the TWS button (refer to the control panel diagram in the manual if available). The speakers will automatically search and pair with each other. Once paired, connect your Bluetooth device to one of the speakers, and audio will play through both.

IMMERSIVE STEREO EXPERIENCE

TWS stereo surrounds the listener by synchronizing audio playback between two speakers, creating a spacious and realistic sound stage.



Image: Two BRAZE-8 speakers positioned to demonstrate the TWS (True Wireless Stereo) function, showing how they synchronize audio playback for a spacious soundstage.

TWS Function Stereo Surround

It's time to unleash the beast!



Image: A family enjoying a sports game with two BRAZE-8 speakers providing stereo surround sound, illustrating the immersive experience of the TWS function.

3. Other Input Modes (USB/TF/FM Radio/AUX)

The speaker supports multiple input sources. Insert a USB drive or TF card into the respective slot to play audio files. Connect an external device using a 3.5mm AUX cable to the AUX input. To use FM Radio, switch to FM mode and use the scan function to find stations.

Premium Sounding Speaker




Image: The BRAZE-8 speaker displayed with icons representing its versatile input options: AUX, Bluetooth, TF card, FM Radio, USB, and Microphone, highlighting its adaptability for various audio sources.

4. Microphone Usage

Connect the wired microphone to the designated microphone input jack. Adjust the microphone volume using the dedicated knob on the speaker's control panel.

5. Dynamic Multi-Hued Light Show

The speaker features built-in disco lights. Press the dedicated light button to cycle through different light modes or to turn the lights on/off. The lights will pulse and change colors, enhancing the atmosphere.



VIBRANT LED LIGHTS

Enjoy a dazzling light show with dynamic LED lights that pulse and change colors to the beat of your music.

Image: The BRAZE-8 speaker with its vibrant LED lights illuminated, set against a backdrop of people enjoying a party, illustrating its dynamic light show feature.

Dynamic LED Lights for Visual Excitement

Simply press to turn on the lights



Image: The BRAZE-8 speaker with its dynamic LED lights creating a festive ambiance at an evening gathering, emphasizing the visual excitement it adds.

MAINTENANCE

1. Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents. Ensure no liquid enters the speaker openings.

2. Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery every 3-6 months to maintain its lifespan.

3. Battery Care

To maximize battery life, avoid fully discharging the speaker frequently. Charge the speaker when the battery low indicator appears. The speaker offers up to 6 hours of playtime on a single charge.

UP TO 6H PLAYTIME

Enjoy uninterrupted music playback with up to 6 hours of battery life on a single charge, ensuring your music never misses a beat.

6H



Image: The BRAZE-8 speaker with a graphic indicating "UP TO 6H PLAYTIME", highlighting its battery endurance for uninterrupted music playback.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker; Press and hold the power button firmly.
No sound.	Volume too low; Incorrect input mode; Device not connected.	Increase volume on speaker and connected device; Select correct input mode (Bluetooth, AUX, USB, TF); Reconnect device.
Bluetooth connection fails.	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in pairing mode; Move device closer to speaker; Avoid obstacles and other wireless devices.

Problem	Possible Cause	Solution
Lights not working.	Lights turned off.	Press the light button to activate or cycle modes.

SPECIFICATIONS

Feature	Detail
Model Number	BRAZE-8-BK
Brand	TOPTECH
Power Source	Battery Powered
Woofers Size	Dual 8-inch
Connectivity Technology	Wireless (Bluetooth), AUX, USB
Bluetooth Distance	Up to 10 meters (33 feet)
Audio Input	Wired microphone, USB, TF, FM Radio, AUX
Playtime	Up to 6 hours (approximate)
Color	Black
Manufacturer	Top Tech Audio
UPC	755824426009

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the included warranty card for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact TOPTECH customer service through the retailer where the product was purchased or visit the official TOPTECH website.

For additional information and updates, please visit the [TOPTECH Store on Amazon](#).