

CCLIFE DSKGT001A0000000

CCLIFE Outdoor 4-in-1 Multifunctional Swing Set User Manual

Model: DSKGT001A0000000

1. INTRODUCTION

Thank you for choosing the CCLIFE Outdoor 4-in-1 Multifunctional Swing Set. This versatile play equipment is designed to provide children with a fun and engaging outdoor experience, featuring a basketball hoop, a nest swing, a standard swing, and a football net. Constructed from high-quality, rust-resistant metal with an A-type frame, this swing set offers stability and durability for long-lasting enjoyment. Please read this manual carefully before assembly and use to ensure safe operation and proper maintenance.

2. SAFETY INFORMATION

Your safety and the safety of others are paramount. Adhere to all safety guidelines to prevent injury.

- **Maximum Weight Capacity:** The swing set has a total weight capacity of 200 kg (approximately 440 lbs). Each individual swing (standard and nest swing) has a maximum weight capacity of 100 kg (approximately 220 lbs). Do not exceed these limits.
- **Adult Supervision:** Children should always be supervised by an adult while using the swing set.
- **Proper Installation:** Ensure the swing set is assembled correctly and securely anchored to the ground using the provided L-shaped iron pieces and ground anchors. Improper installation can lead to instability and injury.
- **Clearance Area:** Maintain a safe clearance area around the swing set, free from obstacles such as fences, trees, or other play equipment.
- **Regular Inspection:** Before each use, inspect the swing set for any loose bolts, worn ropes, damaged components, or signs of rust. Do not use the swing set if any damage is found.
- **Weather Conditions:** Do not use the swing set during strong winds, heavy rain, or thunderstorms.
- **Age Appropriateness:** Ensure children using the swing set are within the appropriate age range for safe use.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact CCLIFE customer support.



Figure 3.1: Overview of all components and dimensions.

- Main Swing Frame (A-type metal construction)
- Standard Swing Seat with adjustable ropes
- Nest Swing with adjustable ropes
- Basketball Hoop attachment
- Football Net attachment
- 5 L-shaped Iron Pieces for stability
- 5 Ground Anchors (stakes)
- Assembly Hardware (bolts, nuts, washers, carabiner hooks)
- Basketball (15cm diameter)
- Football (15cm diameter)

4. SETUP AND ASSEMBLY

Assembly of the CCLIFE Swing Set is designed to be straightforward. It is recommended that two adults perform the assembly for ease and safety.

1. **Unpack Components:** Carefully unpack all parts and lay them out on a clean, flat surface. Verify all components against the package contents list.
2. **Assemble Frame:** Begin by assembling the main A-type metal frame according to the included diagram.

Ensure all connections are secure but do not fully tighten bolts until the frame is complete.

3. **Attach Swings:** Securely attach the standard swing and the nest swing to the top bar using the provided carabiner hooks. The height of both swings can be adjusted using the ropes.
4. **Install Basketball Hoop and Football Net:** Attach the basketball hoop to the designated corner of the frame. Install the football net attachment to the side of the frame.
5. **Secure to Ground:** Once the frame is fully assembled and all attachments are in place, position the swing set in its desired outdoor location. Use the 5 L-shaped iron pieces and 5 ground anchors to firmly secure the swing set to the ground. This step is crucial for stability and safety.
6. **Final Tightening:** Once the swing set is positioned and anchored, fully tighten all bolts and nuts on the frame and attachments.




Figure 4.1: Structural details and connection points.



Figure 4.2: Detail of metal tube connection.



Figure 4.3: Ground anchoring detail.

5. OPERATING INSTRUCTIONS

The CCLIFE Swing Set offers multiple play options for children.

- **Standard Swing:** Children can sit on the green plastic seat and swing back and forth. Ensure proper grip on the ropes.
- **Nest Swing:** The blue nest swing allows for multiple children or different swinging positions. Ensure children are safely positioned within the nest.
- **Adjusting Swing Height:** The height of both the standard and nest swings can be adjusted by modifying the rope length. Refer to the assembly section for details on how to adjust the ropes securely.
- **Basketball Hoop:** Use the provided basketball to practice shooting hoops.
- **Football Net:** Use the provided football to practice kicking and scoring goals.



Figure 5.1: The complete swing set with all features.



Figure 5.2: Swing rope adjustment mechanism.



Figure 5.3: Adjusting swing height.

6. MAINTENANCE

Regular maintenance will extend the life of your swing set and ensure continued safety.

- **Cleaning:** Clean the metal frame and plastic components periodically with mild soap and water. Rinse thoroughly and dry to prevent rust.
- **Hardware Check:** Annually, or more frequently with heavy use, check all bolts, nuts, and connections for tightness. Tighten any loose hardware.
- **Rope Inspection:** Inspect swing ropes for fraying, cuts, or excessive wear. Replace worn ropes immediately.
- **Rust Prevention:** While the metal is rust-resistant, inspect for any scratches or chips in the paint that could expose the metal to moisture. Touch up with rust-inhibiting paint if necessary.
- **Ground Anchors:** Periodically check that the ground anchors remain firmly in place, especially after heavy rain or strong winds.

7. TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Swing Set Wobbles:**
Solution: Ensure all bolts are fully tightened. Verify that the L-shaped iron pieces and ground anchors are properly installed and firmly secured into the ground. The ground surface should be level.
- **Parts Do Not Fit During Assembly:**
Solution: Double-check the assembly instructions and diagrams to ensure you are using the correct parts for each step. Some parts may look similar but have slight differences. Do not force parts together. If a part is genuinely misaligned or defective, contact customer support.
- **Swing Ropes Seem Too Short/Long:**
Solution: The swing ropes are adjustable. Refer to the 'Operating Instructions' section for guidance on how to safely adjust the rope length to the desired height.
- **Rust Appears on Frame:**
Solution: Clean the affected area thoroughly. If it's surface rust, it can often be removed with a wire brush and then treated with rust-inhibiting primer and paint. For significant rust, consider contacting customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	CCLIFE
Model Number	DSKGT001A0000000
Product Dimensions (L x W x H)	256 cm x 181 cm x 179 cm (100.8 in x 71.3 in x 70.5 in)

Feature	Specification
Item Weight	22.5 Kilograms (49.6 lbs)
Frame Material	Metal
Color	Yellow, Blue, Green
Total Weight Capacity	200 kg (440 lbs)
Individual Swing Capacity	100 kg (220 lbs) per swing
Features	Basketball Hoop, Nest Swing, Standard Swing, Football Net

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact CCLIFE customer service directly. Refer to the contact information provided with your purchase or visit the official CCLIFE website. Please retain your proof of purchase for any warranty claims.

© 2025 CCLIFE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question