

[Manuals.plus](#) /

› [TiMOVO](#) /

› TiMOVO Magnetic Pen Compatible with Remarkable 2, EMR Digital Stylus with Eraser for Remarkable, 4096 Sensitivity and Palm Rejection and Tilt for Kindle Scribe/Boox Black - User Manual

TiMOVO TiMOVO EMR Pen


TiMOVO EMR Digital Stylus User Manual

Model: TiMOVO EMR Pen

Brand: TiMOVO

1. INTRODUCTION

Welcome to the user manual for your TiMOVO EMR Digital Stylus. This stylus is designed to provide a natural and precise writing and drawing experience on compatible EMR-enabled devices. It features advanced technology for seamless interaction without the need for charging or pairing.




The TiMOVO EMR Digital Stylus, a sleek black pen with three replacement nibs and a nib removal tool, ready for use.

2. PACKAGE CONTENTS


Please verify that all items are present in your package:

- 1 x TiMOVO EMR Stylus
- 3 x Replacement Nibs
- 1 x Pen Nib Clip (Removal Tool)

Easy to Replace Nibs




1. Use the nib clip to grip the nib.



2. Gently pull out the nib.



3. Align the new nib with the hole



4. Press down firmly to secure

Contents of the TiMOVO EMR Stylus package, including the stylus, three spare nibs, and a metal nib removal clip.

3. SETUP

The TiMOVO EMR Digital Stylus is designed for immediate use with compatible EMR devices. No charging, Bluetooth pairing, or software installation is required.

First Use

1. Unpack the stylus from its packaging.
2. Ensure your device (e.g., reMarkable 2, Kindle Scribe, Samsung Galaxy Tab/Note/Book) has EMR technology integrated into its display.

3. Begin writing or drawing directly on your device's screen. The stylus will be recognized automatically.

Palm Rejection

Rest your hands naturally on the screen while writing or drawing.



A user demonstrating the palm rejection feature, writing on a tablet with their hand resting comfortably on the screen.

4. OPERATING INSTRUCTIONS

Writing and Drawing

The stylus offers a natural writing experience with its precise tip and 4096 levels of pressure sensitivity.

- **Pressure Sensitivity:** The stylus responds to the lightest touch, allowing for varied line thickness and shading based on pressure applied.
- **Tilt Support:** Tilt the pen tip at an angle (e.g., 15°, 30°, 60°, 90°) to create different line effects, similar to a traditional pencil. This feature is ideal for shading and artistic strokes.

4096

Pressure & Tilt Support

Responsive and write down
what you need easily and accurately



An illustration demonstrating the 4096 levels of pressure and tilt support, showing how different angles of the stylus create varying line widths and effects.

Eraser Function

The TiMOVO EMR Stylus features a convenient eraser function for quick corrections.

1. **End Eraser:** For quick erasing, simply flip the stylus over and use the end opposite the nib to erase directly on the screen. This mimics the action of a traditional pencil eraser.
2. **Side Button Eraser:** On some compatible tablets, you may need to press and hold the side button on the stylus while moving the tip over the area you wish to erase. Refer to your device's settings for specific button customization options.

Built-in Eraser

Easily erase unwanted lines and text



A close-up image of the stylus erasing a drawing on a tablet, highlighting the built-in eraser function at the top of the pen.

Palm Rejection

The integrated palm rejection technology allows you to rest your hand naturally on the screen while writing or drawing, preventing accidental marks.

This feature ensures a comfortable and uninterrupted creative or note-taking process.

Magnetic Adsorption

The stylus is designed with magnetic adsorption, allowing it to securely attach to the side of compatible tablets for easy storage and transport.



The TiMOVO stylus magnetically attached to the side of a tablet, illustrating its strong magnetic adsorption feature.

5. MAINTENANCE


Replacing Nibs

The stylus comes with three replacement nibs. Nibs may wear down over time and can be easily replaced.


1. **Use the Nib Clip:** Gently grip the existing nib with the provided metal nib clip.
2. **Pull Out:** Carefully pull the nib straight out from the stylus.
3. **Align New Nib:** Take a new replacement nib and align its base with the hole at the tip of the stylus.
4. **Press Firmly:** Press the new nib firmly into the stylus until it is securely seated.

The nibs are made from durable POM material, providing a smooth writing experience.

Easy to Replace Nibs




1. Use the nib clip to grip the nib.



2. Gently pull out the nib.



3. Align the new nib with the hole



4. Press down firmly to secure

A four-step visual guide demonstrating how to easily replace the stylus nibs using the provided nib clip.

6. COMPATIBILITY

This EMR Digital Stylus is specifically designed for devices with integrated EMR technology.

Compatible Devices Include:

- reMarkable 2 / reMarkable 1 (Note: Not compatible with the latest version of Remarkable Paper Pro)
- Kindle Scribe
- Most Samsung Galaxy Tab, Galaxy Note, and Galaxy Book models
- BOOX devices
- Wacom devices

Please verify your device's compatibility with EMR technology before use.

7. TROUBLESHOOTING

Stylus Not Responding

- **Check Compatibility:** Ensure your device is listed as compatible with EMR technology. This stylus does not work with non-EMR screens.
- **Nib Check:** Verify that the nib is securely inserted. If it's loose or damaged, replace it with a new one.
- **Device Restart:** Try restarting your tablet or e-reader.

Eraser Function Issues

- **End Eraser:** Ensure you are using the correct end of the stylus for the physical eraser.
- **Side Button Eraser:** If using the side button, confirm that your device's software supports this function and that the button is correctly configured in your device settings.

Magnetic Attachment Issues

- **Device Compatibility:** Magnetic attachment is device-specific. Ensure your tablet has a magnetic strip designed for stylus attachment.
- **Orientation:** Try different orientations of the stylus on the tablet's side to find the strongest magnetic connection.

8. SPECIFICATIONS

Feature	Specification
Brand	TiMOVO
Model	TiMOVO EMR Pen
Color	Black
Dimensions	16.51 x 0.91 x 0.91 cm (6.5 x 0.36 x 0.36 inches)
Weight	17 g (0.6 oz)
Material	Plastic (POM nibs)
Pressure Sensitivity	4096 Levels
Battery Required	No
Features	Palm Rejection, Tilt Support, Magnetic Adsorption, Built-in Eraser

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official TiMOVO website or contact your retailer. Keep your purchase receipt for warranty claims.

For further assistance or technical inquiries, please visit the TiMOVO store page:[TiMOVO Official Store](#).

© 2024 TiMOVO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question