

LINNER DEIUXE

LINNER Rechargeable Headphones User Manual

Model: **DEIUXE** | Brand: **LINNER**

1. INTRODUCTION

This manual provides detailed instructions for the proper use, maintenance, and troubleshooting of your LINNER Rechargeable Headphones, model DEIUXE. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW AND FEATURES

The LINNER DEIUXE headphones are designed for an enhanced audio experience, featuring advanced sound technology and a comfortable in-ear design. They are rechargeable for convenient, portable use.

- **Rechargeable Battery:** Provides extended listening time with easy charging.
- **High-Quality Speakers:** Delivers clear and rich audio output.
- **In-Ear Design:** Ensures a secure and comfortable fit.
- **Media Control:** Integrated controls for playback management.
- **Wireless Connectivity:** Operates without cables for freedom of movement.



Figure 2.1: Exploded view and design sketches of the LINNER DEIUXE headphones and their charging case, illustrating internal components and overall structure.

3. PACKAGE CONTENTS

Please check the package for the following items:

- LINNER DEIUXE Rechargeable Headphones (1 pair)
- Charging Case (1)
- USB Charging Cable (1)
- User Manual (this document)
- Various sizes of ear tips (S, M, L)

4. SETUP

4.1 Initial Charging

1. Place both headphones into the charging case.
2. Connect the USB charging cable to the charging port on the case and plug the other end into a compatible USB power source (e.g., computer USB port, wall adapter).
3. The indicator lights on the case and headphones will show charging status. Allow approximately 2 hours for a full charge.
4. Once fully charged, disconnect the charging cable.

4.2 Pairing with a Device

1. Ensure the headphones are charged and inside the charging case.
2. Open the charging case lid. The headphones will automatically enter pairing mode (indicator lights will flash).
3. On your device (smartphone, tablet, computer), go to the Bluetooth settings.

4. Select "LINNEX DEIUXE" from the list of available devices.
5. Once connected, the indicator lights on the headphones will stop flashing and remain solid or turn off, depending on the model.
6. If pairing fails, turn off Bluetooth on your device, close the charging case, wait 10 seconds, then repeat the steps.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Open the charging case lid, or take the headphones out of the case. They will power on automatically.
- **Power Off:** Place the headphones back into the charging case and close the lid. They will power off automatically.

5.2 Media Control

The LINNEX DEIUXE headphones feature touch-sensitive controls. Specific functions may vary slightly, but generally include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.

5.3 Call Management

- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.



Figure 5.1: Individuals utilizing LINNEX DEIUXE headphones in diverse environments, demonstrating their versatility and comfortable fit for everyday use.

6. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the headphones and charging case. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in their charging case to protect them and keep them charged.
- **Battery Life:** To preserve battery life, avoid fully discharging the headphones frequently. Charge them regularly.
- **Water Resistance:** The headphones are not waterproof. Avoid exposure to water, moisture, or extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones not powering on	Low battery; not properly seated in case.	Charge the headphones and case fully. Ensure headphones are correctly placed in the case.
Cannot pair with device	Bluetooth off; headphones not in pairing mode; interference.	Ensure Bluetooth is enabled on your device. Place headphones in case, open lid to re-enter pairing mode. Move closer to device.
No sound or low volume	Volume too low on device/headphones; headphones not connected; dirty ear tips.	Increase volume on both device and headphones. Reconnect headphones. Clean ear tips and speaker mesh.
Charging issue	Cable/adaptor fault; dirty charging contacts.	Try a different USB cable and power adapter. Clean the charging contacts on both headphones and case with a dry cotton swab.

8. SPECIFICATIONS

Feature	Detail
Model Number	DEIUXE
Brand	LINNER
Ear Placement	In Ear
Control Type	Media Control
Cable Feature	Without Cable (Wireless)
Power Source	Rechargeable Battery
Connectivity	Bluetooth

9. WARRANTY AND SUPPORT

LINNER products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official LINNER website.

Official LINNER Store: [Visit the LINNER Store on Amazon](#)

