

[Manuals.plus](#) /

› [Devoko](#) /

› Devoko 3x4m Aluminum Cantilever Patio Umbrella User Manual

Devoko Alu Sonnenschirm Balkon

Devoko 3x4m Aluminum Cantilever Patio Umbrella User Manual

INTRODUCTION

Thank you for choosing the Devoko 3x4m Aluminum Cantilever Patio Umbrella. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new umbrella. Please read these instructions carefully before use and retain them for future reference.

This umbrella is designed to provide shade and protection from sun and light rain in outdoor environments such as gardens, patios, and balconies. It features a durable aluminum frame and a polyester canopy with UV50+ protection and waterproof properties.

SAFETY INFORMATION

- Always ensure the umbrella base is properly weighted or anchored to the ground to prevent tipping, especially in windy conditions. Floor screws are included for ground anchoring.
- Do not use the umbrella in strong winds or severe weather. Close and secure the umbrella when not in use or during adverse weather conditions.
- Keep children and pets away from the umbrella during opening and closing operations to prevent injury.
- Regularly inspect all components for wear and tear. Replace damaged parts immediately.
- Do not hang objects from the umbrella frame or canopy.

PACKAGE CONTENTS

Before assembly, ensure all components are present:

- Umbrella Canopy (Polyester)
- Aluminum Pole/Shaft
- Crank Mechanism
- 6 Support Ribs
- Cross Base

- Protective Cover (Oxford 300D fabric)
- Assembly Hardware (including floor screws)
- Instruction Manual

SETUP AND ASSEMBLY

Assembly typically takes one adult less than 20 minutes. Follow the included clear instructions and use the provided accessories.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components listed in the "Package Contents" section are present.
2. **Assemble the Cross Base:** Connect the base components as per the diagram in the separate assembly guide.
3. **Secure the Base:** It is crucial to secure the cross base. You can either:
 - Place heavy weights (not included) on the cross base.
 - Anchor the base directly to the ground using the provided floor screws. This is highly recommended for stability.
4. **Attach the Main Pole:** Insert the main aluminum pole into the assembled and secured cross base. Ensure it is firmly seated and tightened.
5. **Mount the Umbrella Canopy:** Attach the umbrella canopy assembly to the main pole. Follow the specific instructions for connecting the crank mechanism and securing the canopy.
6. **Final Check:** Before first use, ensure all connections are tight and the umbrella is stable.




Image: Detailed view of the umbrella's dimensions and the robust cross base for stability.

OPERATING INSTRUCTIONS

The Devoko umbrella features a user-friendly crank mechanism and a pedal for easy adjustments.

1. **Opening the Umbrella:** Turn the crank handle clockwise to extend the canopy until it is fully open.
2. **Closing the Umbrella:** Turn the crank handle counter-clockwise to retract the canopy until it is fully closed.
3. **Adjusting Height and Angle:** Use the crank mechanism to adjust the height of the canopy. The angle can also be adjusted to provide optimal shade.
4. **Adjusting Position (Rotation):** To change the umbrella's horizontal position or direction, press the pedal located on the lower side of the main pole. While holding the pedal down, rotate the umbrella to the desired position, then release the pedal to lock it in place. This allows you to easily track the sun's movement throughout the day.



Image: Illustration of the crank and pedal mechanism for opening, tilting, and rotating the umbrella.

MAINTENANCE

- **Cleaning the Canopy:** Clean the polyester canopy with a dry cloth. For stubborn dirt, use a mild soap solution and a soft brush, then rinse thoroughly and allow to air dry completely before closing or storing.
- **Frame Care:** The aluminum frame is rust-resistant. Wipe it clean with a damp cloth as needed. Avoid abrasive cleaners.
- **Storage:** When not in use for extended periods or during off-season, close the umbrella and cover it with the provided 300D Oxford fabric protective cover to shield it from weather elements. Store in a dry, protected area.
- **Inspection:** Periodically check all screws, bolts, and moving parts to ensure they are secure and functioning correctly. Tighten any loose fasteners.



PA-BESCHICHTUNG FÜR UV-SCHUTZ

Der Sonnenschirm besteht aus 210G Polyester-Gewebe mit PA-Beschichtung, UPF 50+ UV-Schutz

WASSERDICHTES POLYESTERGEWEBE

Der Material aus Polyester-Gewebe ist nicht nur wasserfest, sondern auch leicht zu reinigen

Image: The canopy fabric offers UV 50+ protection and is waterproof, making it easy to clean.

TROUBLESHOOTING

- **Umbrella moves excessively in light wind:** Ensure the base is adequately weighted or securely anchored to the ground. The large size of the umbrella makes it more susceptible to wind movement if not properly secured.
- **Crank mechanism or cord is broken:** If the internal cord or crank mechanism fails, discontinue use. Contact Devoko customer support for assistance or replacement parts.
- **Difficulty opening/closing:** Check for any obstructions in the canopy or frame. Ensure the crank mechanism is clean and free of debris. Apply a silicone-based lubricant to moving parts if necessary.

SPECIFICATIONS

Brand	Devoko
-------	--------

Model Name	Alu Sonnenschirm Balkon
Dimensions (Length x Height)	4m x 2.6m
Canopy Size	3m x 4m
Item Weight	30 kg
Frame Material	Aluminum
Canopy Material	Polyester (210G, 300D Oxford for cover)
Special Features	Adjustable Height, UV Resistant (UV50+), Rust Resistant
Opening Mechanism	Crank Mechanism
Tilting Mechanism	Manual Tilt
Included Components	Crank Mechanism, 6 Support Poles, Protective Cover

WARRANTY AND SUPPORT

Devoko products undergo rigorous durability testing. For any questions, concerns, or to report a defect, please contact Devoko customer support. Refer to your purchase documentation for specific warranty terms and contact information. You can often find support contact details on the retailer's website where you purchased the product or by visiting the official Devoko brand store online.

