

## Pwxaxy HX100M4

# User Manual

## PXWAXPY 4-IN-1 MAGNETIC PORTABLE CHARGER 10800MAH

Model: HX100M4

### Introduction

Thank you for choosing the Pwxaxy 4-in-1 Magnetic Portable Charger. This versatile power bank is designed to provide convenient and efficient charging for your iPhone, Apple Watch, and other compatible devices. With its 10800mAh capacity, MagSafe compatibility, and multiple charging outputs, it is an ideal companion for daily use and travel. Please read this manual carefully to ensure proper use and maintenance of your device.

### Product Features

- **4-in-1 Charging Solution:** Supports MagSafe wireless charging for iPhone, wireless charging for Apple Watch, and wired charging via USB-A and USB-C ports.
- **High Capacity:** 10800mAh battery provides multiple charges for your devices.
- **Fast Charging:** Features 20W PD (Power Delivery) USB-C output and 18W QC4.0 USB-A output for rapid wired charging.
- **Magnetic Alignment:** Strong magnetic attraction ensures secure and efficient wireless charging for MagSafe-compatible iPhones.
- **LCD Display:** Intuitive digital screen shows the remaining power percentage for easy management.
- **Compact and Portable:** Designed for easy carrying, making it perfect for travel.
- **Superior Safety:** Built-in smart chip with multi-protect safety system guards against overcharging, over-current, and short circuits.



Image: The Pwxaxy 4-in-1 Magnetic Portable Charger in blue, shown magnetically attached to an iPhone with an Apple Watch charging on its dedicated pad. The LCD display shows '100%' charge.

# 10800mAh Wireless Magnetic Portable Charger



4.4\*2.8\*1 in



**2** Charges  
iPhone 15

**1.5** Charges  
iPhone 15 Pro Max

**25** Charges  
iWatch

Image: A woman holding the Pxwaxpy 10800mAh Wireless Magnetic Portable Charger next to an iPhone. Text indicates its dimensions (4.4\*2.8\*1 inches) and charging capacities: approximately 2 charges for iPhone 15, 1.5 charges for iPhone 15 Pro Max, and 25 charges for iWatch.

## Package Contents

Please check the package for the following items:

- 1 x Pxwaxpy Wireless Magnetic Portable Charger (with 1 USB-C port & 1 USB-A port)
- 1 x USB-C Charging Cable
- 1 x User Manual

## Getting Started (Setup)

### Charging the Portable Charger

1. Connect the included USB-C charging cable to the USB-C input port on the portable charger.
2. Connect the other end of the USB-C cable to a compatible USB wall adapter (not included). A 20W PD adapter is recommended for fastest charging.
3. The LCD display will show the charging progress, indicating the battery percentage.

- The charger is fully charged when the display shows 100%.

## Operating Instructions

### Wireless Charging for iPhone (MagSafe Compatible)

- Ensure your iPhone is MagSafe compatible (iPhone 12 series or newer) or is using a MagSafe-compatible case. Wireless charging will not work with non-magnetic cases.
- Align the back of your iPhone with the magnetic charging area on the portable charger. The magnets will snap into place, ensuring proper alignment.
- The iPhone's screen will indicate that charging has begun.



Image: Illustration showing the difference between magnetic cases (compatible with wireless charging) and non-magnetic cases (not compatible). The Pxwaxy charger attaches securely to an iPhone with a magnetic case.

# MagSafe Super-strong Magnetic Power Bank



Image: A hand holding an iPhone with the Pwxaxy power bank magnetically attached, demonstrating the strong magnetic connection for secure wireless charging.

## Wireless Charging for Apple Watch

1. Place your Apple Watch onto the dedicated wireless charging pad on the portable charger.
2. Ensure the watch is centered on the pad for optimal charging.
3. The Apple Watch screen will indicate that charging has begun.

## Wired Charging (USB-A and USB-C)

1. Connect your device's charging cable to either the USB-A output port or the USB-C output port on the portable charger.
2. Connect the other end of the cable to your device.
3. The portable charger will automatically begin charging your device.

## QC4.0+20W Full-Speed Wired or Wireless Charging



### Wireless Charging (7.5W+3W)

Compatible with iPhone 15/14/13/12 Series/iWatch/Airpods



### Wired Fast Charging (20W Max)

Compatible with all iPhone/iPad/  
Android Phones



iPhone: **7.5W**



iWatch: **3W**



USB C Output: **20W**



USB A Output: **18W**

Image: Visual representation of the charger's capabilities, showing wireless charging for iPhone (7.5W) and iWatch (3W), and wired fast charging (20W Max) via USB-C and USB-A ports.

### Charging Multiple Devices Simultaneously

The Pwxapy portable charger supports charging up to four devices concurrently:

- One iPhone via MagSafe wireless charging.
- One Apple Watch via its dedicated wireless charging pad.
- One device via the USB-A output port.
- One device via the USB-C output port.

# Charging for 4 Devices Simultaneously

Dual Wireless Charging+PD 20W USB-C Output+QC4.0 USB-A Output



Image: A setup showing the Pxwaxpy portable charger simultaneously charging an iPhone (wirelessly), an Apple Watch (wirelessly), a smartphone (wired via USB-C), and a tablet (wired via USB-A), all connected to a laptop.

## Care and Maintenance

- Keep the portable charger away from water, fire, and high temperatures.
- Do not disassemble, modify, or repair the device yourself.
- Avoid dropping or subjecting the device to strong impacts.
- Clean the surface with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the device in a cool, dry place when not in use.

## Troubleshooting

Problem	Possible Cause	Solution
Device not charging wirelessly.	Non-MagSafe case; improper alignment; device not compatible.	Remove non-MagSafe case or use a MagSafe-compatible one. Realign device on the charging pad. Ensure device supports wireless charging.

Problem	Possible Cause	Solution
Slow charging.	Using a non-fast charging adapter/cable; multiple devices charging simultaneously.	Use a 20W PD compatible wall adapter and the included USB-C cable for optimal charging speed. Disconnect other devices if faster charging is needed for one.
Portable charger not charging.	Faulty cable or adapter; loose connection.	Try a different USB-C cable and wall adapter. Ensure all connections are secure.
LCD display not working.	Device is off or battery is completely drained.	Connect the portable charger to a power source to charge it.

## Product Specifications

Feature	Detail
Model Number	HX100M4
Battery Capacity	10800 Milliamp Hours
Product Dimensions	4.4 x 2.8 x 1.02 inches
Item Weight	7.1 ounces
USB-C Input	Max 18W
USB-C Output	Max 20W PD
USB-A Output	Max 18W QC4.0
iPhone Wireless Output	Max 7.5W
Apple Watch Wireless Output	Max 3W
Color	Blue
Manufacturer	Dongguan Yuanhaoxun Technology Co., Ltd

## Warranty and Customer Support

Your Pwxaxy Magnetic Portable Charger comes with a worry-free 24-month warranty. If you encounter any issues or have questions regarding your product, please do not hesitate to contact our friendly customer service team. For support, please refer to the contact information provided with your purchase or visit the official Pwxaxy website.

Seller: Pwxaxy Direct