

[Manuals.plus](#) /

› [Juboos](#) /

› Juboos Kid's Analog Watch Instruction Manual

Juboos 6123

Juboos Kid's Analog Watch Instruction Manual

Model: 6123

INTRODUCTION

This manual provides comprehensive instructions for the Juboos Kid's Analog Watch, designed for children with features such as 5 ATM/50 M water resistance, an easy-to-read dial, and a colorful LED light. Please read this manual thoroughly before using the watch to ensure proper operation and longevity.




The Juboos Kid's Analog Watch features a large, easy-to-read dial with glowing numbers and hands, making it ideal for teaching children how to tell time. The watch is presented in a durable black diamond color.

Safety Information

Please observe the following safety guidelines to prevent injury or damage to the product:

- **KEEP OUT OF REACH OF CHILDREN:** This product contains small parts and a button cell battery which can be a choking hazard.
- **BATTERY WARNING:** This product contains button cells or button batteries. Retain original packaging until ready to use. Dispose of used batteries immediately and keep away from children. If you suspect that a battery has been swallowed or inserted into any part of the body, seek immediate medical attention.
- **CHOKING HAZARD:** Be careful of sharp edges. Not suitable for children under 3 years of age.



Important safety warnings are displayed on the product packaging, emphasizing battery safety and choking hazards for young children.

SETUP

Unboxing

Your Juboos Kid's Analog Watch comes securely packaged in a durable tin box, designed to protect the watch during transit and for storage.



The watch is presented in a protective tin box, making it suitable for gifting and safe storage.

Initial Setup and Time Setting

Before first use, you may need to remove a small plastic stopper from the watch crown (the knob on the side). This stopper prevents battery drain during storage.

1. Gently pull out the crown located on the right side of the watch until you hear a small click.
2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back in firmly until it clicks into place. This also ensures the watch's water resistance.



Follow these steps to accurately set the time on your watch, ensuring the crown is fully pushed in for water resistance.

Battery Information

The watch comes with one Lithium Metal battery included and pre-installed. No initial battery installation is required.

OPERATING INSTRUCTIONS

Using the LED Light

The Juboos Kid's Analog Watch features a vibrant 7-color LED backlight to illuminate the dial in low-light conditions. To activate the light, press the "LIGHT" button located on the side of the watch. Each press cycles through different colors, providing a fun and functional way to read the time in the dark.



The watch offers a variety of LED backlight colors, easily changed by pressing the dedicated light button.



The LED light feature allows for easy time reading in various lighting conditions, including dim environments.

Water Resistance (5 ATM / 50 M)

The Juboos Kid's Analog Watch is designed with 5 ATM (Atmospheres) or 50 Meters of water resistance. This means it is suitable for daily use and can withstand splashes, rain, hand washing, and brief immersion in water, such as during swimming. **IMPORTANT: Do not press any buttons while the watch is submerged in water, and avoid exposure to hot water or steam, as this can compromise the water resistance seal.**



50M/164FT WATER RESISTANT

NOTE: Do not pull out the button underwater.



Hand washing



Rain



Sweat



No heat

The watch is designed to be water resistant for everyday activities, including splashes and brief immersion.

Your browser does not support the video tag.

This video demonstrates the water resistance of the Juboos Kid's Analog Watch, showing it submerged in water without affecting its functionality. It also highlights the 7 colorful LED light feature.

MAINTENANCE

Cleaning

To clean your watch, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish or internal components.

Battery Replacement

The watch uses a Lithium Metal battery. When the battery needs replacement, it is recommended to take the watch to a professional watch repair service. This ensures the correct battery type is used and the water resistance seal is properly maintained.

Storage


When not in use, store the watch in a cool, dry place, away from direct sunlight and extreme temperatures. The original tin box provides excellent protection for storage.

TROUBLESHOOTING

- **Watch not running:** Ensure the crown is fully pushed in. If it was pulled out for time setting, push it back firmly. If the watch still does not run, the battery may need replacement.
- **LED light not working:** If the LED light does not illuminate or is dim, the battery may be low and require replacement.
- **Water inside the watch:** If you notice condensation or water inside the watch, immediately stop using it and contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Juboos
Model Number	6123
ASIN	B0CZDBWP2Y
Water Resistance	5 ATM / 50 Meters (164 feet)
Movement	Quartz
Display Type	Analog
Special Features	7-Color LED Light, Easy-to-Read Dial
Battery Type	1 Lithium Metal battery (included)
Dial Case Thickness	1.7 cm / 0.67 in
Product Weight	34g / 0.07 lb
Minimum Wrist Fit	12.5 cm / 4.92 in
Maximum Wrist Fit	18.5 cm / 7.28 in



Dial Case Thickness:
1.7cm/0.67in



Product Weight:
34g/0.07lb



Detailed dimensions and weight of the Juboos Kid's Analog Watch.

WARRANTY AND SUPPORT

For any questions, concerns, or warranty inquiries regarding your Juboos Kid's Analog Watch, please contact Juboos customer support through the retailer's platform or visit the official Juboos brand store. Please retain your proof of purchase for warranty claims.

You can visit the Juboos Store for more information: [Juboos Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CZDBWP2Y>

More documents and user manuals: <https://manuals.plus/>