

[Manuals.plus](#) /

› [Pafolo](#) /

› Pafolo Whack-A-Mole Game Toy User Manual

Pafolo MG02

Pafolo Whack-A-Mole Game Toy User Manual

Model: MG02

INTRODUCTION

Thank you for purchasing the Pafolo Whack-A-Mole Game Toy. This manual provides important information for the safe and proper use of your new toy. Please read it thoroughly before use and keep it for future reference.



Image: The Pafolo Whack-A-Mole Game Toy in use by two children, demonstrating the interactive play experience.

SAFETY WARNINGS

WARNING: This product contains small parts and is not suitable for children under 12 months due to choking hazards. Adult supervision is recommended during play.

- Always ensure batteries are inserted correctly with the correct polarity.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the toy will not be used for an extended period.
- Keep the toy away from water and excessive moisture.
- Do not attempt to disassemble or modify the toy.

PACKAGE CONTENTS

- 1 x Pafolo Whack-A-Mole Game Board
- 2 x Ergonomic Hammers
- 1 x User Manual (this document)



Image: Overview of the product components and their approximate dimensions.

SETUP

Battery Installation

1. Locate the battery compartment on the underside of the game board.
2. Using a screwdriver (not included), open the battery compartment cover.
3. Insert the required batteries (not included) according to the polarity indicators (+/-) inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

Placement

Place the game board on a flat, stable surface. The toy features stable suction cups on the bottom to prevent slipping during play.



Image: Key features of the game, including the stable suction cups for secure placement.

OPERATING INSTRUCTIONS

Power On/Off and Volume Control

Locate the power buttons on the side of the game board:

- **Power ON (low volume):** Press this button to turn on the toy with a lower sound level.
- **Power ON (high volume):** Press this button to turn on the toy with a higher sound level.
- **Power Off:** Press this button to turn off the toy.

Game Modes

The Pafolo Whack-A-Mole Game Toy offers three exciting game modes:

- **Single Mode:** Designed for solo play, allowing one player to practice their hitting skills. (10 balls available)
- **PK Mode:** For two players to compete against each other. (Fingers can be used if more kids join in)

- **Color Recognition Mode:** A single or teamwork mode where multiple kids can play. This mode is more difficult and challenging, focusing on color identification.

Playing the Game

Once powered on and a mode is selected, lights will illuminate on the game board. Use the ergonomic hammers to hit the illuminated buttons. The game tracks your hits and progress.



Image: Detailed view of the game board controls and their functions.

3 GAME MODES

For solo practice & multi-kid Family interaction



Image: Explanation of the three available game modes for different play experiences.

Educational Benefits

Playing the Pafolo Whack-A-Mole game can help develop several skills:

- **Manual Ability:** Improves fine motor skills and hand dexterity.
- **Teamwork:** Encourages cooperative play in multi-player modes.
- **Hand-Eye-Brain Coordination:** Enhances the connection between visual input and motor response.
- **Concentration:** Helps improve focus and attention during gameplay.



Image: Visual representation of the developmental benefits of playing the game.

MAINTENANCE

- **Cleaning:** Wipe the toy with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Toy does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity. Replace with new batteries.

Problem	Possible Cause	Solution
Lights are dim or sound is distorted.	Low battery power.	Replace all batteries with new ones.
Buttons are unresponsive.	Obstruction or internal issue.	Ensure no debris is lodged around buttons. If problem persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	MG02
Dimensions (L x W x H)	28 x 24.99 x 6 cm
Weight	690 grams
Recommended Age	12 months - 6 years
Number of Players	2 years and up
Main Material	PVC
Color	Blue
Batteries Required	Yes (not included)
Educational Value	Early childhood education and development

WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your Pafolo Whack-A-Mole Game Toy, please contact our customer service team. While specific warranty details are not provided in this manual, we are committed to ensuring your satisfaction.

Please refer to your purchase receipt or the retailer's website for information on return policies and warranty coverage.

Manufacturer: Pafolo

ASIN: B0CZDDJ6TM

