

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OnePlus](#) /

› [OnePlus Nord CE3 CPH2569 5G Smartphone User Manual](#)

## OnePlus CPH2569

# OnePlus Nord CE3 CPH2569 5G Smartphone User Manual

Model: CPH2569

## INTRODUCTION

---

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your OnePlus Nord CE3 CPH2569 5G smartphone. Please read this guide thoroughly to ensure proper usage and to maximize your device's performance and longevity.

### What's in the Box:

- OnePlus Nord CE3 CPH2569 Smartphone
- USB Cable
- (Other accessories may vary by region)

Qualcomm  
Snapdragon  
782G




Sony  
IMX890

50MP Sony IMX890 Camera System



120Hz Fluid  
AMOLED  
Display



5,000mAh  
Battery +  
80W SUPERVOOC



Two Speakers. Bigger Immersion



Image: Front and back view of the OnePlus Nord CE3 CPH2569 smartphone.

## SETUP

### 1. SIM Card Installation

The OnePlus Nord CE3 CPH2569 supports Dual SIM functionality. It also features a shared SIM slot for microSDXC expansion. Ensure your SIM cards are compatible with GSM networks. This smartphone is **not compatible** with CDMA networks (e.g., Verizon, Sprint, US Cellular).

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejector tool into the small hole next to the tray to open it.
3. Place your Nano-SIM cards into the designated slots. If using a microSD card for storage expansion, place it in the shared slot.
4. Carefully reinsert the tray into the phone.

### 2. Initial Power On and Configuration

1. Press and hold the Power button until the OnePlus logo appears.
2. Follow the on-screen instructions to select your language, connect to a Wi-Fi network, and set up your Google account.

3. Configure security features such as fingerprint unlock or facial recognition.

### 3. Charging the Device

Your device is equipped with a 5000mAh battery and supports 80W SUPERVOOC fast charging. Use the provided USB cable and a compatible power adapter for optimal charging speed.

- Connect the USB cable to the charging port on your phone.
- Connect the other end of the USB cable to a power adapter and plug it into a wall outlet.
- The charging indicator will appear on the screen.



A lightning bolt icon is positioned to the left of the phone. Below it, the text "A day's power in 15 minutes" is written in a white, handwritten-style font. The phone's screen shows a green and blue abstract background with a large white circle in the center containing the text "61.00%" and "SUPERVOOC 80W" below it. The phone is connected to a red USB-C cable.

**5,000 mAh Battery + 80W SUPERVOOC**  
Boost the 5,000 mAh equivalent battery up to a day's power in 15 minutes with 80W SUPERVOOC fast charging.

Image: OnePlus Nord CE3 connected to an 80W SUPERVOOC charger, showing fast charging capability.

## OPERATING YOUR SMARTPHONE

---

### 1. User Interface and Navigation

Your OnePlus Nord CE3 runs on Android 13 with OxygenOS 13.1. Navigate the interface using gestures or on-screen buttons. Swipe up from the bottom to access the app drawer, swipe down from the top for notifications and quick settings.

## 2. Display Features

The device features a 6.7-inch Fluid AMOLED display with 1B colors and a resolution of 1080 x 2412 pixels, supporting a 120Hz refresh rate for smooth visuals.

### 17.02cm 120 Hz Fluid AMOLED Display

Get stunning views and ultra-responsive taps and swipes with this big 120 Hz AMOLED display.




Image: The vibrant 120Hz Fluid AMOLED display of the OnePlus Nord CE3.

## 3. Camera Usage

The OnePlus Nord CE3 is equipped with a versatile camera system:

- **Rear Cameras:** 50MP main sensor, 8MP ultra-wide, and 2MP macro lens.
- **Front Camera:** 16MP for selfies and video calls.

Open the Camera app to access various modes like Photo, Video, Portrait, and more. Tap to focus, pinch to zoom, and use the on-screen shutter button to capture images or start recording.

A detailed, angled view of the internal camera module of a smartphone. The central component is a large, square sensor with a vibrant, multi-colored gradient (blue, green, yellow, orange, red, purple) across its surface. To the right of the sensor are two camera lenses of different sizes, with the larger one being the primary lens. Various electronic components, including capacitors and connectors, are visible on the surrounding circuit board.

# Sony IMX890

## **50 MP Sony IMX890 Camera System**

This flagship-level camera is all you need to shoot bright, clear, and colorful photos and videos.

Image: Detailed view of the Sony IMX890 Camera System on the OnePlus Nord CE3.

#### **4. Performance and Storage**

Powered by the Qualcomm Snapdragon 782G (6 nm) Octa-core processor and 12GB of RAM, the device offers smooth multitasking and gaming. It comes with 256GB of internal storage, expandable via microSDXC using the shared SIM slot.

# Qualcomm Snapdragon 782G Chipset

This fast, power-saving Snapdragon chipset makes everything from gaming to image processing effortless.



Image: Internal view highlighting the Qualcomm Snapdragon 782G Chipset.

## MAINTENANCE

---

### 1. Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Avoid using harsh chemicals or abrasive materials that could damage the finish.
- Keep ports free of dust and debris.

### 2. Battery Care

- Avoid exposing the phone to extreme temperatures (hot or cold) as this can degrade battery life.
- For optimal battery health, try to keep the charge level between 20% and 80% when possible, though full charges are safe with modern battery management.
- Use only official or certified charging accessories.

### 3. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to *Settings > About device > OxygenOS version* to check for updates.

## TROUBLESHOOTING

---

### Common Issues and Solutions:

- **Device not powering on:** Ensure the battery is charged. Connect to a charger for at least 15 minutes, then try powering on again.
- **Network connectivity issues:** Check if SIM cards are properly inserted. Verify network settings (*Settings > Mobile network*). Restart the device. Ensure your network provider supports GSM frequencies.
- **Slow performance:** Close unused apps. Clear cache (*Settings > Apps > App management > [App Name] > Storage usage > Clear cache*). Restart the device. Consider a factory reset as a last resort (*Settings > System settings > Back up and reset > Reset phone > Erase all data*).
- **App crashes:** Update the app from the Google Play Store. Clear the app's cache and data. Reinstall the app.

If you encounter persistent issues, please refer to the official OnePlus support website or contact customer service for further assistance.

## SPECIFICATIONS

---

Feature	Detail
Model Name	OnePlus Nord CE3
Item Model Number	CPH2569
Brand	OnePlus
Operating System	Android 13.0, OxygenOS 13.1
Processor	Qualcomm Snapdragon 782G (6 nm) Octa-core (1x2.7 GHz Cortex-A78 & 3x2.4 GHz Cortex-A78 & 4x1.8 GHz Cortex-A55), Adreno 642L
RAM Memory Installed Size	12 GB
Memory Storage Capacity	256 GB (expandable via microSDXC, uses shared SIM slot)
Standing Screen Display Size	6.7 Inches Fluid AMOLED
Resolution	1080 x 2412 pixels
Refresh Rate	120 Hz
Rear Camera	50MP + 8MP + 2MP
Front Camera	16MP
Battery Capacity	5000 Milliamp Hours (non-removable)
Charging	80W SUPERVOOC Fast Charging

Feature	Detail
Connectivity Technologies	4G LTE, 5G, Cellular
Wireless Communication Technologies	Cellular
GPS	True
Audio Jack	3.5 mm
Form Factor	Slate
Color	Gray Shimmer
Item Weight	1.14 pounds
Package Dimensions	7.24 x 3.94 x 2.44 inches
Manufacturer	OnePlus
Date First Available	July 30, 2024

## WARRANTY AND SUPPORT

---

For detailed warranty information, please refer to the warranty card included with your product or visit the official OnePlus website. For technical support, software updates, and additional resources, please visit the official OnePlus support page: [OnePlus Official Support](#)