TVON UT3004

TVON Universal TV Stand Instruction Manual

Model: UT3004

1. Introduction

Thank you for choosing the TVON Universal TV Stand. This stand is designed to provide a stable and adjustable base for your television, accommodating a wide range of TV sizes and VESA patterns. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.

Important Safety Information

- Do not exceed the maximum load capacity of 68 kg (150 lbs).
- Ensure your TV's VESA pattern is within the supported range (200x200mm to 800x600mm).
- Always assemble the stand on a flat, stable surface.
- Use all provided hardware. Do not substitute parts.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support.
- Keep children and pets away during assembly.
- Periodically check all connections to ensure they remain secure.

2. Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. Refer to the diagram for visual identification of parts.



Figure 2.1: Main components and accessories of the TV stand.

- Base Feet (2)
- Vertical Support Columns (2)
- TV Mounting Brackets (2)
- Crossbar/Soundbar Support (1)
- Hardware Kit (various screws, washers, nuts, spacers)
- Cable Management Clips
- Non-Slip Pads
- Leg Plugs
- Soundbar Isolation Pads

3. Setup and Assembly

Follow these steps carefully to assemble your TVON Universal TV Stand.

Step-by-Step Assembly

1. **Attach Base Feet to Vertical Support Columns:** Securely fasten the base feet to the bottom of the vertical support columns using the provided screws. Ensure the columns are oriented correctly for stability.
2. **Install Crossbar/Soundbar Support:** Attach the crossbar to the vertical support columns at the desired height. This bar provides additional stability and can serve as a platform for a soundbar.
3. **Prepare TV Mounting Brackets:** Identify the correct screws and spacers for your TV's VESA mounting holes. Attach the TV mounting brackets to the back of your television. Ensure the brackets are level and securely fastened.



Figure 3.1: TV compatibility and VESA range.

4. **Mount TV onto Stand:** Carefully lift the TV with the attached brackets and hook them onto the vertical support columns. Ensure the TV is centered and level. Secure the TV to the stand using the safety screws or locking mechanisms on the brackets.



Figure 3.2: Rear view of TV mounted on the stand.

5. **Adjust Height (Optional):** The stand offers 6 levels of height adjustment. To adjust the height, remove the TV from the stand, reposition the TV mounting brackets on the vertical support columns to the desired level, and then re-mount the TV. Each level adjusts the TV height by approximately 45mm.



Figure 3.3: Six levels of height adjustment.



Figure 3.4: Specific height measurements at different levels.

6. **Apply Non-Slip Pads and Leg Plugs:**Attach the non-slip pads to the bottom of the base feet to prevent scratching surfaces and improve stability. Insert leg plugs into any open ends of the stand components for a finished look.
7. **Utilize Cable Management:** Use the provided cable management clips to route and organize TV cables along the back of the vertical support columns, ensuring a tidy appearance.
8. **Place Soundbar (Optional):** If using a soundbar, place it on the crossbar support. For enhanced audio quality and vibration dampening, use the included soundbar isolation pads between the soundbar and the crossbar.



Figure 3.5: Soundbar isolation pads in use.

4. Operating the Stand

Once assembled, the TVON Universal TV Stand provides a stable platform for your television. Its primary operational feature is height adjustment.

Height Adjustment

The stand allows for 6 distinct height settings to optimize your viewing experience. To change the height:

1. Carefully remove the television from the mounting brackets. It is recommended to have assistance for this step.
2. Unscrew or unlatch the TV mounting brackets from the vertical support columns.
3. Slide the brackets up or down to align with the desired height level holes on the columns.
4. Securely re-fasten the brackets at the new height.
5. Carefully re-mount the television onto the brackets, ensuring it is properly seated and secured.

Cable Management

Utilize the integrated cable management clips on the rear of the vertical columns to keep your cables organized and out of sight. This helps maintain a clean and clutter-free entertainment area.

5. Maintenance

Regular maintenance ensures the longevity and continued stability of your TV stand.

- **Cleaning:** Wipe the stand with a soft, dry cloth. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by drying thoroughly. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and connections to ensure they are tight and secure. Over time, vibrations or movement can cause fasteners to loosen.
- **Damage:** If any part of the stand becomes bent, cracked, or otherwise damaged, discontinue use immediately and contact customer support for replacement parts or advice.

6. Troubleshooting

This section addresses common issues you might encounter with your TV stand.

Common Issues and Solutions

- **Stand is Wobbly:**
  - Ensure all screws are tightened securely.
  - Verify the stand is on a flat, level surface.
  - Check that the non-slip pads are properly applied to the base feet.
- **TV Does Not Fit the Brackets:**
  - Confirm your TV's VESA pattern is within the supported range (200x200mm to 800x600mm).
  - Ensure you are using the correct screws and spacers from the hardware kit for your TV's specific mounting holes.
- **Missing or Damaged Parts:**
  - Review the 'Package Contents' section and compare with received items.
  - Contact TVON customer support immediately for assistance. Do not attempt to assemble with missing or damaged parts.

7. Specifications

Feature	Detail
Brand	TVON
Model Number	UT3004
Compatible TV Sizes	37 - 86 inches

Maximum Load Capacity	68 kg (150 lbs)
VESA Compatibility (Min)	200mm x 200mm
VESA Compatibility (Max)	800mm x 600mm
Height Adjustment Levels	6 levels
Material	Thick high-strength steel
Design Features	Triangular structure for stability, Cable Management, Non-Slip Pads, Soundbar Isolation Pads



Figure 7.1: Ultra-stable design features.

8. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact TVON customer service directly. Keep your purchase receipt as proof of purchase.
For further assistance, please visit the official TVON website or contact their customer support line.

© 2024 TVON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question