

Rohnson R-1219

Rohnson R-1219 2-in-1 Vertical & Portable Vacuum Cleaner Instruction Manual

1. INTRODUCTION

Thank you for choosing the Rohnson R-1219 2-in-1 Vertical & Portable Vacuum Cleaner. This appliance is designed for efficient cleaning of various surfaces in your home. Please read this manual carefully before operating the vacuum cleaner to ensure safe and proper use. Keep this manual for future reference.

2. SAFETY INSTRUCTIONS

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not immerse the motor unit, power cord, or plug in water or other liquids.
- Always unplug the vacuum cleaner from the power outlet before cleaning, maintenance, or when not in use.
- This appliance is for household use only. Do not use it outdoors or for commercial purposes.
- Do not pick up flammable or combustible materials, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the vacuum cleaner with a damaged cord or plug. Contact qualified service personnel for repair.
- Children should be supervised to ensure they do not play with the appliance.

3. PACKAGE CONTENTS

Verify that all components are present and in good condition upon unpacking:

- Main Motor Unit (Handheld Vacuum)
- Extension Tube
- Motorized Floor Brush with LED lights
- 2-in-1 Brush (combination tool)
- Crevice Nozzle

- Wall Mount Base
- Instruction Manual
- 2 Floor and Carpet Rollers (pre-installed or spare)



Image: Included accessories, showing the 2-in-1 brush and crevice nozzle.

4. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your Rohnson R-1219 vacuum cleaner:

1. Handle with Power Button
2. Dust Cup
3. HEPA Filter Assembly
4. Extension Tube Release Button
5. Extension Tube
6. Motorized Floor Brush
7. LED Headlights (on floor brush)
8. Brush Roll Release Latch



Image: The Rohnson R-1219 vacuum cleaner assembled in its vertical stick configuration.

5. SETUP AND ASSEMBLY

Follow these steps to assemble your vacuum cleaner:

1. **Attach the Extension Tube:** Insert the extension tube into the main motor unit until it clicks securely into place.
2. **Attach the Floor Brush:** Connect the motorized floor brush to the other end of the extension tube, ensuring it locks firmly.
3. **For Handheld Use:** To use as a portable vacuum, detach the extension tube and floor brush by pressing their respective release buttons. Attach the desired accessory (2-in-1 brush or crevice nozzle)

directly to the main motor unit.

4. **Wall Mount Installation:** Choose a suitable location for the wall mount base. Secure it to the wall using appropriate screws and anchors (not included). Ensure it is at a convenient height for storing the vacuum.

6. OPERATING INSTRUCTIONS

6.1 Vertical Mode

1. Ensure the vacuum is fully assembled in vertical mode.
2. Plug the power cord into a suitable electrical outlet. The 6-meter cord provides a 7-meter cleaning radius.
3. Press the power button located on the handle to turn on the vacuum cleaner. The LED lights on the floor brush will illuminate.
4. Guide the vacuum cleaner over the desired surfaces. The motorized brush is effective on both carpets and hard floors.
5. When finished, press the power button again to turn off the vacuum and unplug it from the outlet.



Image: The motorized floor brush of the Rohnson R-1219 vacuum cleaner in action on a hard floor.

6.2 Portable Mode

1. Detach the extension tube and floor brush from the main motor unit.
2. Attach either the 2-in-1 brush or the crevice nozzle directly to the main motor unit.
3. Plug the power cord into an electrical outlet.
4. Press the power button to turn on the handheld vacuum.
5. Use the handheld unit for cleaning upholstery, car interiors, stairs, or tight spaces.
6. After use, turn off the vacuum and unplug it.



Image: The Rohson R-1219 vacuum cleaner used in handheld mode to clean a sofa.

7. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

7.1 Emptying the Dust Cup

1. Ensure the vacuum cleaner is unplugged.
2. Press the dust cup release button and remove the dust cup from the main motor unit.

3. Open the dust cup and empty its contents into a waste bin.
4. Reattach the dust cup to the main motor unit until it clicks securely.

7.2 Cleaning the Filters

The Rohnson R-1219 features a washable HEPA filter. Clean regularly for best suction.

1. Unplug the vacuum cleaner.
2. Remove the dust cup as described above.
3. Carefully remove the HEPA filter and its protective mesh from the dust cup.
4. Rinse the HEPA filter and mesh under cold running water until the water runs clear. Do not use detergents.
5. Allow the filters to air dry completely for at least 24 hours before reassembling. Do not use a dryer or heat to dry them.
6. Once completely dry, reinsert the filters into the dust cup and reattach the dust cup to the vacuum.



Image: The washable HEPA filter and mesh filter being cleaned with water.

7.3 Cleaning the Brush Roll

1. Unplug the vacuum cleaner.
2. Turn the motorized floor brush upside down.
3. Locate the brush roll release latch and open it to remove the brush roll.
4. Remove any tangled hair, threads, or debris from the brush roll using scissors or a brush.
5. Reinsert the clean brush roll and secure the latch.



Image: A close-up view of the motorized brush roll.

8. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Not plugged in; Power outlet fault; Damaged cord/plug	Check plug connection; Test outlet with another appliance; Contact service for inspection.
Low suction power	Dust cup full; Filters clogged; Blockage in nozzle/tube/brush; Brush roll tangled	Empty dust cup; Clean filters; Remove any blockages; Clean brush roll.
Motorized brush not rotating	Brush roll tangled; Connection issue; Motor fault	Clean brush roll; Ensure floor brush is securely attached; Contact service if problem persists.
Unusual noise	Blockage; Damaged part; Motor issue	Check for and remove blockages; Contact service for inspection.

9. SPECIFICATIONS

Brand	Rohnson
Model Number	R-1219
Power	700 Watts
Voltage	240 Volts
Dust Cup Capacity	0.6 Liters
Cable Length	6 meters
Cleaning Radius	7 meters
Filter Type	HEPA (Washable)
Noise Level	78 dB
Product Dimensions (L x W x H)	120 x 10 x 120 cm

Item Weight	3 Kilograms
Recommended Surface	All floors
Power Source	Corded Electric

10. STORAGE

The Rohnsen R-1219 is designed for compact storage. After use, unplug the vacuum cleaner and store it on its wall mount base to save space. Ensure the dust cup is empty and filters are clean before storing for extended periods.



Image: The Rohnsen R-1219 vacuum cleaner conveniently stored on its wall mount.

11. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were provided in the product data for embedding in this manual.

Related Documents - R-1219

<div data-bbox="151 371 271 414">Rohnson® Handheld Vacuum Cleaner</div> <div data-bbox="172 425 229 434">Model: R-1219</div> <div data-bbox="177 445 268 537"></div> <div data-bbox="158 568 247 580">INSTRUCTION MANUAL</div>	<p>Rohnson R-1219 Handheld Vacuum Cleaner Instruction Manual</p> <p>Instruction manual for the Rohnson R-1219 Handheld Vacuum Cleaner, providing detailed guidance on safe operation, assembly, cleaning, maintenance, and troubleshooting.</p>
<div data-bbox="151 687 271 730">Rohnson®</div> <div data-bbox="186 723 237 750">VACUUM CLEANER MODEL: R-1555</div> <div data-bbox="186 757 237 763">INSTRUCTION MANUAL</div> <div data-bbox="177 768 244 864"></div> <div data-bbox="162 869 260 875">POWER PROTECTION MANUAL, CORDLESS VACUUM CLEANER READ AND FOLLOW INSTRUCTIONS CAREFULLY</div> <div data-bbox="177 896 247 904">Power: 200W Voltage: 220-240V 50/60Hz</div>	<p>Rohnson R-1555 Vacuum Cleaner Instruction Manual</p> <p>Official instruction manual for the Rohnson R-1555 vacuum cleaner. Learn about safety precautions, operating instructions, maintenance procedures, filter cleaning, and proper disposal guidelines.</p>
<div data-bbox="201 992 284 1001">Číslo návodní příručky: R-1239 85</div> <div data-bbox="162 1012 260 1061">Rohnson: Návod k použití CYKLONOVÝ TYČOVÝ VYSÁVAČ R-1239</div> <div data-bbox="154 1068 266 1180"></div> <div data-bbox="132 1187 293 1202">Před použitím pečlivě seznámte s průběhem obsluhy, instalací a údržbou. Nejprve si přečtěte všechny pokyny v tomto návodu. Uložte si návod pro budoucí použití.</div>	<p>Rohnson R-1239 Cyclonic Stick Vacuum Cleaner User Manual</p> <p>User manual for the Rohnson R-1239 cyclonic stick vacuum cleaner, providing instructions for use, safety precautions, maintenance, and troubleshooting.</p>
<div data-bbox="201 1308 284 1317">Titel et numéro de manuel: R-1239 83</div> <div data-bbox="162 1328 260 1377">Rohnson: Návod k použití TYČOVÝ CYKLONOVÝ VYSÁVAČ R-1239</div> <div data-bbox="154 1384 266 1494"></div> <div data-bbox="132 1503 293 1518">Před použitím pečlivě seznámte s průběhem obsluhy, instalací a údržbou. Nejprve si přečtěte všechny pokyny v tomto návodu. Uložte si návod pro budoucí použití.</div>	<p>Rohnson R-1239 Stick Vacuum Cleaner User Manual</p> <p>User manual for the Rohnson R-1239 stick vacuum cleaner, providing instructions on use, safety, maintenance, and troubleshooting.</p>
<div data-bbox="162 1624 260 1657">Rohnson® INNOVATE FOR LIFE</div> <div data-bbox="138 1664 292 1809"></div> <div data-bbox="142 1816 284 1823">Thank you for buying a Rohmson cordless stick vacuum cleaner with digital navigation system (DNC).</div> <div data-bbox="154 1836 266 1868"> MAMBA pro Mamba pro cordless stick vacuum cleaner to find out more about your machine</div>	<p>Rohnson Mamba Pro M8 Cordless Stick Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the Rohnson Mamba Pro M8 cordless stick vacuum cleaner, detailing setup, operation, maintenance, troubleshooting, and specifications.</p>



[Rohnson R-1223 Bagless Cyclone Vacuum Cleaner Instruction Manual](#)

Comprehensive instruction manual for the Rohnson R-1223 Bagless Cyclone Vacuum Cleaner, covering safety instructions, components, preparation, usage, maintenance, and disposal guidelines.