HOZEREEL 004

HOZEREEL 150 FT x 1/2" Retractable Garden Hose Reel Instruction Manual

Model: 004

1. Introduction and Overview

Thank you for choosing the HOZEREEL 150 FT x 1/2" Retractable Garden Hose Reel. This manual provides essential information for the safe and efficient use of your new garden tool. Designed for convenience and durability, this hose reel features an automatic self-retract system, a robust wall-mount design, and a versatile 10-pattern nozzle to simplify your watering tasks.
Key features include:

- **Space & Time Saver:** The self-rewind system makes watering effortless, saving time and effort.
- **Tidy Looking in Yard:** A guide mechanism evenly distributes the hose, keeping your yard organized.
- **Cover A Large Space:** The 180-degree pivot bracket allows extensive coverage across your garden.
- **Heavy Duty for Long Term Using:** Constructed with a hybrid hose and brass fittings for durability.



Image: Man effortlessly pulling the hose from the HOZEREEL unit, highlighting its time and energy-saving design.

Video: An overview of the HOZEREEL brand, showcasing various hose reel models and their benefits for garden maintenance.

2. Safety Information

- Always read and understand all instructions before installation and use.
- Ensure the mounting surface is strong enough to support the weight of the hose reel when full of water.
- Do not allow the hose to retract unsupervised or at high speed, as this may cause injury or damage to the unit. Always guide the hose during retraction.
- Do not drink water from the hose unless explicitly stated as potable.
- Keep children and pets away from the hose reel during operation and retraction.
- Drain the hose completely before freezing temperatures to prevent damage.

3. Package Contents

Your HOZEREEL 150 FT x 1/2" Retractable Garden Hose Reel package includes:

- 1 x HOZEREEL Retractable Hose Reel (with 150 FT x 1/2" hose pre-installed)
- 1 x Wall Mount Bracket
- 1 x Set of Mounting Hardware (screws, anchors)
- 1 x 10-Pattern Spray Nozzle
- 1 x Additional Spray Nozzle
- 1 x Weather Cover
- 1 x Instruction Manual with Mounting Template

4. Setup and Installation

The HOZEREEL is designed for easy wall mounting. Follow these steps for secure installation:

1. **Choose Location:** Select a sturdy wall or post near your water source. For optimal stability, identify wall studs using a stud finder if mounting to siding.
2. **Use Template:** Utilize the provided sticky-back mounting template to mark the drill holes accurately.
3. **Drill Holes:** Drill pilot holes at the marked locations. For masonry surfaces (brick/concrete), use appropriate masonry drill bits and anchors (note: some users recommend purchasing heavy-duty masonry anchors separately for increased security).
4. **Mount Bracket:** Securely attach the wall mount bracket using the provided screws.
5. **Attach Hose Reel:** Lift the hose reel unit and slide it onto the mounted bracket. The design allows for easy attachment and removal.
6. **Connect to Water:** Connect the short leader hose from the reel to your outdoor spigot. Ensure all connections are tight to prevent leaks.



Image: A man demonstrating the easy installation process of the HOZEREEL mounting bracket on a wooden post.



Image: Various installation methods for the HOZEREEL, showcasing its versatility for mounting on walls or posts.

5. Operating Instructions

Using your HOZEREEL is straightforward and efficient:

1. **Pulling Out the Hose:** Gently pull the hose to the desired length. The hose will smoothly extend without kinking.
2. **Locking Mechanism:** The hose features an any-length lock system. Pull the hose out and stop; it will automatically lock in place.
3. **Retracting the Hose:** To retract, give the hose a short, gentle tug. The automatic rewind system will engage, smoothly guiding the hose back into the reel. **Important:** Always guide the hose during retraction to prevent damage to the internal spring mechanism and ensure safe operation. Do not let the hose snap back freely.
4. **180-Degree Pivot:** The wall mount allows the reel to pivot 180 degrees, enabling you to reach all areas of your garden without straining the unit or the hose.
5. **Using the Nozzle:** Attach one of the provided nozzles to the end of the hose. The 10-pattern nozzle offers various spray options for different watering needs. Adjust the spray pattern by rotating the nozzle head.

Time and Energy Saver



Image: A man extending the HOZEREEL garden hose from its wall-mounted reel, demonstrating the smooth pull-out action.

SMOOTH

AUTO-RETRACT SYSTEM

Makes Automatic Tidy Possible



600PSI

Bursting Pressure

200PSI

Working Pressure

Image: An internal view of the smooth auto-retract system, highlighting the 600 PSI bursting pressure and 200 PSI working pressure.




Image: Features of the HOZEREEL, including a 180-degree rotating wall mount, shift-lock mechanism, durable bracket, and a 10-pattern adjustable spray nozzle.

Video: A demonstration of the HOZEREEL retractable hose reel in action, showing how to pull out and retract the hose smoothly.

6. Maintenance

To ensure the longevity and optimal performance of your HOZEREEL, follow these maintenance tips:

- **Cleaning:** The hose has a smooth, glossy finish that is easy to wash off dirt and mud. Regularly wipe down the hose and casing to keep it clean.
- **Weather Protection:** Use the provided weather cover to protect the hose reel from harsh weather conditions,

especially during extreme temperatures or prolonged periods of non-use. The casing is UV-stabilized for added durability.

- **Winterization:** Before the first freeze, disconnect the hose reel from the water source, drain all water from the hose, and store the unit indoors in a frost-free environment.
- **Check Connections:** Periodically inspect all hose connections for tightness and signs of wear. Replace worn washers as needed.



Image: Close-up of the HOZEREEL's UV-stabilized casing, emphasizing its resistance to fading and weather elements.



Image: The HOZEREEL unit keeps the garden hose organized and tidy, preventing tangles and clutter.

7. Troubleshooting

Problem	Possible Cause	Solution
Hose does not retract fully or smoothly.	Hose is kinked or tangled inside the reel; debris in mechanism; spring issue.	Pull out the entire hose and inspect for kinks. Ensure the hose is clean. Gently tug the hose to re-engage the retraction mechanism. If issues persist, contact customer support.

Problem	Possible Cause	Solution
Water leaks from connections.	Loose connections; worn washers; damaged hose.	Tighten all connections. Replace rubber washers if they are worn or cracked. Inspect the hose for any visible damage.
No water flow or low pressure.	Spigot is off; hose is kinked; nozzle is blocked.	Ensure the water spigot is fully open. Check the hose for kinks. Clean the nozzle for any blockages.

8. Specifications

- **Brand:** HOZEREEL
- **Model Number:** 004
- **Hose Length:** 150 FT
- **Hose Diameter:** 1/2"
- **Material:** Polypropylene (casing), Hybrid Hose, Brass Fittings
- **Color:** Grey
- **Item Dimensions (L x W x H):** 25.6 x 10.4 x 19.1 inches
- **Item Weight:** 38 Pounds
- **Operation Mode:** Automatic
- **Working Pressure:** 200 PSI
- **Bursting Pressure:** 600 PSI
- **Mounting:** Wall-mounted with 180-degree pivot bracket
- **Nozzle:** 10 adjustable spray modes



Image: Detailed dimensions of the HOZEREEL retractable hose reel for installation planning.



Image: Man watering his garden, illustrating the advanced structural design and increased water flow of the HOZEREEL.



Image: An illustration detailing the advanced structural design of the HOZEREEL hose reel.

9. Warranty and Support

HOZEREEL offers a leading **2-YEARS Service** for this product. If you encounter any unexpected issues or require a replacement, please feel welcome to contact HOZEREEL customer support. For further assistance, visit the official HOZEREEL store on Amazon.

Visit the HOZEREEL Store

© 2026 HOZEREEL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question