

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Aroepurt](#) /

› [Aroepurt Slim Case for Ziovo Z128 11-inch Tablet with Stand Flap - Instruction Manual](#)

Aroepurt OZ-P347-254 DTG

Aroepurt Slim Case for Ziovo Z128 11-inch Tablet with Stand Flap

Model: OZ-P347-254 DTG | Brand: Aroepurt

INTRODUCTION

Thank you for choosing the Aroepurt Slim Case for your Ziovo Z128 11-inch tablet. This case is designed to provide protection and enhance the usability of your device with its integrated stand feature. Please read this manual carefully to ensure proper installation and optimal use of your new tablet case.



Image: The Aroepurt Slim Case, showcasing its design and compatibility with the Ziovo Z128 11-inch tablet.

PRODUCT FEATURES

- **Four Corner Protection:** Designed to minimize the risk of damage from drops and impacts.
- **Magnetic Closure:** Side magnets ensure easy and secure closure, keeping your tablet protected when not in use.
- **Slim and Lightweight Design:** Engineered through a tension process to be thin and light, adding minimal bulk to your tablet.
- **Vibrant Inkjet Pattern:** Features an exquisite inkjet pattern that remains bright and resistant to fading over time.
- **Integrated Stand Function:** Allows the tablet to be used in a standing position for comfortable viewing or typing.
- **No Keyboard Slot:** Please note that this case does not include a dedicated slot for a keyboard.

ALL-OVER PROTECTION

Goes into every side & corner



Device ports, speakers, buttons all work fine



Slim & Lightweight



Image: Illustration highlighting the all-over protection and slim, lightweight design of the case.

SETUP INSTRUCTIONS

1. **Prepare Your Tablet:** Ensure your Ziovo Z128 11-inch tablet is clean and free of dust or debris.
2. **Align the Tablet:** Gently align your tablet with the case, ensuring the camera, ports, and buttons match the cutouts on the case.
3. **Insert the Tablet:** Carefully push the tablet into the case, starting with one side and then the other, until all four corners are securely seated within the protective frame.
4. **Check Fit:** Verify that the tablet is snug and secure within the case and that all ports and buttons are accessible and functional.

OPERATING INSTRUCTIONS

Using the Stand Feature

The case features a foldable flap that allows you to position your tablet at two different angles for optimal viewing or typing.

1. **Viewing Angle:** Open the front flap of the case. Fold the flap backward and align it with the grooves on the back of the case to create a stable triangular stand. This angle is ideal for watching videos or making video calls.
2. **Typing Angle:** For a lower, more ergonomic typing angle, fold the flap differently, creating a shallower incline. This position is suitable for typing or drawing.

Ergonomic Structure



Built-in magnets bolster different positions.



Image: Visual guide demonstrating the ergonomic viewing and typing angles provided by the case's stand feature.

Magnetic Closure

The case is equipped with side magnets that automatically secure the front flap when closed, providing protection for your tablet screen and preventing accidental openings.

MAINTENANCE

Cleaning Your Case

To maintain the appearance and longevity of your Aroepurt Slim Case, follow these cleaning guidelines:

- Wipe the exterior with a soft, damp cloth.
- For stubborn stains, use a mild soap solution on the cloth, then wipe with a clean, damp cloth to remove any residue.

- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the material and finish.
- Allow the case to air dry completely before reinserting your tablet.

TROUBLESHOOTING

Tablet Does Not Fit

- Ensure your tablet is the correct model (Ziovo Z128 11-inch). This case is specifically designed for this model.
- Check for any obstructions or foreign objects inside the case or on your tablet that might prevent a proper fit.

Stand Function is Unstable

- Ensure the flap is correctly folded and securely seated in the designated grooves to form a stable triangle.
- Use the case on a flat, stable surface for best results.

Magnetic Closure Not Working

- Check if any debris is preventing the flap from closing completely.
- Ensure the tablet is correctly positioned within the case, as misalignment can affect magnetic contact.

SPECIFICATIONS

Feature	Detail
Brand	Aroepurt
Model Number	OZ-P347-254 DTG
Compatible Devices	Ziovo Z128 11-inch Tablet
Material	Polyurethane
Form Factor	Case
Case Type	Hybrid
Item Weight	70 g
Product Dimensions (L x W x H)	1 x 1 x 1 cm
Special Features	Anti-drop thick corner protection, foldable stand, card insertion (Note: 'Cachez le changement' is unclear and omitted)
Box Contents	1 tablet case

WARRANTY AND SUPPORT

Specific warranty information for this product may vary by region and retailer. Please refer to your purchase

documentation or contact the retailer where you purchased the product for details regarding warranty coverage.

For further assistance or inquiries, please contact Aroepurt customer support through the contact information provided by your retailer or on the official Aroepurt website, if available.