

## CF618

# Generic Universal Smart LCD Car Key Fob CF618 User Manual

## 1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Generic Universal Smart LCD Car Key Fob, model CF618. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage.

12. Lifting windows from the car (some models)

13.15 Min quick installation

14. With OBD installations

15. Standby 100 days (close comfort entry)

16. 365 days of physical keys

17. Anti-loss function

18. Fill in the owner information

19. Smart trunk reserve function.

This image displays the Universal Smart LCD Car Key Fob, model CF618, showcasing its sleek design and integrated LCD screen.

## 2. KEY FEATURES

The CF618 Smart LCD Car Key Fob offers a range of advanced features designed to enhance your vehicle access and control experience:

- **Remote Window Control:** Ability to remotely lift or lower vehicle windows (functionality may vary by car model).
- **Quick Installation:** Designed for a rapid installation process, typically completed within approximately 15 minutes.
- **OBD-II Port Installation:** Utilizes the vehicle's On-Board Diagnostics II (OBD-II) port for simplified setup.
- **Extended Standby Time:** Provides up to 100 days of standby operation when comfort entry features are disabled.
- **Integrated Physical Key Backup:** Ensures continued access to your vehicle with a physical key function.
- **Anti-Loss Tracking Function:** Helps locate the key fob if misplaced.
- **Owner Information Display:** Allows for the display of owner contact information on the LCD screen.
- **Smart Trunk Release Function:** Enables remote or smart access to the vehicle's trunk.

## 3. SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance of your CF618 Smart LCD Car Key Fob. It is recommended that installation be performed by a qualified technician.

### 3.1 Initial Charging

Before first use, fully charge the key fob using the provided USB cable. Connect the cable to the charging port on the key fob and a standard USB power adapter.

### 3.2 OBD-II Connection

1. Locate your vehicle's OBD-II port, typically found under the dashboard on the driver's side.
2. Connect the provided OBD-II module to the vehicle's OBD-II port.
3. Ensure the connection is secure.

### 3.3 Pairing with Vehicle

The pairing process may vary slightly depending on your vehicle's make and model. Generally, this involves:

1. Insert the original car key into the ignition or place it in the designated area for keyless start.
2. Follow the specific pairing instructions provided with your CF618 key fob or consult a professional installer.
3. Once paired, the LCD screen will display confirmation.

## 4. OPERATION

The CF618 Smart LCD Car Key Fob provides intuitive control over your vehicle's functions via its touch-sensitive LCD screen and physical buttons.

### 4.1 Basic Functions

- **Lock/Unlock:** Tap the respective icons on the LCD screen or use the side buttons to lock or unlock your vehicle.
- **Trunk Release:** Tap the trunk icon on the LCD screen to open the vehicle's trunk.

- **Remote Start:** If supported by your vehicle and configured, tap the remote start icon to start the engine remotely.

## 4.2 LCD Screen Navigation

Swipe left or right on the LCD screen to access different menus and functions, such as vehicle status, settings, and owner information.

## 4.3 Owner Information

To input or view owner information, navigate to the 'Owner Info' section on the LCD screen. This feature can assist in returning a lost key fob.

## 4.4 Anti-Loss Function

Activate the anti-loss function through the key fob's settings menu. This feature typically uses a connected smartphone application to help locate the key fob within a certain range.

## 5. MAINTENANCE

To ensure the longevity and optimal performance of your CF618 Smart LCD Car Key Fob, follow these maintenance guidelines:

- **Charging:** Recharge the key fob regularly. The LCD screen will display the battery level. Avoid complete discharge for extended periods.
- **Cleaning:** Use a soft, dry cloth to clean the LCD screen and the body of the key fob. Avoid abrasive cleaners or solvents.
- **Storage:** Store the key fob in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** The key fob is not waterproof. Avoid exposure to water or high humidity.

## 6. TROUBLESHOOTING

If you encounter issues with your CF618 Smart LCD Car Key Fob, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Key Fob not responding	Low battery; Not paired; Out of range	Charge the key fob; Re-pair with the vehicle; Move closer to the vehicle.
LCD screen is blank	Battery depleted; Device malfunction	Charge the key fob; If issue persists, contact support.
Vehicle not locking/unlocking	Interference; Key fob not paired; Vehicle battery low	Move away from sources of interference; Re-pair the key fob; Check vehicle battery.

If the problem persists after attempting these solutions, please contact customer support.

## 7. SPECIFICATIONS

Specification	Detail
Brand	Generic

Specification	Detail
Model Number	CF618 (Manufacturer reference: 012)
Item Weight	150 g
First Available	29 March 2024

## 8. WARRANTY AND SUPPORT

---

For warranty information, technical support, or service inquiries, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your purchase receipt as proof of purchase.