

- [Manuals.plus](#) /
- › [BoxWave](#) /
 - › BoxWave ClearTouch ImpactShield Screen Protector User Manual

BoxWave ClearTouch ImpactShield

BoxWave ClearTouch ImpactShield Screen Protector User Manual

Compatible with Xgody H30 Dash Cam

INTRODUCTION

The BoxWave ClearTouch ImpactShield is a high-quality screen protector designed to provide superior protection for your Xgody H30 Dash Cam. This flexible film offers 9H hardness, exceptional shock absorption, and maintains crystal clear visibility, ensuring your device's screen remains pristine and functional. This manual provides detailed instructions for installation, maintenance, and troubleshooting to help you get the most out of your screen protector.



Image: BoxWave ClearTouch ImpactShield screen protector packaging, showing the product and its compatibility.

KEY FEATURES

- **9H Hardness Rating:** Provides impenetrable protection against scratches, bumps, and accidental drops, ensuring the screen of your Xgody H30 Dash Cam remains protected.



ClearTouch® IMPACTSHIELD



COLOR BRILLIANCE

High-quality optical film that optimizes color rendition.



CLARITY

Your vibrant screens don't deserve blur or bland. 99% transparency means perfect clarity. No loss of color. No loss of resolution.



PRECISION

Precision cut. Precision Accuracy. Cut exactly for your device for increased touchpad accuracy and recognition.



REUSABILITY

Cleartouch® comes equipped with installation forgiveness. Reuse and reinstall as needed.





Image: Visual representation of the 9H hardness rating, indicating strong protection against impacts.

- **Shock Absorption:** Infused with a thin TPU layer to absorb shock and vibration, further safeguarding your device's screen from daily wear and tear.



Image: Diagram showing the screen protector's ability to absorb shock and protect the device.

- **Ultimate Protection:** Made with next-generation material that is strong yet flexible, guarding your screen from scratches or cracks more effectively than brittle glass protectors.



Unmatched Protection

Dual-layered high-grade PET protects your screen from scratches, fingerprints and dust.



*Image for reference only. The actual product is designed to fit the screen of your device

Image: Graphic illustrating the comprehensive protection offered by the screen protector.

- **Crystal Clear Visibility:** Provides 99% visibility with super clear material, ensuring no bulk or distortion to your screen's display.



Shatterproof Protection



Image: A close-up showing the high transparency and clarity of the screen protector.

- **Perfect Design:** Specifically designed to fit your Xgody H30 Dash Cam for a precise fit, ensuring all ports and buttons remain fully accessible.



Flexible Material

ClearTouch protects your device without chipping and cracking.



*Image for reference only. The actual product is designed to fit the screen of your device.

Image: An illustration highlighting the precise cut and perfect fit of the screen protector on a device.

SETUP: INSTALLATION GUIDE

Follow these steps carefully for optimal installation of your ClearTouch ImpactShield screen protector:

1. **Prepare Your Workspace:** Choose a clean, dust-free environment. Wash your hands thoroughly to avoid transferring oils or dirt to the screen.
2. **Clean the Device Screen:** Use the provided cleaning cloth (or a microfiber cloth) to thoroughly clean the screen of your Xgody H30 Dash Cam. Ensure there are no dust particles, smudges, or fingerprints. For stubborn marks, a screen cleaning solution can be used sparingly.
3. **Peel Off Layer 1:** Carefully peel back a small portion of the protective film labeled 'Layer 1' (or similar) from one end of the screen protector. Avoid touching the adhesive side.
4. **Align the Protector:** Align the exposed adhesive edge of the screen protector with one edge of your device's screen. Take your time to ensure precise alignment with the screen's contours, camera, and sensors.



Image: A hand carefully aligning and applying the screen protector to a device.

5. **Apply Gradually:** Slowly lower the rest of the screen protector onto the device screen, using a squeegee card (if provided) or a soft cloth to gently push out air bubbles as you go. Work from the aligned edge towards the opposite end.
6. **Remove Air Bubbles:** If bubbles remain, gently push them towards the nearest edge using the squeegee card or cloth. For persistent bubbles, you may carefully lift a corner of the protector and reapply that section.
7. **Remove Layer 2:** Once the screen protector is fully adhered and free of bubbles, carefully peel off the top protective film labeled 'Layer 2' (or similar).
8. **Final Wipe:** Give the newly installed screen protector a final gentle wipe with a clean, dry microfiber cloth.

OPERATION

The BoxWave ClearTouch ImpactShield is designed to be virtually unnoticeable once applied. It maintains the original touch sensitivity and clarity of your Xgody H30 Dash Cam's screen, allowing for seamless interaction and vibrant display. You can continue to use your device as normal, benefiting from the added layer of protection without compromising functionality.



High Definition Clarity

99.9% Color and Transparency




Image: The screen protector applied to a device, emphasizing its crystal clear quality.

MAINTENANCE

To keep your ClearTouch ImpactShield screen protector in optimal condition and ensure maximum clarity:

- **Regular Cleaning:** Gently wipe the screen protector with a clean, soft microfiber cloth to remove dust and fingerprints.
- **Stubborn Smudges:** For more persistent smudges, lightly dampen the microfiber cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials, as these can damage the protector's surface.
- **Avoid Sharp Objects:** While the protector offers significant resistance, avoid direct contact with extremely sharp objects to prolong its lifespan.

TROUBLESHOOTING

Here are some common issues and their solutions:

Problem	Solution
Bubbles After Installation	Small bubbles often disappear within 24-48 hours as the adhesive settles. For larger bubbles, gently lift the nearest edge of the protector and reapply, using a squeegee card to push the air out.
Dust Under the Protector	If dust particles are trapped, carefully lift the nearest corner of the protector. Use a piece of sticky tape to dab the dust off both the screen and the adhesive side of the protector. Reapply carefully.
Misalignment	If the protector is significantly misaligned, carefully peel it off completely. Clean the screen again thoroughly and attempt reinstallation, paying close attention to alignment. The ClearTouch ImpactShield is designed for installation forgiveness.
Reduced Touch Sensitivity	Ensure the protector is fully adhered without air gaps. If the issue persists, verify that the protector is indeed the correct model for your device.

SPECIFICATIONS

Attribute	Detail
Brand	BoxWave
Model	ClearTouch ImpactShield (2-Pack)
Compatible Device	Xgody H30 Dash Cam
Material	Polyethylene Terephthalate (PET)
Screen Surface Description	Glossy
Hardness Rating	9H
Item Weight	2.5 ounces



Designed to Fit Your Device



Precisely Manufactured




*Image for reference only. The actual product is designed to fit the screen of your device

Image: A caliper measuring a device, symbolizing the precise manufacturing and design of the screen protector.

WARRANTY AND SUPPORT

BoxWave is committed to providing high-quality accessories. For any questions, concerns, or support regarding your ClearTouch ImpactShield screen protector, please contact BoxWave customer service directly. Refer to the product packaging or the official BoxWave website for the most current contact information and warranty details.

© 2024 BoxWave Corporation. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CZG6SQ45>

More documents and user manuals: <https://manuals.plus/>