

Roku CS1000P25

Roku Indoor Camera for Home Security

Model: CS1000P25

INTRODUCTION

The Roku Indoor Camera is designed to provide reliable home security and monitoring. With 1080p HD video, color night vision, and smart detection features, you can keep an eye on your home, children, and pets from anywhere using the Roku Smart Home mobile app. This manual provides detailed instructions for setting up, operating, and maintaining your camera.

WHAT'S IN THE Box

Your Roku Indoor Camera package includes the following items:

- Roku Indoor Camera (2 units for 2-pack)
- USB charging cable
- Power adaptor
- Mounting screw




Image: Contents of the Roku Indoor Camera package, showing the camera, power adapter, USB cable, and mounting screw.

SETUP GUIDE

Follow these steps to set up your Roku Indoor Camera:

- 1. Power Connection:** Plug the USB charging cable into the camera's port and connect the power adaptor to a standard electrical outlet. The light on the front of the camera will begin flashing red, indicating it's ready for setup.



Image: A Roku Indoor Camera connected to its power cable, illustrating the simple plug-in setup.

- 2. Download the Roku Smart Home App:** Download and install the Roku Smart Home app on your smartphone (available for iOS and Android).
- 3. Add Device:** Open the app and follow the on-screen instructions to add a new device. Select