

- Manuals.plus /
- › AGARO /
- › AGARO Elite 2L Electric Sprayer Bottle User Manual

AGARO 34214

AGARO Elite 2L Electric Sprayer Bottle User Manual

Model: 34214

1. INTRODUCTION

The AGARO Elite 2L Electric Sprayer Bottle is designed for efficient and effortless spraying tasks. This rechargeable device is suitable for various applications, including watering plants, fertilizing, and general cleaning. Its automatic operation eliminates the need for manual pumping, providing a continuous and adjustable spray.



Figure 1: AGARO Elite 2L Electric Sprayer Bottle in operation.

2. PRODUCT FEATURES

- **Large Capacity:** Features a 2-liter capacity, reducing the need for frequent refills.



Figure 2: The sprayer bottle showcasing its 2-liter capacity.

- **Durable Construction:** Made with premium HDPE material for a sturdy bottle body and a comfortable ABS handle for easy grip.
- **Water Level Indicator:** Integrated indicator allows for easy monitoring of liquid volume.
- **Adjustable Nozzle:** The nozzle can be twisted to change the spray pattern from a wide mist for broad coverage to a narrow stream for targeted application.

Adjustable Nozzle

Twist the nozzle to adjust spray pattern



Figure 3: Adjustable nozzle for varied spray patterns.

- **Rechargeable Battery:** Provides up to 2.5 hours of continuous use on a 3.5-hour charge. Includes a USB charging cable.



Figure 4: USB charging port for the sprayer.

- **Easy Filling:** Designed with a wide mouth for convenient and spill-free refilling.
- **Automatic Operation:** A single power button activates continuous spraying, eliminating manual pumping.



Figure 5: Automatic spray with a single button press.

3. SETUP

1. **Charge the Sprayer:** Before first use, fully charge the sprayer using the provided USB charging cable. The charging port is located on the handle. A full charge takes approximately 3.5 hours.
2. **Fill with Liquid:**
 - Unscrew the top section (handle and nozzle assembly) from the bottle.
 - Fill the bottle with water or your desired cleaning/fertilizing solution. Do not exceed the 2L maximum capacity. The water level indicator on the side of the bottle helps monitor the volume.
 - Securely screw the top section back onto the bottle, ensuring a tight seal to prevent leaks.

4. OPERATION

Watch the official product video for a visual guide on operating your AGARO Elite Electric Sprayer Bottle:

Video 1: Demonstration of AGARO Elite Electric Sprayer Bottle features and various uses.

- 1. Power On/Off:** Press the power button located on the top of the handle to turn the sprayer on or off. The sprayer will begin to operate automatically.
- 2. Adjusting Spray Pattern:** Twist the nozzle at the front of the sprayer to adjust the water stream.
 - Twist clockwise for a finer mist or wider spray pattern.
 - Twist counter-clockwise for a more concentrated, narrow stream.
- 3. Applications:** The AGARO Elite Electric Sprayer is versatile for various tasks:
 - **Plant Watering & Washing:** Use the fine mist to water indoor and outdoor plants, and to gently wash dust from leaves.
 - **Artificial Plants & Grass Cleaning:** Effectively clean dust and debris from artificial greenery.
 - **Surface Cleaning:** The narrow stream is ideal for removing dirt from walls, floors, and other hard surfaces, especially in outdoor areas like balconies and terraces.
 - **Outdoor Furniture Cleaning:** Easily clean outdoor chairs, tables, and other furniture.
 - **Vehicle Cleaning:** Suitable for cleaning bicycles and other small vehicles, removing dust and dirt from intricate parts.

5. MAINTENANCE

- **Nozzle Cleaning:** The front part of the nozzle can be removed for easy cleaning and to clear any blockages. Ensure the rubber gasket is properly seated when reassembling.
- **General Cleaning:** The bottle and exterior can be cleaned with a damp cloth. For thorough cleaning, the bottle can be hand washed. Do not immerse the handle/motor unit in water.
- **Storage:** Store the sprayer in a cool, dry place when not in use. Ensure it is clean and empty of any solutions before storage.

6. TROUBLESHOOTING

- **No Spray/Weak Spray:**
 - Check if the battery is charged. Recharge if necessary.
 - Ensure the nozzle is not clogged. Remove and clean the nozzle if needed.
 - Verify that the lid is securely tightened.
 - Check the water level in the bottle.
- **Leaking:**
 - Ensure the lid is tightly screwed on.
 - Check the rubber gasket inside the nozzle for proper placement and damage. Replace with an extra gasket if damaged.

7. SPECIFICATIONS

Feature	Detail
Brand	AGARO

Model Number	34214
Capacity	2 Litres
Material	Acrylonitrile Butadiene Styrene (ABS), HDPE
Run Time	Up to 2.5 hours
Recharge Time	3.5 hours
Included Components	Main Unit, USB Power Cord

14 cm (W) x 28 cm (H)

Dimensions
(Approx.)



Figure 6: Sprayer bottle dimensions.

8. WARRANTY AND SUPPORT

This product comes with a **1-year warranty** from the date of purchase. For warranty claims, technical support, or any inquiries, please contact AGARO customer service. Retain your purchase receipt as proof of purchase.

Manufacturer: Universal Corporation Ltd, Guangzhou, China
Importer: Universal Corporation Ltd, 4/1 Middleton Street, Sikkim Commerce House, Kolkata-71

© 2026 AGARO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B0CZHPGZDB>
More documents and user manuals: <https://manuals.plus/>