

[Manuals.plus](#) /

› [HOMLAND](#) /

› HOMLAND Raised Toilet Seat with Handles (Model TRB10-1) Instruction Manual

HOMLAND TRB10-1

HOMLAND Raised Toilet Seat with Handles (Model TRB10-1) Instruction Manual

For Model: TRB10-1

INTRODUCTION

Thank you for choosing the HOMLAND Raised Toilet Seat with Handles. This product is designed to provide enhanced safety, comfort, and independence for individuals who may experience difficulty using a standard toilet, including seniors, individuals with disabilities, pregnant women, and those recovering from surgery or injury. This manual provides essential information for proper assembly, use, and maintenance of your raised toilet seat.

SAFETY INFORMATION

- Always ensure all components are securely assembled before use.
- Verify that the non-slip rubber feet are firmly on the floor and not on any rugs or uneven surfaces.
- Do not exceed the maximum weight capacity of 400 lbs (181 kg).
- Regularly inspect the product for any signs of wear, damage, or loose parts. Discontinue use if any issues are found.
- Use the padded armrests for stable support when sitting down or standing up.
- Ensure the toilet seat is centered and stable over the toilet bowl.

PACKAGE CONTENTS

Please check that all the following components are included in your package:

- Handrails (x2)
- Front Connecting Tube Left (x1)
- Rear Connecting Tube Left (x1)
- Front Connecting Tube Right (x1)
- Rear Connecting Tube Right (x1)
- Foot Tubes (x4)

- Long Transverse Tubes (x2)
- C-Claps (x4)
- Seat Plate (x1)
- Toilet Paper Holder (x1)
- Organizer Pouch (x1)

SETUP AND ASSEMBLY

Assembly is tool-free and straightforward. Follow these steps:

Step 1: Install the Handrails

1. Connect the handrails to the corresponding front and rear connecting tubes. Ensure the buttons snap into place securely. Match the letters (A, B, C, D) on the tubes for correct pairing.

Your browser does not support the video tag.

Video: Assembly instructions for the HOMLAND Raised Toilet Seat, demonstrating how to connect the handrails and other components.

Step 2: Install the Long Transverse Tubes

1. Connect the two long transverse tubes between the assembled handrail sections. Ensure the buttons snap into place. Confirm the required width before securing.
2. Insert the C-Claps into the designated holes to further secure the transverse tubes.

Step 3: Install the Seat Plate

1. Place the soft padded seat plate onto the frame. Make sure the buckles under the seat are locked onto the long transverse tubes for stability.

Step 4: Install the Foot Tubes

1. Insert the four foot tubes into the bottom of the frame. Adjust all foot tubes to the same height for optimal stability.

Step 5: Attach the Toilet Paper Holder

1. Attach the toilet paper holder to either side of the frame as desired.

Step 6: Attach the Organizer Pouch

1. Attach the organizer pouch to the opposite side of the frame from the toilet paper holder, or as preferred.

ADJUSTMENTS

Height Adjustment

The HOMLAND Raised Toilet Seat offers 6 levels of height adjustment, ranging from a minimum seat height of 18.1 inches to a maximum of 23 inches. The overall product height can be adjusted from 25.8 inches to 30.9 inches. To adjust the height:

- Press the button on each foot tube.
- Slide the inner tube up or down to the desired height setting.
- Ensure the button snaps securely into one of the adjustment holes.
- Repeat for all four foot tubes, ensuring they are all set to the same height for stability.

Adjustable Height

Suitable for most peoples of different height



Image: Detailed view of the height adjustment mechanism on the HOMLAND Raised Toilet Seat, showing the numbered settings on the leg tubes.

Width Adjustment

The product width is adjustable from 19.1 inches to 23.2 inches, accommodating various toilet sizes. To adjust the width:

- Locate the adjustment buttons on the transverse tubes connecting the handrail sections.
- Press the buttons and slide the sections inward or outward to achieve the desired width.
- Ensure the buttons snaps securely into the adjustment holes on both sides.



Image: Illustration demonstrating the width adjustment feature of the HOMLAND Raised Toilet Seat, showing how it fits various toilet shapes including square, suspended, and V-shape.

FEATURES

- **Soft & Large Padded Seat:** The seat is generously sized (16.5 inches) and padded for extended comfort, preventing discomfort and offering stable support. It is non-absorbent and features a non-slip surface.
- **Non-slip Armrests:** The armrests are padded for comfort and provide reliable support for sitting and standing.
- **Non-slip Rubber Feet:** Each adjustable leg is equipped with non-slip rubber pads to effectively reduce friction and prevent sliding, ensuring stability and security.
- **Durable Construction:** The support rod under the aluminum raised toilet seat is welded to the four support legs, enhancing stability and allowing for a load-bearing capacity of up to 400 lbs. The legs have an outward tilt for improved support.
- **Convenience Features:** Includes a removable toilet paper holder and an organizer pouch for personal items.


SOFT PADDED SEAT

Soft Padded Seat Make You More Comfortable



Image: A close-up view highlighting the soft, padded material of the toilet seat, emphasizing comfort.

More Convenience Features



Organizer Pouch



Toilet Paper Holder



Easy to Setup



Image: Features of the HOMLAND Raised Toilet Seat, including the organizer pouch, toilet paper holder, and a visual of the easy-to-setup connection points.

OPERATING INSTRUCTIONS

- Position the raised toilet seat over your existing toilet, ensuring it is centered and stable.
- Use the padded armrests for support when lowering yourself onto the seat or pushing up to stand.
- Adjust the height and width as needed to ensure a comfortable and secure fit for the user and the toilet.

Your browser does not support the video tag.

Video: Demonstration of the HOMLAND Raised Toilet Seat with Handles in use, highlighting its stability and ease of access.

MAINTENANCE AND CLEANING

- Clean the seat and frame regularly with a mild soap and water solution.
- Avoid using abrasive cleaners or harsh chemicals, as these may damage the materials.
- Wipe dry after cleaning to prevent water spots and maintain hygiene.
- Periodically check all connections and adjustment buttons to ensure they remain secure.

TROUBLESHOOTING

- **Instability:** Ensure all four foot tubes are set to the same height and the non-slip rubber feet are flat on the floor. Check that all connecting tubes and the seat plate are securely locked.
- **Difficulty Adjusting:** Press the adjustment buttons fully before attempting to slide tubes. If resistance is met, ensure no debris is obstructing the mechanism.
- **Uncomfortable Seat:** The padded seat is designed for comfort. If discomfort persists, ensure the seat is correctly positioned and the height is appropriate for the user.

SPECIFICATIONS

Feature	Detail
Model Number	TRB10-1
Max Weight Capacity	400 lbs
Adjustable Seat Height	18.1" to 23"
Adjustable Product Width	19.1" to 23.2"
Package Dimensions	17 x 16.75 x 5 inches
Item Weight	7.95 Pounds
Material	Aluminum frame, padded seat

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided with your purchase or visit the official HOMLAND website. Keep your purchase receipt for any warranty claims.

Legal Disclaimer: Statements regarding medical equipment have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. Consult with a healthcare professional for medical advice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CZHY88PT>

More documents and user manuals: <https://manuals.plus/>