

[Manuals.plus](#) /

> [Goyappin](#) /

> Goyappin 2500W Handheld High-Temperature Steam Cleaner TC-SC-001 User Manual

Goyappin TC-SC-001

Goyappin 2500W Handheld High-Temperature Steam Cleaner

MODEL: TC-SC-001 USER MANUAL

Introduction

Thank you for choosing the Goyappin 2500W Handheld High-Temperature Steam Cleaner. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new steam cleaner. Please read it thoroughly before first use and retain it for future reference.

Important Safety Information

WARNING: Failure to follow these safety instructions could result in fire, electric shock, serious injury, or property damage.

- Always ensure the power supply matches the voltage specified on the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Exercise extreme caution when using steam. Steam is very hot and can cause severe burns. Keep hands, face, and body away from the steam nozzle.
- Never open the water tank cap while the unit is pressurized or hot. Allow the unit to cool down completely and release any residual pressure before refilling.
- Keep the appliance out of reach of children and pets.
- Do not use the appliance if the power cord or plug is damaged, or if the appliance itself is faulty or has been dropped.
- Use only clean tap water. Do not add detergents, perfumes, or other chemicals to the water tank, as this can damage the unit or create hazardous fumes.
- Always wear the provided heat-resistant gloves during operation.

Package Contents

Verify that all items are present in the package:

- 1 x Goyappin High-Pressure Steam Cleaner Unit
- 1 x Extension Pole
- 1 x Large Round Brush

- 1 x Small Brush
- 1 x Steel Brush
- 1 x Short Copper Nozzle
- 1 x Power Cord
- 1 x Pair of Heat-Resistant Gloves
- 1 x Instruction Manual



This image displays the Goyappin handheld steam cleaner unit, its steam gun, extension pole, large round brush, small brush, steel brush, short copper nozzle, power cord, and a pair of heat-resistant gloves, illustrating the complete package contents.

Product Overview

The Goyappin Handheld High-Temperature Steam Cleaner is designed for versatile cleaning tasks around the home and for car detailing. It features a powerful 2500W heating element, a 1.1-liter water tank, and a range of attachments for different surfaces.

Main Components:

- **Main Unit:** Contains the heating element, water tank, and control panel.
- **Steam Gun:** The primary steam output device, to which various nozzles and brushes attach.
- **Water Inlet/Outfall:** Separate ports for convenient and safe water management.
- **Control Panel:** Buttons for power and steam adjustment.


Attachments:

- **Extension Pole:** Extends reach for higher or harder-to-access areas.
- **Large Round Brush:** Ideal for larger surfaces like walls, countertops, and hoods.
- **Small Brush:** Suitable for delicate items, furniture, glass, and tile surfaces.
- **Steel Brush:** Designed for tough grime on cooktops, pots, pans, and other metal surfaces.
- **Short Copper Nozzle:** For concentrated steam application.


Setup

1. **Place the Unit:** Position the steam cleaner on a stable, flat surface.
2. **Fill the Water Tank:** Ensure the unit is unplugged and cool. Pull the safety cap until it opens. Using a measuring cup or funnel, carefully pour clean tap water into the water inlet. The tank has a capacity of 1.1 liters. Do not overfill. Securely close the safety cap.

Multiple Brushes for Whole House Cleaning



Big Brush for Large area , like walls, countertops, hoods, etc.



Steel Brush for cooktops, pots, pans, dishwashers and other metal surfaces.



Small brush for toys, furniture, glass and tile surfaces.



This image demonstrates the process of safely filling and emptying the water tank of the steam cleaner, highlighting the separate water inlet and outfall design for user convenience and safety.

3. **Attach Accessories:** Select the appropriate brush or nozzle for your cleaning task. Connect it firmly to the steam gun. If needed, attach the extension pole between the steam gun and the chosen accessory.
4. **Connect Power:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

1. **Power On:** Press the power button on the control panel. The indicator light will illuminate, signaling that the unit is heating up.
2. **Heating Time:** The steam cleaner will reach its operating temperature of 105°C (221°F) and 3.0 Bar pressure within approximately 15 seconds. The indicator light may change or turn off once ready, depending on the model.
3. **Adjust Steam Output:** Use the steam adjustment buttons (if available, often labeled '+' and '-') to select the desired steam intensity. The unit offers 6 adjustable steam gears.

4. **Begin Cleaning:** Direct the steam gun with the attached accessory towards the surface to be cleaned. Hold the steam trigger to release steam. Always wear heat-resistant gloves.

5. **Cleaning Applications:**

- **Kitchen:** Use the steel brush for cooktops, ovens, and greasy surfaces. The large round brush can be used for countertops and range hoods.
- **Bathroom:** The small brush is effective for tiles, grout, and fixtures.
- **Home:** Clean windows, mirrors, furniture, and upholstery with the small brush. For bed bugs, apply steam directly to affected areas, ensuring high temperature penetration.
- **Car Detailing:** Use various attachments for cleaning car interiors, upholstery, and even engine components.

2024 Upgraded High Pressure Steamer

Ours

Water inlet
Outfall

Safer, More convenient



Others

Only one inlet/outlet is
inconvenient and unsafe



A collage of images showing the effectiveness of the steam cleaner on different dirty surfaces, including a range hood, stovetop, grill, and tile grout, with 'Before' and 'After' comparisons.

Safer, More Convenient



The steam cleaner being used to clean an air conditioning unit, illustrating its capability to remove dust and sanitize with high-temperature steam.

Automobile Engine clean



An image depicting the steam cleaner being used to clean an automobile engine, showcasing its application in car detailing.

Multifunctional Independent Spray Gun



A series of images demonstrating the versatility of the steam cleaner's spray gun with different nozzle attachments, showing various steam patterns and applications.

Wide Application



Kitchen



Bathroom



Car Detail

This image illustrates the broad range of applications for the steam cleaner, including cleaning in the kitchen, bathroom, and for car interior detailing.

6. **Power Off:** After cleaning, release the steam trigger, press the power button to turn off the unit, and unplug it from the electrical outlet.

Maintenance

1. **Empty Water Tank:** Once the unit has cooled down completely and is unplugged, pull out the stopper from the outfall to empty any remaining water from the tank. This prevents mineral buildup and prolongs the life of the appliance.
2. **Clean Accessories:** Rinse brushes and nozzles under running water to remove dirt and debris. Allow them to air dry completely before storing.
3. **Wipe Down Unit:** Wipe the exterior of the steam cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents.
4. **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

Troubleshooting

Problem	Possible Cause	Solution
No steam or cold steam	Unit not plugged in; insufficient water; unit not heated sufficiently; steam trigger not pressed.	Ensure unit is plugged in and powered on. Check water level and refill if necessary. Allow 15 seconds for heating. Press and hold the steam trigger.
Water leakage from nozzle	Unit not fully heated; accessory not properly attached; mineral buildup.	Allow unit to fully heat before use. Ensure all attachments are securely fastened. Descale the unit if mineral buildup is suspected (refer to advanced maintenance).
Reduced steam output	Low water level; mineral buildup in nozzle or internal components.	Refill water tank. Clean or replace nozzle if clogged. Consider descaling the unit.
Unit does not turn on	No power; faulty power cord/plug.	Check power outlet and connections. Try a different outlet. If problem persists, contact customer support.

Specifications

Feature	Detail
Brand	Goyappin
Model Name	TC-SC-001
Wattage	2500W
Voltage	110V
Water Tank Capacity	1.1 Liters (1100ml)
Maximum Steam Temperature	105°C (221°F)
Steam Pressure	3.0 Bar
Heating Time	Approx. 15 seconds
Power Cord Length	1.5m
Steam Outlet Hose Length	2.0m
Item Weight	1.92 kg (4.22 lbs)
Form Factor	Handheld
Special Features	Portable, Large Tank, 6-Gear Adjustable Steam

High Temperature Steam Cleaner

Voltage	110V	Power	2500W
Power Cord Length	1.5m	Steam Pressure	3.0BAR
Steam Outlet Hose Length	2.0m	Water Tank Capacity	1.1L
Steam Temperature Max	105°C /221°F	Air Output	50-400 ML/min



A detailed table outlining the technical specifications of the steam cleaner, including voltage (110V), power (2500W), power cord length (1.5m), steam pressure (3.0 BAR), steam outlet hose length (2.0m), water tank capacity (1.1L), maximum steam temperature (105°C / 221°F), and air output (50-400 ML/min).

Warranty and Support

The Goyappin Handheld High-Temperature Steam Cleaner comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use conditions.

If you encounter any issues or have questions regarding your product, please contact our customer support team. We are committed to providing satisfactory after-sales service and will endeavor to resolve your concerns within 24 hours. Please note that in many cases, a return of the product may not be necessary for resolution.

For support, please refer to the contact information provided on your purchase receipt or the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CZKQF1QQ>

More documents and user manuals: <https://manuals.plus/>