Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Slevoo YLW6336

Slevoo Carpet Cleaner Machine User Manual

Model: YLW6336

1. Introduction

Thank you for choosing the Slevoo Carpet Cleaner Machine. This portable upholstery cleaner is designed for efficient spot and stain removal from various surfaces including carpets, rugs, upholstery, and car interiors. Featuring a powerful 400W motor delivering 10.5Kpa suction, and a dual-tank system, it ensures deep cleaning and easy maintenance. Please read this manual thoroughly before operation to ensure safe and effective use of your new appliance.

2. Important Safety Instructions

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not allow children to play with the appliance. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Unplug from outlet when not in use and before cleaning.
- Use only low-foaming or non-foaming cleaning solutions specifically designed for carpet cleaners. High-foaming solutions can cause leakage.

3. Package Contents

Verify that all items are present in the package:

- Slevoo Carpet Cleaner Machine (Main Unit)
- 3.2" Tough Stain Tool
- Tight Spot Tool
- 30X Concentrated Spot & Stain Cleaner (1 bottle)
- User Manual

4. Product Components

Familiarize yourself with the main parts of your Slevoo Carpet Cleaner Machine:



Image: The Slevoo Carpet Cleaner Machine, showing the main unit, hose, cleaning tools, and a bottle of cleaning solution.

- **Clean Water Tank:** Holds clean water and cleaning solution. Capacity: 40 oz.
- **Dirty Water Tank:** Collects dirty water and debris. Features a MAX fill line.
- **Main Unit:** Houses the motor, pumps, and tanks.
- **Hose:** Flexible hose connecting the cleaning tool to the main unit (4 ft long).
- **Power Cord:** Electrical cord for power supply (16.4 ft long).
- **Power Button:** On/Off switch for the machine.
- **Spray Trigger:** Located on the cleaning tool handle, activates water/solution spray.

5. Setup Guide

1. **Prepare the Clean Water Tank:** Remove the clean water tank from the main unit. Fill it with warm water up to the indicated fill line. Add one capful of the Slevoo 30X Concentrated Spot & Stain Cleaner. If using other brands of cleaners, ensure they are low-foaming or non-foaming to prevent leakage. Securely close the tank and place it back onto the main unit.



Image: A person filling the clean water tank of the Slevoo carpet cleaner at a sink, demonstrating the large tank capacity.

2. **Attach the Cleaning Tool:** Connect the desired cleaning tool (3.2" Tough Stain Tool or Tight Spot Tool) to the end of the hose until it clicks securely into place.
3. **Position the Machine:** Place the carpet cleaner on a flat, stable surface near the area you intend to clean.
4. **Plug In:** Plug the power cord into a grounded electrical outlet (Rated voltage: 120V).

6. Operating Your Carpet Cleaner

General Cleaning Process

1. **Power On:** Press the power button on the main unit to turn on the machine.
2. **Pre-treat (Optional):** For heavily soiled areas, you may pre-treat the stain by spraying a small amount of solution directly onto it and allowing it to soak for a few minutes.
3. **Spray:** Hold the cleaning tool over the stained area. Press the spray trigger to release the cleaning solution onto the surface.
4. **Scrub:** Gently scrub the stained area with the brush on the cleaning tool. The high-precision soft brush is designed not to damage fabrics.
5. **Suction:** Release the spray trigger and slowly pull the cleaning tool across the wet area to suction up the dirty water. Repeat as necessary until the area is clean and as dry as possible.



Image: A visual representation of the deep cleaning process, showing how the machine sprays water, allows for scrubbing, and then suctions away the dirty liquid from the fabric.

Using the Cleaning Tools

- **3.2" Tough Stain Tool:** Ideal for larger areas and general scrubbing on carpets, rugs, sofas, and upholstery.
- **Tight Spot Tool:** Designed for crevices, corners, baseboards, and hard-to-reach areas.



Image: A detailed view of the two included cleaning tools: the wider 3.2-inch Tough Stain Tool for general use and the narrower Tight Spot Tool for detailed cleaning.

Recommended Usage Areas

The Slevoo Carpet Cleaner Machine is versatile and can be used on a variety of surfaces:

- Carpets and Rugs
- Upholstery (Sofas, Chairs)
- Car Interiors (Seats, Floor Mats)
- Stairs
- Cribs and Toys (fabric surfaces)



Image: A collage demonstrating the versatility of the Slevoo cleaner, showing it effectively cleaning stains on carpets, car seats, sofas, floors, stairs, curtains, cribs, and even fabric toys.

7. Care and Maintenance

Emptying and Cleaning Tanks

It is crucial to empty and clean both tanks after each use to prevent odors and maintain optimal performance.

1. **Power Off and Unplug:** Turn off the machine and unplug it from the power outlet.
2. **Remove Dirty Water Tank:** Detach the dirty water tank from the main unit.
3. **Empty Dirty Water:** Pour out the dirty water into a sink or drain. Observe the amount of dirt extracted.



Image: A close-up view of the dirty water tank, highlighting the 'MAX' fill line. The tank is designed to prevent leaks, but should be emptied when the water level reaches maximum capacity.

4. **Rinse Tanks:** Rinse both the dirty water tank and the clean water tank thoroughly with clean water. Allow them to air dry before reassembling or storing.

Cleaning the Cleaning Head

The cleaning head is detachable for easy cleaning:

1. **Detach Head:** Disconnect the cleaning tool from the hose.
2. **Separate Components:** Carefully separate the clear nozzle from the brush head if applicable, following the instructions in the diagram.



Image: A user demonstrating how to detach the cleaning head from the hose, making it easier to clean thoroughly after use.

3. **Rinse:** Rinse all parts of the cleaning head under running water to remove any debris or residue.
4. **Reassemble:** Ensure all parts are dry before reassembling the cleaning head and reattaching it to the hose or storing.

Storage

Store the Slevoo Carpet Cleaner Machine in a cool, dry place.

- Ensure all tanks are empty and clean.
- Wrap the power cord neatly.

- The compact design (10.8" x 5.8" x 11.5") allows for easy storage in small spaces.



Image: A person easily storing the lightweight and compact Slevoo Portable Carpet Cleaner in a kitchen cabinet, demonstrating its convenient size for storage.

8. Troubleshooting Guide

If you encounter any issues with your Slevoo Carpet Cleaner Machine, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Machine does not turn on	Not plugged in; Power outlet not working; Power button not pressed.	Ensure power cord is securely plugged into a working outlet. Press the power button firmly.
No spray from cleaning tool	Clean water tank empty; Tank not seated correctly; Spray trigger not pressed; Clogged nozzle.	Refill clean water tank. Ensure tank is securely in place. Press spray trigger. Clean nozzle.
Poor suction	Dirty water tank full; Tank not seated correctly; Hose or tool clogged; Tank lid not sealed.	Empty dirty water tank. Ensure tank is securely in place. Check hose and tool for blockages. Ensure dirty tank lid is properly sealed.
Water leakage	Dirty water tank overfilled; Tank not seated correctly; Using high-foaming cleaner.	Do not exceed MAX fill line on dirty water tank. Ensure tanks are properly seated. Use only low-foaming or non-foaming cleaners.

9. Product Specifications

Feature	Specification
Model Number	YLW6336
Dimensions (L x W x H)	10.8" x 5.8" x 11.5" (Product dimensions: 7.48 x 12.95 x 13.77 inches)
Item Weight	7.5 lbs (10.1 lbs when filled with water)
Motor Power	400W
Suction Power	10.5Kpa
Clean Water Tank Capacity	40 oz
Hose Length	4 ft
Power Cord Length	16.4 ft
Rated Voltage	120V
Rated Current	3 Amps

10. Warranty and Customer Support

Slevoo products are manufactured under strict quality standards to provide a positive customer experience. We offer friendly customer service, including email support for troubleshooting within 24 hours. For any questions, concerns, or support needs regarding your Slevoo Carpet Cleaner Machine, please contact our professional customer service team. Refer to your purchase documentation for specific warranty terms and conditions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CZL5R3S6

More documents and user manuals: **https://manuals.plus/**