

Casfuy B0CZLBJXDJ

Casfuy 3-in-1 Interactive Cat Toy Instruction Manual

Model: B0CZLBJXDJ

1. INTRODUCTION

Thank you for choosing the Casfuy 3-in-1 Interactive Cat Toy. This device is designed to provide engaging and stimulating play for your cat, promoting physical activity and mental enrichment. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. PRODUCT OVERVIEW

2.1 Key Features

- **3-in-1 Design:** Includes interchangeable feather, ribbon, and simulated mouse tail attachments for varied play.
- **Irregular Movement Patterns:** Moves forward, backward, turns, and spins to mimic prey, stimulating your cat's hunting instincts.
- **Intelligent Obstacle Avoidance:** Automatically navigates around furniture and walls, changing direction to prevent interruptions.
- **Dual-Speed Modes:** Offers both fast and slow speeds to accommodate different cat temperaments and activity levels.
- **Smart Sleep Mode:** Enters standby after 5 minutes of inactivity, reactivating with a touch.
- **USB Type-C Rechargeable:** Convenient charging with a 2-hour charge providing approximately 2 hours of continuous play.
- **Safe Materials:** Constructed from BPA-free, food-grade ABS and silicone.

2.2 Package Contents

- Casfuy Interactive Cat Toy Unit
- Feather Attachment
- Ribbon Attachment

- Simulated Mouse Tail Attachment
- USB Type-C Charging Cable
- User Manual



Image: The Casfuy 3-in-1 Interactive Cat Toy in action, featuring a kitten engaging with the feather attachment.

3. SAFETY INFORMATION

- This product is intended for pet use only. Keep out of reach of children.
- Inspect the toy regularly for damage. Discontinue use if any parts are broken or detached to prevent choking hazards.
- Ensure the toy is used on appropriate surfaces. While it works on various floors, avoid long-pile carpets where movement may be restricted.
- Do not immerse the toy in water or expose it to excessive moisture.
- Use only the provided USB Type-C cable for charging.
- Supervise your pet during play, especially when introducing new toys.



Image: A cat interacting closely with the toy, demonstrating the use of safe, BPA-free, and food-grade materials.

4. SETUP

4.1 Charging the Toy

1. Locate the USB Type-C charging port on the toy.
2. Connect the provided USB Type-C cable to the toy and a compatible USB power adapter (not included).
3. The indicator light will show charging status (e.g., red for charging, green for fully charged).
4. A full charge takes approximately 2 hours and provides about 2 hours of continuous play.

4.2 Attaching the Play Wand

1. Select your desired attachment (feather, ribbon, or simulated mouse tail).
2. Insert the base of the attachment firmly into the designated slot on top of the toy until it clicks into place.
3. Ensure the attachment is securely fastened before activating the toy.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- To power on, press and hold the power button located on the top of the toy.
- To power off, press and hold the power button again.

5.2 Changing Speed Modes

- While the toy is active, press the power button briefly to switch between speed modes (fast and slow).
- Observe your cat's reaction to determine the preferred speed.

Dual-Speed-Modus

Hält Katzen jeden Alters frisch

Niedrige Geschwindigkeit

Für empfindliche Kätzchen oder ältere Katzen



Schnelle Geschwindigkeit

Für übergewichtige oder athletische Katzen

Image: Illustration of the dual-speed modes, showing a cat calmly interacting with the toy at low speed and another cat actively chasing it at high speed.

5.3 Smart Sleep Mode

- The toy will automatically enter sleep mode after 5 minutes of inactivity.
- It will remain in standby for 4 hours, during which it can be reactivated by a gentle touch or nudge from your cat.
- After 4 hours in standby, the toy will power off completely to conserve battery.

Freie Hände genießen das Leben

Automatisches Spielzeug mit Touch-Aktivierung



Arbeiten Sie alle 5
Minuten und wechseln
Sie in den Schlafmodus

Tippen Sie
auf Aufwachen



Image: A cat playing with the interactive toy, demonstrating its automatic operation and smart sleep mode, allowing for hands-free entertainment.

5.4 Obstacle Avoidance

- The toy is equipped with sensors to detect obstacles. When it encounters a wall, furniture, or other objects, it will automatically reverse and change direction.
- This feature ensures continuous play without getting stuck.
- Optimal performance is achieved on hard floors (wood, tile, marble) and low-pile carpets. Performance may vary on long-pile carpets.

Intelligente Hindernisvermeidung

Keine Unterbrechung für verschiedene Etagen



Image: The toy navigating different floor surfaces (wood, marble, carpet) and avoiding obstacles, illustrating its intelligent movement capabilities.

6. MAINTENANCE

6.1 Cleaning

- Wipe the toy's surface with a soft, dry cloth.
- Do not use harsh chemicals or abrasive cleaners.
- Periodically remove any pet hair or debris that may accumulate around the wheels or attachments to ensure smooth operation.

6.2 Storage

- Store the toy in a cool, dry place when not in use.
- Ensure the toy is fully charged before long-term storage to maintain battery health.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Toy does not turn on.	Low battery.	Charge the toy using the provided USB Type-C cable.
Toy stops moving unexpectedly.	Entered smart sleep mode.	Touch or nudge the toy to reactivate it.
Toy gets stuck or moves slowly.	Debris in wheels; unsuitable surface.	Clean wheels of any hair or debris. Move to a hard floor or low-pile carpet.
Attachments fall off easily.	Attachment not securely fastened.	Ensure the attachment is firmly inserted into the slot until it clicks.

8. SPECIFICATIONS

- **Model:** B0CZLBJXDJ
- **Dimensions (L x W x H):** 12.8 x 10.5 x 5.4 cm (5.04 x 4.13 x 2.13 inches)
- **Weight:** 230 grams (0.51 lbs)
- **Battery Type:** 1 Lithium-ion (included)
- **Charging Time:** Approximately 2 hours
- **Play Time:** Approximately 2 hours (continuous)
- **Material:** ABS, Silicone (BPA-free, food-grade)
- **Recommended for:** Cats of all ages and sizes
- **Usage:** Indoor

9. WARRANTY AND SUPPORT

Casfuy products are manufactured with quality and performance in mind. For specific warranty details, please refer to the warranty card included with your purchase or contact Casfuy customer support directly. If you encounter any issues or have questions regarding your Casfuy 3-in-1 Interactive Cat Toy, please contact our customer support team for assistance. Contact information can typically be found on our official website or on the product packaging.



A Reference for the Rest of Us!

[Casfuy Dog Nail Grinder User Manual and Tutorial](#)

A comprehensive guide for operating and maintaining the Casfuy Two-Speed Dog Nail Grinder. Learn about safety precautions, proper grinding techniques, nail anatomy, and troubleshooting tips for effective pet nail care.



[Casfuy F13-L Automatic Pet Feeder User Manual](#)

User manual for the Casfuy F13-L Automatic Pet Feeder, covering setup, operation, safety, and troubleshooting.



[Casfuy Pet Trimmer User Manual - EC21](#)

User manual for the Casfuy Pet Trimmer (Model EC21), providing instructions on package contents, product diagram, cautions, charging, operation, cleaning, maintenance, trimming tips, FAQs, and warranty information.