

[Manuals.plus](#) /

› [MoKo](#) /

› MoKo Keyboard Case for iPad 11th/10th Generation (11-inch 2025 & 10.9-inch 2022) - User Manual

MoKo P840401434024

MoKo Keyboard Case for iPad 11th/10th Generation (11-inch 2025 & 10.9-inch 2022)

User Manual

INTRODUCTION

The MoKo Keyboard Case is designed to enhance your iPad experience by providing both protection and functionality. This manual provides instructions for setting up, operating, and maintaining your keyboard case, ensuring optimal performance and longevity.

COMPATIBILITY

This keyboard case is specifically designed for the following iPad models:

- iPad 11th Generation 11-inch 2025 (Model: A3354, A3355, A3356)
- iPad 10th Generation 10.9-inch 2022 (Model: A2696, A2757, A2777)

It is not compatible with any other iPad models.



This image illustrates the specific iPad models compatible with the MoKo Keyboard Case, including their model numbers.

PACKAGE CONTENTS

Upon opening your package, please ensure all the following items are present:

- 1 x MoKo iPad Case
- 1 x Wireless Bluetooth Keyboard
- 1 x USB Charging Cable
- 1 x User Guide

SETUP

1. Charging the Keyboard

Before initial use, fully charge the wireless keyboard using the provided USB charging cable. Connect the Type-C end of the cable to the keyboard's charging port and the USB-A end to a compatible power adapter (not included).

The keyboard features a 150mAh battery, requiring approximately 2 hours for a full charge, providing over 100 hours of working time.

2. Attaching the iPad to the Case

Gently place your iPad into the protective case. Ensure it is securely fitted within the flexible PC back shell, aligning all ports and buttons correctly.

3. Connecting the Keyboard via Bluetooth

1. Ensure the keyboard is charged and powered on.
2. On your iPad, navigate to **Settings > Bluetooth**.
3. Toggle Bluetooth to the 'On' position. Your iPad will begin searching for nearby devices.
4. Locate 'MoKo Keyboard' (or a similar name) in the list of available devices and tap to connect.
5. Follow any on-screen prompts to complete the pairing process. The keyboard is designed for a strong magnetic connection to the case.

The keyboard connects wirelessly via Bluetooth, offering a strong magnetic attachment to the case and an effective operating distance of 10 meters (33 feet).

4. Using the Built-in Pencil Holder

The integrated pencil holder is designed for convenient and secure storage of your Apple Pencil. The side opening facilitates automatic pairing and charging of the Apple Pencil stylus when placed correctly.

The MoKo design features a convenient pen slot for easy one-hand removal of your stylus.

OPERATING INSTRUCTIONS

1. Adjusting Viewing Angles

The case features multiple horizontal slots that allow you to prop up your iPad at various angles. Adjust the iPad to your preferred position for comfortable viewing, typing, or media consumption.

The case offers adjustable viewing angles, typically between 120 and 126 degrees, suitable for various tasks.

2. Keyboard Functions

The QWERTY keyboard layout includes practical shortcuts to improve work efficiency. While primarily designed for iPadOS, it is also compatible with iOS, Windows, and Android systems.

3. Auto Wake/Sleep Function

When the keyboard is detached from the case, the case supports an auto wake/sleep function for your iPad. Closing the case will put your iPad to sleep, and opening it will wake it up, helping to conserve battery life.

MAINTENANCE

1. Cleaning the Case

The case is designed with a splash-proof and easy-to-clean exterior. To clean, gently wipe the surface with a damp, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these may damage the material.

The case material is splash-proof and can be easily cleaned by wiping away spills.

2. Battery Care

To prolong the keyboard's battery life, avoid fully discharging it frequently. Recharge the keyboard when the battery indicator shows a low charge. Store the keyboard in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Keyboard Not Connecting

- Ensure the keyboard is charged and powered on.
- Verify that Bluetooth is enabled on your iPad.
- Try unpairing the keyboard from your iPad's Bluetooth settings and then re-pairing it.
- Restart both your iPad and the keyboard.

Keys Not Responding

- Check if the keyboard battery is low and recharge if necessary.
- Ensure the keyboard is properly connected via Bluetooth.
- Clean any debris from around the keys.

iPad Not Waking/Sleeping Automatically

- Ensure the case is properly closed and aligned with the iPad.
- Note that this function is typically active when the keyboard is detached from the case.

SPECIFICATIONS

Refer to the table below for detailed product specifications:

Feature	Detail
Brand	MoKo
Model Number	P840401434024
Compatible Devices	iPad 11th Gen 11-inch 2025 (A3354, A3355, A3356), iPad 10th Gen 10.9-inch 2022 (A2696, A2757, A2777)
Connectivity Technology	Bluetooth
Keyboard Layout	QWERTY
Keyboard Description	Multi-functional
Special Features	Anti-Slip, Multi-Angle Stand Folio Cover, Detachable Wireless Bluetooth Keyboard, Auto Wake Sleep
Material	Polycarbonate
Color	C-White
Battery	1 Lithium-polymer (rechargeable)

Feature	Detail
Charging Time	Approx. 2 hours
Working Time	100+ hours
Weight	22.58 Ounces
Components Included	iPad Case, Wireless Keyboard, USB Charging Cable, User Guide
Minimum OS Requirement	iOS 16
Compatible OS Family	iOS, Windows, Android

WARRANTY & SUPPORT

MoKo products are designed for reliability and performance. For any questions, technical assistance, or support needs, please contact MoKo customer service. Our dedicated team is available to assist you.

Our dedicated customer service team is available to assist you with any inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question