



Manuals.plus /

› GOWENIC /

› GOWENIC Electric Sprayer 8L User Manual

GOWENIC GOWENICp3a9buk26z-11

GOWENIC Electric Sprayer 8L User Manual

Model: GOWENICp3a9buk26z-11

INTRODUCTION

Thank you for choosing the GOWENIC Electric Sprayer 8L. This battery-powered sprayer is designed for efficient and convenient application of liquids for various tasks, including gardening, lawn care, cleaning, and disinfection. Its automatic operation and portable design make it suitable for both small and large areas. Please read this manual thoroughly before initial use to ensure proper assembly, safe operation, and optimal performance.



The GOWENIC 8L Electric Sprayer, shown with its shoulder strap and demonstrating its spray capability.

SAFETY INFORMATION

Always follow basic safety precautions when using this product to reduce the risk of injury or damage.

- Read all instructions before use.
- Do not spray flammable liquids, strong acids, or corrosive chemicals.
- Wear appropriate personal protective equipment (PPE) such as gloves and eye protection when handling chemicals.
- Keep out of reach of children and pets.
- Do not immerse the sprayer unit in water.
- Charge the battery in a dry, well-ventilated area.
- Disconnect the charger once the battery is fully charged.
- Do not modify the sprayer or its components.

SETUP

Follow these steps to assemble and prepare your electric sprayer for first use.

1. Unpacking and Component Check

Carefully remove all components from the packaging. Verify that all parts listed below are present and undamaged.

- 1 x Water Bottle (8L capacity)
- 1 x Sprayer Unit (with inbuilt battery and handle)
- 1 x Sprayer Pole
- 1 x Hose
- 4 x Nozzles (various types)
- 1 x Straps (shoulder strap)
- 2 x Cover (for bottle openings)
- 1 x USB Cable (for charging)
- 2 x Gasket
- 1 x English Manual (this document)



All included components of the GOWENIC 8L Electric Sprayer, including the main unit, hose, pole, nozzles, strap, and charging cable.

2. Assembly

1. **Connect the Hose:** Attach one end of the hose to the outlet port on the sprayer unit and the other

- end to the inlet on the water bottle. Ensure connections are secure to prevent leaks.
2. **Attach the Sprayer Pole:** Connect the sprayer pole to the handle of the sprayer unit.
 3. **Select and Attach Nozzle:** Choose the desired nozzle from the four provided and screw it onto the end of the sprayer pole.
 4. **Attach Shoulder Strap:** If desired, attach the shoulder strap to the designated loops on the water bottle for easier portability.

3. Initial Charging

Before first use, fully charge the built-in lithium battery. Connect the provided USB cable to the charging port on the sprayer unit and plug the other end into a compatible USB power adapter (not included). The charging indicator light will show the charging status. A full charge typically takes several hours.

OPERATING INSTRUCTIONS

1. Filling the Water Bottle

1. Ensure the sprayer unit is turned off.
2. Unscrew the main cap of the 8L water bottle.
3. Pour the desired liquid (water, fertilizer, pesticide, cleaning solution) into the bottle. Do not exceed the 8L maximum fill line.
4. Securely screw the cap back onto the bottle to prevent leaks.



A close-up view of the sprayer's top cap, which is removed for filling, and the integrated handle.

2. Powering On and Spraying

1. Hold the sprayer handle comfortably.
2. Press the power button on the handle to turn on the sprayer. The built-in electric motor will activate, and liquid will begin to spray automatically.
3. Direct the sprayer pole towards the target area.
4. To stop spraying, press the power button again.



Comfortable to hold
Easy watering with one click start
The handle is designed to feel comfortable and easy to handle

A hand demonstrating how to comfortably hold the sprayer handle and operate the one-click start button.

3. Adjusting Spray Pattern

The sprayer comes with four different nozzles to achieve various spray patterns:

- **Direct Spray:** For concentrated application.
- **Atomized Nozzle:** For a fine mist.
- **Fan Nozzle:** For a wide, flat spray pattern.
- **6-Hole Nozzle / 2-Head Nozzle:** For broader coverage or specific applications.

To change the spray pattern, unscrew the current nozzle from the sprayer pole and screw on the desired nozzle. Test the spray pattern in a safe area before applying to your target.



**Various spray nozzles
Spray effect display**

Direct spray / atomized nozzle, fan nozzle, 6 hole nozzle, 2 head nozzle



Visual examples of various spray patterns achievable with the different nozzles, including direct spray, atomized mist, and fan spray.

MAINTENANCE

Proper maintenance ensures the longevity and efficient operation of your sprayer.

1. Cleaning After Use

1. Empty any remaining liquid from the water bottle.
2. Rinse the bottle thoroughly with clean water.
3. Fill the bottle with clean water and spray it through the nozzle for a few minutes to flush out the hose and sprayer pole.
4. Clean the exterior of the sprayer unit with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
5. Remove and clean the nozzles separately to prevent clogging.

2. Storage

- Store the sprayer in a cool, dry place, away from direct sunlight and freezing temperatures.
- Ensure the battery is partially charged (not fully depleted or fully charged for extended periods) before storing for long durations.
- Keep the sprayer out of reach of children.

TROUBLESHOOTING

If you encounter issues with your sprayer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Sprayer does not turn on.	Battery is depleted.	Charge the battery using the provided USB cable.
No spray or weak spray.	Nozzle is clogged.	Remove and clean the nozzle.
	Hose is kinked or disconnected.	Check hose for kinks and ensure secure connections.
	Water bottle is empty.	Refill the water bottle.
Liquid leaks from connections.	Connections are loose or gaskets are damaged.	Tighten all connections. Check and replace gaskets if necessary.

SPECIFICATIONS

- **Model:** GOWENICp3a9buk26z-11
- **Capacity:** 8 Liters (2.1 Gallons)
- **Battery Type:** Built-in Lithium Battery
- **Battery Capacity:** 2000 mAh
- **Material:** Acrylonitrile Butadiene Styrene (ABS), Polyethylene (PE)
- **Power Source:** AC/DC (via USB charging)
- **Dimensions (approx.):** 26 cm (H) x 30 cm (L) x 16.5 cm (W) / 10.24 in (H) x 11.81 in (L) x 6.5 in (W)
- **Weight (approx.):** 1430g / 50.4oz



Key dimensions of the GOWENIC 8L Electric Sprayer for reference.

WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty. For specific details regarding warranty coverage, duration, and claims, please refer to the warranty card included in your product packaging or contact GOWENIC customer support directly. Keep your purchase receipt as proof of purchase.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue with your GOWENIC Electric Sprayer, please contact our customer support team. Refer to the contact information provided on the product packaging or the official GOWENIC website for the most up-to-date support channels.