

## Venture Forward GBT1754M

# Venture Forward Portable Propane Gas Grill User Manual

Model: GBT1754M

## 1. INTRODUCTION

---

Thank you for choosing the Venture Forward Portable Propane Gas Grill, Model GBT1754M. This grill is designed for outdoor cooking, offering a durable stainless steel construction, a 10,000 BTU burner, and a spacious 208 sq. cm cooking surface. Its compact and portable design, featuring foldable legs and a locking lid, makes it ideal for tailgating, camping, and picnics. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your grill.

## 2. SAFETY INFORMATION

---

**WARNING:** For outdoor use only. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. An LP cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.

- Always read and follow all instructions before operating the grill.
- Keep children and pets away from the grill at all times.
- Ensure the grill is placed on a stable, level, non-combustible surface.
- Maintain a safe distance from combustible materials.
- Never leave a lit grill unattended.
- Always check for gas leaks before each use.
- Use only the type of gas and pressure regulator specified by the manufacturer.
- Allow the grill to cool completely before moving or cleaning.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before assembly:

- Venture Forward Portable Propane Gas Grill
- Electric Starter (integrated)

- User Manual (this document)
- Thermometer (integrated)
- Adapter Hose (for 0.5 kg or 9 kg propane tanks)

## 4. SETUP

---

Follow these steps to set up your portable gas grill:

1. **Unpack the Grill:** Carefully remove all packaging materials and inspect the grill for any damage.
2. **Unfold the Legs:** Place the grill on a flat surface. Release the leg locks and extend the four legs until they click securely into place. Ensure the grill is stable.
3. **Connect the Propane Tank:**
  - Ensure the grill's control knob is in the 'OFF' position.
  - Attach the adapter hose to the grill's gas inlet.
  - Connect the other end of the adapter hose to your 0.5 kg or 9 kg propane tank. Hand-tighten all connections firmly.
  - Perform a leak test: Apply a soapy water solution to all gas connections. Open the propane tank valve. If bubbles appear, there is a leak. Close the tank valve immediately and re-tighten connections. Repeat the test. Do not use the grill if a leak persists.



Image: The Venture Forward Portable Propane Gas Grill positioned on a portable table, with a small green propane tank connected to its side, ready for use.

## 5. OPERATING

---

Operating your Venture Forward grill is straightforward:

### 1. Pre-heating:

- Ensure the propane tank valve is fully open.
- Turn the control knob to the 'HIGH' position.
- Press and hold the push-button ignition until the burner ignites. You should hear a 'click' and see a flame. If it doesn't light within 5 seconds, turn the knob to 'OFF', wait 5 minutes, and try again.
- Close the lid and allow the grill to preheat for 5-10 minutes. The integrated thermometer will indicate the internal temperature.

### 2. Cooking:

- Place food on the stainless steel cooking grate.
- Adjust the control knob to achieve your desired cooking temperature.
- Monitor food and internal grill temperature using the integrated thermometer.

### 3. Shutting Down:

- When finished cooking, turn the control knob to the 'OFF' position.
- Close the valve on the propane tank.
- Allow the grill to cool completely before cleaning or storing.




Image: The Venture Forward Portable Propane Gas Grill with its lid fully open, revealing the clean stainless steel cooking grate and the internal burner components.

## 6. MAINTENANCE

---

Regular maintenance ensures your grill remains in excellent condition:

- **Cleaning the Cooking Grate:** After each use, once the grill has cooled, brush the cooking grate with a grill brush to remove food residue. For stubborn residue, wash with warm soapy water and rinse thoroughly.
- **Cleaning the Exterior:** Wipe down the stainless steel exterior with a damp cloth and mild detergent. Avoid abrasive

cleaners or scouring pads that can scratch the surface.

- **Burner Maintenance:** Periodically inspect the burner ports for blockages (e.g., from insects). Use a wire brush or a stiff wire to clear any obstructions.
- **Storage:** Ensure the grill is clean and dry before storing. Fold the legs and secure the lid with the locking mechanism. Store in a dry, protected area. Disconnect and store the propane tank separately in a well-ventilated area, away from direct sunlight or heat sources.



Image: The Venture Forward Portable Propane Gas Grill with its lid closed and legs folded, demonstrating its compact and portable design for easy storage or transport.

## 7. TROUBLESHOOTING

---

Refer to this section for common issues and their solutions:

Problem	Possible Cause	Solution
Burner does not light	No gas flow; Clogged burner; Faulty igniter	Check propane tank connection and fuel level; Clean burner ports; Check igniter electrode for spark.
Low flame or uneven heat	Low gas pressure; Clogged burner ports; Regulator issue	Ensure tank valve is fully open; Clean burner ports; Disconnect and reconnect regulator to reset.
Gas leak detected	Loose connections; Damaged hose/regulator	Immediately turn off gas. Tighten all connections. If leak persists or hose/regulator is damaged, replace parts. Do not use.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	GBT1754M
Brand	Venture Forward
Material Type	Stainless Steel
Product Dimensions (L x W x H)	53.34 x 38.1 x 25.4 cm (21 x 15 x 10 inches)
Item Weight	5.49 kg (12.1 lbs)
Heat Output	10,000 BTU
Cooking Area	208 sq. cm
Fuel Type	Propane Gas
Ignition System	Push-Button Ignition
Assembly Required	Yes
Outdoor Use	Yes

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the documentation included with your purchase or contact Venture Forward customer service. Keep your purchase receipt and model number (GBT1754M) handy for any inquiries.