

FAMAPY Display Cabinet with 6 Acrylic Doors and Shelves

FAMAPY Display Cabinet with 6 Acrylic Doors and Shelves User Manual

Model: Display Cabinet with 6 Acrylic Doors and Shelves
Brand: FAMAPY

1. INTRODUCTION

Thank you for choosing the FAMAPY Display Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new cabinet. Designed for versatility, this cabinet features six acrylic doors and multiple shelves, making it ideal for displaying collectibles, organizing household items, or enhancing your living room, home office, or kitchen space. Please read these instructions carefully before beginning assembly and retain them for future reference.

2. SAFETY INFORMATION

- **Anti-Tip Device:** For your safety, this cabinet includes an anti-tip device. It is crucial to install this device securely to a wall to prevent accidental tipping, especially in households with children or pets.
- **Weight Distribution:** Distribute weight evenly across shelves. Avoid placing heavy items on upper shelves only, as this can affect stability.
- **Assembly:** Assembly requires two people for stability and ease. Follow all steps precisely to ensure the cabinet is structurally sound.
- **Placement:** Place the cabinet on a flat, level surface to prevent wobbling and ensure stability.
- **Children:** Do not allow children to climb on or play with the cabinet.

3. PACKAGE CONTENTS

Your FAMAPY Display Cabinet is shipped in two separate packages due to its size and weight. These packages may arrive at different times. Please be patient and ensure you have received both packages before starting assembly. Before assembly, carefully unpack all components and verify that all parts and hardware are present and undamaged. Each piece is labeled for easy identification. If any parts are missing or damaged, please contact customer support immediately.

- Cabinet Panels (e.g., side panels, back panels, top, bottom)
- Acrylic Doors (6 units)

- Shelves (6 units)
- Hardware Pack (screws, dowels, hinges, handles, shelf pins, anti-tip kit)
- Assembly Instructions Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of this display cabinet requires careful attention to detail and the assistance of a second person. Please follow the instructions step-by-step to ensure proper construction and stability.

4.1 Pre-Assembly Checklist

- **Clear Workspace:** Ensure you have a spacious, clean, and level area for assembly.
- **Tools Required:** Gather necessary tools, typically a Phillips head screwdriver and a hammer (not included).
- **Inspect Parts:** Before starting, inspect all pieces for any damage. If you purchased assembly service, ensure all pieces are in good condition first.
- **Identify Components:** Familiarize yourself with all labeled parts and hardware.

4.2 Assembly Steps

1. **Attach Cam Locks and Dowels:** Insert cam locks and wooden dowels into the designated holes on the main panels according to the provided diagrams.
2. **Assemble Base and Side Panels:** Connect the bottom panel to the side panels using the cam locks and dowels. Ensure a snug fit.
3. **Install Back Panels:** Secure the back panels into the grooves on the assembled frame. Use small nails or screws as indicated in the manual.
4. **Attach Top Panel:** Connect the top panel to the assembled structure using cam locks and dowels.
5. **Insert Shelves:** Place shelf pins into the desired height holes on the side panels. Carefully slide the shelves onto the pins. The shelves are adjustable to accommodate items of various heights.
6. **Install Door Hinges:** Attach hinges to the acrylic doors and then to the cabinet frame. Adjust hinges as needed to ensure doors close properly and are aligned.
7. **Attach Handles:** Secure the handles to the acrylic doors.
8. **Install Anti-Tip Device:** Securely attach the anti-tip device to the top rear of the cabinet and then to a wall stud using appropriate hardware. This step is critical for safety.

Assemble the item gently to prevent damage. Refer to the detailed diagrams in your included paper manual for specific part identification and step-by-step visual guidance.




Image 1: Detailed dimensions of the FAMAPY Display Cabinet, including overall height (78.7 inches), width (47.2 inches), and depth (15.7 inches), along with internal shelf spacing.



Image 2: The FAMAPY Display Cabinet showcased in a modern living room or office environment, demonstrating its capacity for storing and displaying various items behind its clear acrylic doors.

5. OPERATING INSTRUCTIONS

The FAMAPY Display Cabinet is designed for straightforward use and organization.

- **Opening/Closing Doors:** Gently pull the handles to open the acrylic doors. Push them closed until they latch securely. Avoid forcing the doors.
- **Adjusting Shelves:** The cabinet features adjustable shelves. To change a shelf's height, remove all items from the shelf, lift the shelf, remove the shelf pins, reposition the pins to the desired height, and then place the shelf back onto the pins. Ensure all four pins are securely in place before loading the shelf.
- **Display and Storage:** Utilize the various shelf sizes to store and display a wide range of items, from books and collectibles to kitchen supplies and decorative pieces.



Image 3: The display cabinet showcasing various trophies, awards, and decorative items, highlighting its suitability for collectible display.



Image 4: The cabinet configured for kitchen storage, displaying bottles, various dishware, and small appliances, demonstrating its functional versatility.

6. MAINTENANCE

Proper care will help maintain the appearance and longevity of your FAMAPY Display Cabinet.

- **Cleaning:** The cabinet's polished surface is waterproof and easy to clean. Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish or acrylic doors.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the engineered wood.
- **Dusting:** Regularly dust the cabinet and acrylic doors with a soft, dry cloth to prevent dust buildup.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your display cabinet, refer to the following common problems and solutions:

- **Cabinet is Wobbly:**

- Ensure the cabinet is placed on a completely level surface.
- Check that all cam locks and screws are fully tightened.
- Verify the anti-tip device is securely installed to the wall.

- **Doors Do Not Align or Close Properly:**

- Adjust the hinges. Most hinges have screws that allow for minor adjustments in door position (up/down, left/right, in/out).
- Ensure the cabinet frame is square and level.

- **Missing Parts:**

- Double-check both packages.
- Refer to the package contents list. If parts are genuinely missing, contact FAMAPY customer support with your purchase details.

- **Difficulty Assembling:**

- Review the assembly instructions carefully, paying close attention to diagrams.
- Ensure you have a second person assisting, as recommended.
- Do not force parts together; if they don't fit, re-check the orientation.

8. SPECIFICATIONS

Brand	FAMAPY
Color	White
Product Dimensions	15.7"D x 47.2"W x 78.7"H
Special Feature	Acrylic Door
Mounting Type	Floor Mount
Room Type	Bedroom, Hallway, Home Office, Living Room
Door Style	Acrylic
Included Components	Shelves
Finish Type	Polished
Shape	Rectangular
Number of Shelves	6
Number of Pieces	2 (shipped in 2 packages)
Base Type	Legs
Installation Type	Freestanding
Top Material Type	Engineered Wood
Back Material Type	Engineered Wood
Assembly Required	Yes

Frame Material	Engineered Wood
Number of Levels	6

9. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product issues, please contact FAMAPY customer support. Keep your purchase receipt and product information handy when contacting support.

While specific warranty details are not provided in this manual, most products come with a manufacturer's warranty covering defects in materials and workmanship. Please refer to your purchase documentation or the FAMAPY official website for detailed warranty information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question